


Purchasing Dept  
Copy



**HIGHLEAD**

**GC20688-1-D**

**1-Needle Compound-feed Lockstitch Machine With Thread  
Trimmer**

**Instruction Manual  
Parts Catalog**

**SHANGHAI HUIGONG NO.3 SEWING MACHINE FACTORY**



---

----- CONTENTS -----

1.	PRECAUTIONS BEFORE STARTING OPERATION .....	1
1)	Safety precautions.....	1
2)	Precaution before Starting Operation .....	1
3)	Precaution for Operating Conditions .....	1
2.	SPECIFICATIONS.....	1
3.	PREPARATION BEFORE STARTING TO OPERATE.....	2
1)	Connection of control box.....	2
2)	Oil pan .....	3
3)	Operation panel.....	3
4)	Adjusting the needle stop position .....	3
5)	Lubrication .....	4
4.	HOW TO USE THE MACHINE.....	5
1)	Threading .....	5
2)	Adjusting of the thread regulator.....	5
3)	Adjusting of upper thread tension .....	5
4)	Winding the lower thread .....	5
5)	Threading the lower thread.....	6
6)	Adjusting the lower-thread tension.....	6
7)	Installing the needle.....	6
8)	Alternating presser foot movement amount.....	6
9)	Adjusting the presser foot pressure .....	7
10)	Adjusting the stitch length.....	7
11)	Using the manual switches.....	7
12)	Cleaning.....	8
13)	Lubrication .....	8
14)	Adjusting the trailing length after thread trimming.....	9
15)	Back tacking .....	9
16)	Adjusting the feed dog .....	10
17)	Adjusting the needle bar height.....	10
18)	Adjusting the gap between the needle and the rotary hook tip .....	10
19)	Adjusting of the needle and the hook timing.....	11
20)	Hook protection .....	11
21)	Adjusting the needle and feed mechanism timing .....	11
22)	Adjusting the opener position .....	12
23)	Adjusting the presser foot height .....	13
24)	Adjusting the alternating presser foot movement amount.....	13
25)	Adjusting the presser foot timing .....	15
26)	Adjusting the fixed knife position .....	15
27)	Adjusting the thread holding spring position.....	16
28)	Adjusting the knife timing position.....	16
29)	Adjusting the driving knife height .....	16
30)	Adjusting the driving knife stop position.....	16

---

---

31) Adjusting the driving knife operating position .....	17
32) Adjusting the thread trimming timing .....	18
33) Safety clutch .....	18

**----- PARTS LIST -----**

<b>A.ARM BED AND ITS ACCESSORIES .....</b>	<b>20</b>
<b>B.THREAD TENSION REGULATOR MECHANISM.....</b>	<b>23</b>
<b>C.SEWING MECHANISM.....</b>	<b>26</b>
<b>D.PRESSER FOOT MECHANISM.....</b>	<b>29</b>
<b>E.UPPER FEED LIFTING ROCK SHAFT MECHANISM.....</b>	<b>33</b>
<b>F.STITCH REGULATOR MECHANISM .....</b>	<b>36</b>
<b>G.FEEDING AND FEED LIFTING &amp; ROTATING HOOK SHAFT MECHANISM .....</b>	<b>39</b>
<b>H.HOOK SADDLE MECHANISM .....</b>	<b>42</b>
<b>I.OIL LUBRICATION MECHANISM .....</b>	<b>46</b>
<b>J.ACCESSORIES .....</b>	<b>49</b>
<b>K.PNEUMATIC CONTROL UNIT .....</b>	<b>51</b>

# 1. PRECAUTIONS BEFORE STARTING OPERATION

## 1) Safety precautions

- (1) When turning the power on, keep your hands and fingers away from the area around/under the needle and the area around the pulley.
- (2) Power must be turned off when the machine is not used, or when the operator leaves his/her seat.
- (3) The power must be turned off before tilting the machine head, installing or adjusting the machine, or when replacing.
- (4) Avoid placing fingers, hairs, bars etc. nears the pulley, bobbin winder pulley, when the machine is operation. Injury could result.
- (5) Do not insert fingers into the thread take-up cover, under/round the needle, or pulley when the machine is in operation.
- (6) If a mini motor cover, finger guard, and/or eye guard are installed, do not operate the machine without these safety devices.

## 2) Precaution before starting operation

- (1) If the machine's oil pan has an oil sump, never operate the machine before filling it.
- (2) If the machine is lubricated by a drop oiler, never operate the machine before lubricating.
- (3) When a new sewing machine is first turned on, verify the rotational direction of the pulley with the power on. (The pulley should rotate counterclockwise when viewed from the pulley.)
- (4) Verify the voltage and (single or three) phase with those given on the machine nameplate.

## 3) Precaution for Operating Conditions

- (1) Avoid using the machine at abnormally high temperature (35°C or higher) or low temperatures (5°C or lower). Otherwise, machine failure may result.
- (2) Avoid using the machine in dusty conditions. Avoid using the machine in areas where too much electrical noise, resulted from the high-frequency welder and others, is generated

# 2. SPECIFICATIONS


Item	Specifications
Max. Speed	3,500rpm
Stitch length	0 - 9mm
Needle bar stroke	34mm
Presser foot clearance	By hand 9 mm
	By knee 16 mm
Needle	DP×17 #18-#25
Rotating hook	Large vertical hook (1.6 times)
Presser foot alternation	1-7mm
Auto presser foot lifter	Pneumatic
Oil lubrication method	Automatic lubrication
Bed dimensions	300×120 mm

### 3. PREPARATION BEFORE STARTING TO OPERATE

#### 1) Connection of control box


It shows the connection of the electrical wires of the whole machine on the right picture.

When the machine needs to be assembled, each line should be linked to the right joint according to the instruction of the picture.




All the pins on the control box have signals of function showing, and usually, different wires have different kinds of joint.

**Caution:** the pin of synchronizer wire is the same with another two external pins and if there is a misconnection, the synchronizer might be burn.




When connecting the pipes, please check the joint at the picture of the whole machine above as reference.

And also there have an instruction mark of each joint of the solenoid at the setting board.




## 2) Oil pan

(1) Install the oil pan 3 to the underside of the worktable 1 in the place shown in the illustration using the nails 2.




(2) From front view, the oil pan 3 to the side is 60mm; from right view, the oil pan 3 to the side is 80mm.



## 3) Operation panel

(1) Install the operation panel 1 to the set plate 2 with the three screws 3.

(2) Install the set plate 2 to the back of the machine arm with the two screws 4.





## 4) Adjusting the needle stop position

(1) Adjusting the needle up stop position

When the sewing machine stops in the needle up stop position (the stop position of trimming) and the treadle is pressed back, the red mark on the pulley should be consistent with the mark on the belt cover A. Adjust as follows:

- a. Turn off the power switch.
- b. Loosen the screw 4. and then remove the cover 3.

c. When the red mark stops in a position over the mark on the belt cover, the needle up stop position disc 1 should be turned in the opposite direction as the direction of machine pulley rotation. When the red mark stops in a position under the mark on the belt cover, Turn the disc 1 in the same direction as the pulley rotation direction.



## (2) Adjusting the needle down stop position

When the sewing machine stops in the needle down stop position, the black mark on the pulley should be consistent with the mark on the belt cover A. Adjust as follows:

a. Turn off the power switch.


b. When the black mark stops in a position over the mark on the belt cover, the needle down stop position disc 2 should be turned in the opposite direction as the direction of machine pulley rotation. When the black mark stops in a position under the mark on the belt cover, Turn the disc 2 in the same direction as the pulley rotation direction.

c. After adjusting, install the cover 3, with screw 4.

**Note: There is no need to loosen the screw 5, when turning the discs.**

## 5) Lubrication

Before the new machine is used, please loosen the screw 2 and full the oil into the oil case. Set the oil level between “EMPTY” and “FULL”. Then replace oil-filling screw 2.





## 4. HOW TO USE THE MACHINE


### 1) Threading

Raise the thread take-up lever to its highest position and thread the upper thread in the following order.

### 2) Adjusting of the thread regulator




The thread regulator 9 (see the right picture) regulates the amount of needle thread necessary for stitch formation. The setting depends on the following factors: material thickness, yarn characteristics and stitch length.

The thread regulator is fitted with slots for this purpose. Moving in the “+” direction increases the quantity of needle thread; Moving in the “-” direction reduces the quantity of needle thread.



### 3) Adjusting of upper thread tension

Tension should be as low as possible. The crossover point should be in the center of the material. Upper thread tension can be adjusted by thread tension nut 4 and 5 (see the picture of above). Turn the thread tension nut clockwise to increase the needle thread tension. Turn the thread tension nut counter-clockwise to decrease the needle thread tension.




### 4) Winding the lower thread

(1) Place the bobbin onto the bobbin winder shaft.

(2) Pass the thread for winding thread as shown in the figure, and wind the end of the thread clockwise around the bobbin several times.

(3) Push the bobbin presser 1 toward the bobbin.

(4) The operation will automatically stop when winding is completed. The amount of thread wound onto the bobbin should be a maximum of 80% of the bobbin capacity.



1 2


(5) After the thread has been wound on, remove the bobbin and cut the thread with the thread-trimming knife 2.

### 5) Threading the lower thread

(1) Raise flap 1 and remove the empty bobbin.

(2) Insert bobbin 2 in such a way that when the thread is unwound from it moves in the opposite direction to the gripper.

(3) Pass the thread through slit 3 and below spring 6, pass the thread through slit 4 and pull about 3 cm through.



(4) Close flap 1 and pass the thread through the flap's guide 5.


### 6) Adjusting the lower-thread tension

The lower-thread tension should be set in accordance with the type of seam required. Adjust the tension with screw 7. (See the picture of above)

### 7) Installing the needle


**Note:** Before the following adjustment, be sure to turn off the power switch.

Insert the needle up to the bottom of needle clamp and tighten the screw 1 keeping the long groove side of needle forward the left.




### 8) Alternating presser foot movement amount

The alternating movement amount for the inner presser foot and the outer presser foot can be adjusted within the range of 1-7 mm using the alternating presser foot movement dial 1. Turn the alternating presser foot movement dial 1 clockwise or counterclockwise to align the mark. (MIN. A, B, C, D, E, F MAX. )



## 9) Adjusting the presser foot pressure

The presser foot pressure should be set as weak as possible, but strong enough so that the material does not slip. If the presser-adjusting dial 1 is turned clockwise, the presser foot pressure will become stronger, and if it is turned counterclockwise, the pressure will become weaker.



## 10) Adjusting the stitch length

The feed adjustment dials 2 and 3 can be used to set two different types of stitch length. (See the picture of above) Use feed adjustment dial 2 to set the big stitch length. Use feed adjustment dial 3 to set the little stitch length. The sewing machine will switch between the two stitch lengths each time the stitch length change switch is pressed.

## 11) Using the manual switches

### (1) Quick reverse switch

Back tacking is carried out during sewing only while the switch 1 is being pressed.

### (2) Alternating presser foot movement change switch

The sewing machine can be switched between two different alternating presser foot movement amounts each time when the switch 2 is pressed.

### (3) Auto back tacking select switch

If the switch 3 is pressed when either start back tacking or end back tacking has been set to ON at the operation panel, back tacking is canceled for the first time only. Furthermore, if the switch 3 is pressed when neither starting nor end back tacking has been set, back tacking is carried out for the first time only.

### (4) Needle up or down switch


If the switch 4 is pressed, The needle will move up to the needle up stop position from down stop position or move down to the needle down stop position from up stop position.

### (5) Stitch length change switch

The stitch length changes alternately between two different stitch length settings each time the switch 5 is pressed. OFF: Sewing is carried out using the big stitch length; ON: Sewing is carried out using the little stitch length.

### (6) Stitch counter switch

The orange light on the switch will flash and the machine will stop when the bobbin thread is used up.




Push the switch one more time after change the bobbin. The sewing machine cannot run before the switch be pushed one more time. The stitch count should be set according to the stitch length and the count of the bobbin thread. **Notice:** the switch is not work until the correlative functions of the control box are set. The functions please read the parameter 42, 43, 44 in the servo motor user manual.

## 12) Cleaning


- (1) The area around the feed dog and the hook should be cleaned every day.
- (2) Remove any thread scraps from inside the rotary hook.
- (3) Keep the control box clean.

## 13) Lubrication


- (1) Check the oil level at the sight glass 1 every week. If the oil is not enough, remove oil-filling screw 2 and pour in oil. Check oil level at sight glass 2. The oil level must be between "EMPTY" and "FULL". Replace oil-filling screw 2. After running for 500 hours since buying the new sewing machine, the oil must be changed. Then change the oil every two years.
- (2) The oil quantity is pre-set at a relatively high level in order to ensure adequate lubrication during running-in. This setting should be checked and corrected after running-in. (approx. 50 hours).



The hook is to have positive lubrication with the least possible amount of oil. Let the sewing machine run approx. 2 minutes. And run in intervals. Hold a piece of paper next to



the hook and check if sufficient oil is spun onto the paper. Remove cover plate 2. Loosen screw 3 until the tube 1 no longer moves. This is the case when the tube is in the center of the drilled hole. Turn screw 3




in until the tube movement just starts and then a 1/8 turn farther. The hook lubrication is preset. Attach cover plate 2 again. Setting the hook lubrication with screw 3.

(3) Lubricating wicks and felt (see the picture of above)

- a. The wick 1 leading from the oil sump to the oscillating crank 4 must be fixed between the groove 2 in the arm and the spring 3 of the recirculation wick.
- b. When the oil satchel is changed, the flock side should be faced to connecting plate 10. The oil wick 7 and 8 should be set between the oil satchel 9 and plate 8.


(4) Checking the lubrication oil.

Turn on the power switch. Depress the treadle gently and check that the oil level rises in the oil sight glass.




**14) Adjusting the trailing length after thread trimmin**

Adjust by turning the pre-tensioner 1. If the tension of the pre-tension is increased, the lengths of the threads trailing from the needle tips will be reduced; if the tension is reduced, the lengths will be increased.



**15) Back tacking**


When the reverse lever 1 or the quick reverse switch is pressed during sewing, the feed direction will be reversed. When it is released, the feed direction will return to normal.



## 16) Adjusting the feed dog

Set the feed adjustment dials to the minimum settings. Then adjust as follows so that the feed dog 1 is at its highest position (0.5mm above the top of the needle plate 2) when the needle bar is at its lowest position.


- (1) Turn the machine pulley to set the feed dog 1 is at its highest position.
- (2) Loosen the screw 3.
- (3) Adjust the feed dog's height.
- (4) Tighten the screw 3.



## 17) Adjusting the needle bar height

Set the feed adjustment dials to the minimum settings. Then adjust so that the distance from the setting surface of the needle plate 2 to the end of the needle bar 1 is 18.5mm when the needle bar 1 is at its lowest position.

- (1) Remove the face plate.
- (2) Set the feed adjustment dials to "0".
- (3) Turn the pulley to set the needle bar 1 to its lowest position.
- (4) Loosen the screw 3 and then move the needle bar 1 up or down to adjust so that the distance from the setting surface of the needle plate 2 to the end of the needle bar 1 is 18.5 mm.
- (5) Tighten the screw 3, install the face plate.






## 18) Adjusting the gap between the needle and the rotary hook tip

The gap between the needle and the rotary hook tip 1 is 0.1 mm.

Set the rotary hook tip at the level of the middle of the needle. Then adjusting the gap as follow:


- (1) Loosen the screws 2 and 5 (see the picture of below).
- (2) Set the hook base 6 to the fit position.
- (3) Rotate the adjusting plate 3, let the hook base 6 depend on the bed plate 4.
- (4) Tighten the screws 2 and 5.





## 19) Adjusting of the needle and the hook timing


- (1) Set the stitch length to "0".
- (2) Remove the needle plate.
- (3) Overturn the arm.
- (4) Loosen the screw 1
- (5) Turn the machine pulley to raise the needle bar from its low position to the point that the needle rises 2.4 mm.
- (6) Turn the rotary hook to align the rotary hook tip with the center of the needle.
- (7) Tighten the screw 1.



## 20) Hook protection

In looping stroke position the needle must abut on the hook protection 1 without being displaced.

Move needle in looping stroke position by pulley. In looping stroke position the hook tip is at the level of the middle of the needle. Press needle against hook protection 1 manually. The needle should not touch the hook tip.




## 21) Adjusting the needle and feed mechanism timing

- (1) Horizontal feed direction

Set the feed adjustment dials to the maximum settings. Then turn the machine pulley until the needle bar is at its lowest position. Then adjust so that the needle and the feed dog do not move even when the reverse lever is moved up and down at this time.

- a. Remove the bed upper cover 1.
- b. Set the feed adjustment dial to the maximum settings.
- c. Loosen the two screws 2.



d. Turn the machine pulley until the needle bar is at its lowest position.

e. Turn the lower feed cam 3 gradually until it is at the position where the needle and the feed dog do not move even when the reverse lever is moved up and down.

f. Tighten the two screws 2.

## (2) Vertical feed direction


Set the feed adjustment dials to the minimum settings. Then adjust as follows so that the feed dog 1 is at its highest position (0.5mm above the top of the needle plate 2) when the needle bar is at its lowest position.

a. Loosen the two screws 3

b. Turn the machine pulley to set the needle bar to its lowest position.

c. Turn feed cam 4 to align the point 5 of feed cam 4 with the centerline of feed rod 6

d. Tighten the screws 3




## 22) Adjusting the opener position

Adjust so that the clearance between the needle plate 3 and the stopper 4 of the inner rotary hook 2 is 0.5-0.7 mm when the opener 1 is at its closest position to the inner rotary hook 2.

(1) Turn the machine pulley to move the opener 1 in direction "a" (opening direction), and then loosen the screw 5

(2) Turn the machine pulley to move the opener 1 in direction "b" (closing direction), and then loosen the





screw 6.

(3) Turn the machine pulley to move the opener 1 as close to the inner rotary hook 2 as possible.

(4) While pressing the opener 1 against the inner rotary hook 2 with your finger, adjust so that the clearance between the needle plate 3 and the stopper 4 of the inner rotary hook 2 is 0.5-0.7 mm.

(5) Tighten the screw 6.

(6) Turn the machine pulley to move the opener 1 in direction "a" (opening direction), and then tighten the screw 5.

### 23) Adjusting the presser foot height

The standard height of the outer presser foot 7 is 9 mm when it is raised by the presser lifter bar 1.

(1) Remove the belt cover.

(2) Loosen the presser adjusting screw, to release the presser foot pressure.


(3) Raise the presser lifter bar 1 and then loosen the screw 2.

(4) Move the outer presser bar up or down to adjust so that the height of the outer presser foot 7 is 9 mm.

(5) While the stopper pin 6 is touching against the notch B in the presser foot lifter connection 5 and while pushing the presser lifter shaft so that there is no play in the thrust direction, tighten the screw 2.

(6) Turn the presser adjusting screw to adjust the presser foot pressure.

(7) Install the belt guards.



### 24) Adjusting the alternating presser foot movement amount

(1) Maximum alternating presser foot movement amount. Carry out the following adjustment to set the maximum alternating movement amounts for the inner presser foot 1 and outer presser foot 2 to the maximum of 7 mm.




- a. Remove the upper plate.
- b. Remove the adjusting bracket 3.
- c. Loosen screw 5 of adjusting bracket collar 4.

d. Adjust the adjusting bracket collar 4. If the adjusting bracket collar 4 is be installed at the highest position, the alternating presser foot movement amount is 1-6mm. If it is at the lowest position, the alternating presser foot movement amount is 1.6-7mm.

e. Tighten the screw 5.

f. Install the adjusting bracket 3.

d. Loosen the bolt 6 and turn connecting lever 7 to adjust so that the distance from the outer edge of the arm to the outer edge of the pin 7 is 78 mm at this time. Then tighten the bolt 6. (When installing the upper plate, set the alternating presser foot movements dial to the “min.” position.)




(2) Inner presser foot 1 and outer presser foot 2 movement amounts. Carry out the following adjustment to make the movement amounts for the inner presser foot 1 and outer presser foot 2 equal when the presser feet are lowered and the machine pulley is turned.

a. Set the feed adjustment dials to the maximum settings.

b. Open the cover 4


c. Turn the alternating presser foot movement dial to the “B” position.

d. Loosen the screw 3




e. Turn the machine pulley toward you to align the tip of the needle and the top of the feed dog with the top of the needle plate.

f. Move the connecting lever to adjust so that both the inner presser foot 2 and outer presser foot 1 are in contact with the top of the needle plate at this time. Then tighten the screw 3.



## 25) Adjusting the presser foot timing

When the presser feet are lowered and the machine pulley is turned toward you. The inner presser foot should touch the feed dog before the needle arrives at the feed dog. Then when the needle lifts up, the tip of the needle should move away from the feed dog before the inner presser foot moves away.





- (1) Remove the upper cover 4.
- (2) Loosen the two screws 1.
- (3) Turn the machine pulley until the needle tip and the feed dog's up face is the same plane.
- (4) Turn inner presser cam to adjust so that the point of inner presser cam is facing straight up.
- (5) Tighten the screws 2.
- (6) When installing the upper plate, set the alternating presser foot movement dial to the "MIN." position.

## 26) Adjusting the fixed knife position

The distance from the groove of slide plate to the fixed knife 1 should be 26 mm. Furthermore, the distance from the edge of the needle plate to the left edge of the tip of the fixed knife 1 should be 4 mm.

- (1) Loosen the two bolts 2.
- (2) Adjust the position of the fixed knife 1, and then tighten the bolts 2.



## 27) Adjusting the thread holding spring position (see the picture of above)

The thread holding spring 1 holds the lower thread after thread trimming to prepare it for the next sewing operation. The clearance between the thread holding spring 1 and the side of the fixed knife 2 should be 1.4-1.6 mm.


- (1) Loosen the two screws 3.
- (2) Move the thread holding spring 1 to adjust its position, and then tighten the screws 3.

## 28) Adjusting the knife timing position

After adjusting the position of the fixed knife 1, adjust the knife timing position.

Adjust so that the driving knife 1 starts touching the fixed knife at a position 5.5 mm along the front edge of the driving knife 1.


- (1) Loosen the two bolts 3 and 4.
- (2) Move the driving knife 1 to the left or right to adjust its position.
- (3) Then tighten the bolts 3 and 4.



## 29) Adjusting the driving knife height

The clearance between the lower blade edge of the driving knife 1 and the lower surface of the inner rotary hook should be 0.3-0.4mm.

- (1) Loosen the two screws 2 and 5.
- (2) Move the driving knife shaft 6 up or down to adjust the position of the driving knife 1.
- (6) Tighten the screws 2 and 5 on the setting collars again.





## 30) Adjusting the driving knife stop position

The distance from the blade of the fixed knife 2 to the end of the driving knife 1 should be 0.5 mm when the driving knife 1 has moved as far as possible toward the fixed knife 2.

- (1) Tilt back the machine head.
- (2) Turn the machine pulley to move the roller 4 of the driving knife arm 3 to the outermost side (right side) of the thread trimmer cam 5.

(3) Loosen the bolt 6.

(4) Move the driving knife 1 so that the distance between the blade of the fixed knife 2 to the end of the driving knife 1 is 0.5 mm, and then tighten the bolt 6.



### 31) Adjusting the driving knife operating position

The standard distance from the left side of driving knife arm 1 to the screw tip on the plunger 2 of the thread trimming solenoid is 1 mm. The clearance between the outermost side (right side) of the thread trimmer cam 5 and the roller 6 of the driving knife arm should be 0.1 mm.

(1) Overturn the arm.

(2) Loosen the bolt 3


(3) Turn the plunger 2 of the thread trimming solenoid so that the distance from the left side of driving knife arm 1 to the screw tip on the plunger 2 of the thread trimming solenoid is 1 mm, and then tighten the bolt 3.

(4) Loosen the bolt 4.

(5) Set the plunger 2 to the position where it projects as far as possible to the left.

(6) Turn the machine pulley to move the roller 6 of the driving knife arm to the outermost side (right side) of the thread trimmer cam 5.

(7) Move the roller 6 so that the clearance between the outermost side (right side) of the thread trimmer cam 5 and the roller 6 is 0.1mm, and then tighten the bolt 4.



### 32) Adjusting the thread trimming timing

The center of the pin 1, the center of the reference hole 3 and the center of the roller 4 of the driving knife arm should be in a straight line when the thread take-up lever is at the highest position. (The white point on the pulley and the point on the belt cover are in a straight line.)


(1) Turn the machine pulley until the white point on the pulley and the point on the belt cover are in a straight line.

(2) Overturn the arm.

(3) Loosen the three bolts 5

(4) Turn the thread trimmer cam 2 to adjust the position of the thread trimmer cam 2 so that the center of the pin 1, the center of the reference hole 3 and the center of the roller 4 of the driving knife arm are in a straight line.

(5) Tighten the bolts 5.



### 33) Safety clutch

The standard safety clutch 2 in the lower toothed belt wheel protects the hook from being displaced or damaged in case of thread jamming in the hook path. When the hook is blocked, the safety clutch 2 must come out.

(1) Set free blocked hook.

(2) Stick a pin in drill-hole 1 of the outer clutch disc.

(3) Turn the pulley until the pin can be stuck in the drill-holes of both clutch parts.

(4) Turn the pulley forwards and backwards until the hook is freely movable again.

(5) Pull out pin.


(6) Hold down hook and turn the pulley until safety clutch 2 engages.

Adjust transmittable torque

Standard checking


The torque transmittable from safety clutch 4 should be adjusted by the supplier by means of a torque spanner.

(1) Loosen counter-nuts 3.




(2) Adjust torque

(3) Tighten counter-nuts 3 again.



# A.ARM BED AND ITS ACCESSORIES



From the library of: Diamond Needle Corp




## A.ARM BED AND ITS ACCESSORIES

Fig. No.	Part No.	Description	Pcs.	Remarks
A01	HF914B8001	Screw M5×12	4	
A02	H005001040	Washer	1	
A03	H415040080	Screw	1	M4×8
A04	HF927B8001	Thread take-up cover	1	
A05	HF930B8001	Plug	1	
A06	HF933B8001	Dial	1	
A07	HF935B8001	Dial shaft	1	
A08	HF936B8001	Guard plate	1	
A09	HF931B8001	Cover	1	
A10	H003045040	Hexagonal nut	1	M4
A11	H005001040	Washer	1	
A12	H401040060	Screw	1	M4×6
A13	HA710B0671	Pre-tension adjusting nut	1	
A14	H6739B8001	Thread tension spring	1	
A15	HA310B0705	Thread tension discs	2	
A16	H6736B8001	Thread guide	1	
A17	HF974B8001	Thread tension stud	1	
A18	H4728H8001	Washer	1	
A19	H5344B8001	Nut	1	
A20	HF965B8001	Fixing clamp	1	
A21	HF964B8001	Winder shaft	1	
A22	H401030120	Screw	1	M3×12
A23	HF952B8001	Disc	1	
A24	H5731F8001	Presser spring	1	
A25	HF954B8001	Knife	1	
A26	H401030040	Screw	1	M3×4
A27	HF947B7101	Release lever	1	
A28	H401030120	Screw	1	M3×12
A29	H403040080	Screw	2	M4×8
A30	HF921B7101	Arm cover	1	
A31	H901030080	Pin	1	
A32	HF942B7101	Winder block	1	
A33	HF944B8001	Release cam	1	
A34	H431050060	Screw	1	M5×6
A35	HF958B8001	Block	1	
A36	HF955B8001	Bushing	1	
A37	H007013035	E-type stop ring 3.5	1	
A38	HA300E2110	Presser spring	1	
A39	HF957B8001	Washer	1	
A40	HF960B8001	Arm	1	
A41	HF959B8001	Presser spring	1	
A42	HF966B8001	Washer	2	
A43	HF967B8001	Winder wheel	1	

## A.ARM BED AND ITS ACCESSORIES

Fig. No.	Part No.	Description	Pcs.	Remarks
A44	HF969B8001	Rubber ring	1	
A45	H431050050	Screw	1	M5×5
A46	HF999B8001	Cord cover	1	
A47	H7331G8001	Screw	1	
A48	HF914B8001	Screw M5×12	1	
A49	HF915B8001	Screw M5×12	1	
A50	HF918B8001	Bar	1	
A51	HF913B8001	Face plate	1	
A52	HF919B8001	Bar	1	
A53	HF920B8001	Oil pillow	1	
A54	HF998B8001	Leg	1	
A55	HF980B8001	Slide Plate	1	
A56	HF988B8001	Needle plate	1	
A57	HF989B8001	Screw	2	
A58	HF981B8001	Slide Plate	1	
A59	HF985B8001	Slide Plate	1	
A60	HF986B8001	Spring for slide plate	2	
A61	H401020025	Screw	2	M2×2.5
A62	HF982B8001	Stopper	1	
A63	H7331G8001	Screw	2	
A64	HF938K8001	Pipe	1	
A65	HF914B8001	Screw M5×12	10	
A66	HF997B8001	Gasket	10	
A67	HF991B8001	Cover	1	
A68	HF992B8001	Oil indicator	1	
A69	HF993B8001	Screw	1	
A70	HF994B8001	Gasket	1	
A71	HF995B8001	Gasket	1	
A72	H3108B0692	Felt	1	
A73	H3108B0691	Thread guide	1	
A74	HF938C8001	Screw	1	
A75	HA307B0674	Rubber plug	1	
A76	HF90AB8001	Gasket	2	
A77	JB1000 M10×1	Screw	1	M10×1
A78	HG605H8001	Rubber plug	1	
A79	HF981I8001	Pin	1	
A80	H7335C8001	Washer	2	
A81	H428080120	Screw	1	M8×12
A82	H007013060	E-type stop ring 6	1	
A83	GB/T276 28	Bearing	2	
A84	HF980I8001	Spacer	1	
A85	HF979I8001	Belt tensioner	1	

# B.THREAD TENSION REGULATOR MECHANISM



From the library of: Diamond Needle Corp


## B.THREAD TENSION REGULATOR MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
B01	H003002050	Nut	1	M5
B02	HF930C8001	Thead hook	1	
B03	HF929C8001	Thread tension stud	1	
B04	HA112B0693	Thread tension discs	1	
B05	HA710B0672	Tension spring	1	
B06	HA710B0671	Tension adjusting nut	1	
B07	HF907C8001	Thread tension stud	2	
B08	HF917C8001	Thread guide	1	
B09	H3221B6817	Thread tension releasing pin	2	
B10	H3221B6811	Shoulder screw	2	
B11	H7316B8001	Screw	2	
B12	HF925C8001	Thread guide	1	
B13	H7322B8001	Screw	2	
B14	H7316B8001	Screw	2	
B15	HF905C8001	Tension plate	1	
B16	HF923C8001	Rod	1	
B17	HF924C8001	Sping	1	
B18	HF915C8001	Tension release plate	1	
B19	HF916C8001	Thread guide	1	
B20	HA310B0705	Tension discs	4	
B21	HA310B0702	Tension release discs	2	
B22	H4710C8001	Tension spring	2	
B23	HA115B7010	Stopper	2	
B24	HA310B0701	Tension nut	2	
B25	H431040040	Screw	1	M4×4
B26	HF936C8001	Thread tension post	1	
B27	H431050050	Screw	1	M5×5
B28	H4805C8001	Thread tension stud	1	
B29	H4804C8001	Screw	1	
B30	H32481BD21	Plate complete	1	
B31	H4713C8001	Thread take-up spring	1	
B32	H32481B721	Thumb nut	1	
B33	H003045050	Nut	1	M5
B34	H003002050	Nut	1	M5
B35	HF918C8001	Release lever	1	
B36	H007013050	E-type stop ring 5	1	
B37	HF919C8001	Bolt	1	
B38	HF921C8001	Hook	1	
B39	HF908C8001	Spring	1	
B40	HF909C8001	Block	1	
B41	H005001040	Washer	1	
B42	H415040080	Screw	1	M4×8
B43	HF927I8001	Washer	1	

## B.THREAD TENSION REGULATOR MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
B44	H415040080	Screw	2	M4×8
B45	HF906C8001	Magnet support	1	
B46	HF922C8001	Solenoid	1	
B47	H403050120	Screw	2	M5×12

# C.SEWING MECHANISM



## C.SEWING MECHANISM


Fig. No.	Part No.	Description	Pcs.	Remarks
C01	H6715C8001	Screw	1	
C02	H431060080	Screw	1	M6×8
C03	HF907D8001	Crank	1	
C04	H431060060	Screw	1	M6×6
C05	HF914B8001	Screw	2	
C06	HF905D8001	Upper shaft	1	
C07	H3205J0662	Ball bearing	1	
C08	H431080100	Screw	1	M8×10
C09	HF913D8001	Counterweight	1	
C10	H007009200	Retainer ring	1	
C11	HF921D8001	Ball bearing	1	
C12	HF918D8001	Bushing	1	
C13	H431060060	Screw	2	M6×6
C14	HF943D8001	Bobbin winder driving wheel	1	
C15	H431060100	Screw	2	M6×10
C16	HF923D8001	Belt pulley(upper)	1	
C17	H431060080	Screw	1	M6×8
C18	H429060100	Screw	1	M6×10
C19	H007009200	Retainer ring	1	
C20	HF932D8001	Ball bearing	1	
C21	H431060080	Screw	2	M6×8
C22	HF929D8001	Bushing	1	
C23	H431060100	Screw	1	M6×10
C24	HF934D8001	Pulley	1	
C25	H005008080	Washer	1	
C26	H415080250	Screw	1	M8×25
C27	H429060100	Screw	1	M6×10
C28	H428050060	Screw	1	M5×6
C29	HF913G8001	Thread take-up pin	1	
C30	HF918G8001	Gasket	2	
C31	H7221G8001	Needle bearing	2	
C32	HF916G8001	Thread take-up support	1	
C33	H428050060	Screw	1	M5×6
C34	HF911G8001	Thread take-up pin bushing	1	
C35	HF919G8001	Support screw	1	
C36	HF909G8001	Bearing	1	
C37	HF910G8001	Bearing	1	
C38	HF907G8001	Thread take-up lever	1	
C39	HF908G8001	Bushing	1	
C40	H003008040	Nut	1	M4
C41	HF920G8001	Thread take-up crank	1	
C42	HF923G8001	Bearing	2	
C43	HF926G8001	Bushing	1	

# C.SEWING MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
C44	HF922G8001	Needle bar link	1	
C45	H431030050	Screw	1	M3×5
C46	H401040100	Screw	2	M4×10
C47	HF924G8001	Needle bar holder	1	
C48	HF928G8001	Threaded bolt	1	
C49	HF927G8001	Slide block	1	
C50	HF938G8001	Oil wick	1	
C51	H415040100	Screw	2	M4×10
C52	HF933G8001	Slide guide	1	
C53	HF939G8001	Oil feeding pipe	2	
C54	HF936G8001	Oil pipe	1	
C55	HF937G8001	Oil wick	1	
C56	HF940G7101	Rubber	1	
C57	HF970G8001	Needle bar	1	
C58	HF971G8001	Thread guide	1	
C59	H428030030	Screw	1	M3×3
C60	HF972G8001	Screw	1	
C61	HF974G8001	DP×35R #19	1	
C62	HF931G7101	Needle bar bracket	1	
C63	H403040100	Screw	1	M4×10
C64	HF943G8001	Oil satchel	1	
C65	HF947G8001	Oil wick	3	
C66	HF927E8001	Bushing	1	
C67	HF968G8001	Support disc	2	
C68	H415040120	Screw	2	M4×12
C69	H005001040	Washer	2	
C70	HF965G8001	Collar	2	
C71	HF924E8001	Bushing	1	
C72	H415060200	Screw	1	M6×20
C73	HF962G8001	Upper feed connecting rod	1	
C74	HF951G8001	Shoulder screw	1	
C75	HF949G8001	Connecting lever	1	
C76	H415060160	Screw	1	M6×16
C77	H007013080	E-type stop ring 8	2	
C78	HF958G8001	Oil wick	1	
C79	HF957G8001	Oil pipe	1	
C80	HF956G8001	Oil feeding pipe	1	
C81	HF952G7101	Pull rod	1	
C82	HF959G8001	Plug	1	



# D.PRESSER FOOT MECHANISM



From the library of: Diamond Needle Corp

## D.PRESSER FOOT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
D01	H428050080	Screw	4	M5×8
D02	HF919E8001	Support pin	1	
D03	HF906E8001	Adjusting bracket	1	
D04	H428050080	Screw	1	M5×8
D05	HF912E8001	Oil wick	1	
D06	HF911E8001	Oil pipe	1	
D07	HF908E8001	Oil wick	2	
D08	HF913E8001	Plate	1	
D09	H005018050	Washer	1	
D10	H415050100	Screw	1	M5×10
D11	HF956G8001	Oil feeding pipe	1	
D12	HF917E8001	Link pin	2	
D13	HF916E8001	Link	2	
D14	H415060200	Screw	1	M6×20
D15	HF951E8001	Connecting lever	1	
D16	HF956E8001	Pin	1	
D17	HF953E7101	Link	1	
D18	HA104D0652	Plug	1	
D19	HF942E8001	Inner presser cam	1	
D20	H428060060	Screw	2	M6×6
D21	HF946E8001	Inner presser rod	1	
D22	HF947E8001	Bearing	1	
D23	HF948E8001	Rod pin	1	
D24	HF949E8001	Oil wick	1	
D25	HF960E8001	Oil wick	1	
D26	HF961E8001	Plug	1	
D27	HF959E8001	Oil pipe	1	
D28	HF956G8001	Oil feeding pipe	1	
D29	HF924E8001	Bushing	1	
D30	HF923E8001	Collar	2	
D31	HF921E8001	Adjusting shaft	1	
D32	H431050050	Screw	2	M5×5
D33	HF927E8001	Bushing	1	
D34	HF928E8001	Ball pin	1	
D35	H415050120	Screw	1	M5×12
D36	HF926E8001	Lever	1	
D37	H415060200	Screw	1	M6×20
D38	HF940E8001	Pipe	2	
D39	HF914E8001	Pin	2	
D40	HF918E8001	Spring	2	
D41	HF933E8001	Draught rod	1	
D42	HF936E8001	Disc	1	
D43	HF935E8001	Gasket	1	


## D.PRESSER FOOT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
D44	HF934E8001	Piston	1	
D45	HF931E8001	Pipe	1	
D46	HF932E8001	Cylinder base	1	
D47	HF997B8001	Gasket	2	
D48	H005001050	Washer	2	
D49	H415050180	Screw	2	M5×18
D50	H415040160	Screw	1	M4×16
D51	H005001040	Washer	1	
D52	HF943E8001	Spacer	1	
D53	HF937E8001	Coupling	1	
D54	HF938E8001	Hose	1	
D55	HF939E8001	Coupling	1	
D56	HF962E7101	Shaft	1	
D57	H415040120	Screw	1	M4×12
D58	HF924E8001	Bushing	2	
D59	H402050080	Screw	2	M5×8
D60	HF923E8001	Collar	2	
D61	HF970E8001	Sponge	1	
D62	HF964E8001	Oil wick	1	
D63	H415030060	Screw	1	M3×6
D64	HF974E8001	Plate	1	
D65	HF973E8001	Oil satchel	1	
D66	HF972E8001	Draught rod	1	
D67	HF961E8001	Plug	1	
D68	HF983E8001	Oil pipe	1	
D69	HF984E8001	Oil wick	1	
D70	HF982E8001	Spring	1	
D71	HF986E8001	Oil wick	1	
D72	HF977E8001	Pin	1	
D73	H401040040	Screw	1	M4×4
D74	HF977E8001	Pin	1	
D75	HF978E8001	Oil wick	1	
D76	HF979E8001	Stopper claw	1	
D77	HF925F8001	Joint	1	
D78	HF926F8001	Pin	1	
D79	HF933F8001	Slide block	1	
D80	HF914B8001	Screw	2	
D81	HF934F8001	Guide	1	
D82	HF928F8001	Pin	1	
D83	HF930F8001	Oil wick	1	
D84	HF932F8001	Screw	1	
D85	HF979E8001	Stopper claw	1	
D86	HF939F8001	Oil wick	1	

## D.PRESSER FOOT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
D87	H431050100	Screw	1	M5 × 10
D88	HF940F8001	Bushing	1	
D89	HF938F8001	Outer presser bar	1	
D90	HF946F8001	Presser connecting plate	1	
D91	HF977E8001	Connecting pin	2	
D92	HF978E8001	Oil wick	2	
D93	HF979E8001	Stopper claw	2	
D94	H401040040	Screw	1	M4 × 4
D95	HF956F8001	Inner presser bar	1	
D96	HF959F8001	Inner presser foot	1	
D97	HF960F8001	Screw	1	
D98	HF943F8001	Outer presser foot	1	
D99	H401040100	Screw	1	M4 × 10
D100	H431040040	Screw	1	M4 × 4
D101	HF987E8001	Holder	1	
D102	HF922E8001	Potentiometer control	1	

# E.UPPER FEED LIFTING ROCK SHAFT MECHANISM



From the library of: Diamond Needle Corp


## E.UPPER FEED LIFTING ROCK SHAFT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
E01	H007013080	E-type retaining ring 8	1	
E02	HF965F7101	Press adjusting plate assy	1	
E03	HF963F8001	Pin	1	
E04	HF961F7101	Press adjusting dial	1	
E05	H007013050	E-type retaining ring 5	1	
E06	H612030080	Spring pin	2	
E07	HF976F8001	Spring support (U)	1	
E08	HF972F8001	Spring	1	
E09	HF975F8001	Hose	1	
E10	HF973F8001	Shaft	1	
E11	HF974F8001	Spring support (D)	1	
E12	H428080120	Bolt	1	M8×12
E13	HF905F8001	Press-foot lifter shaft bush(L)	1	
E14	HF922F8001	Oil wick	1	
E15	HF919F7101	Press-foot lifter connection assy	1	
E16	H605050320	Pin	1	
E17	HF904F8001	Press bar lifter shaft	1	
E18	HF906F8001	Spreader shaft bush(L2)	1	
E19	H424050160	Set screw	1	
E20	H003002050	Nut	1	
E21	HF997F8001	Stopper	1	
E22	HF996F8001	Crack	1	
E23	H415060160	Screw	1	M6×16
E24	HF910F8001	Set screw collar	1	
E25	H401050060	Screw	1	
E26	HF907F8001	Bushing(R)	1	
E27	HF909F8001	Bushing	1	
E28	HF908F8001	Bushing(R2)	1	
E29	H415060200	Screw	1	M6×20
E30	HF913F8001	Crack	1	
E31	HF915F8001	Washer	2	
E32	H005014080	Wave washer	1	
E33	HF916F8001	Lifter lever	1	
E34	HF917F8001	Screw	1	
E35	HF980F8001	Lever(U)	1	
E36	H415060160	Screw	1	M6×16
E37	H415050250	Screw	2	M5×25
E38	H003002050	Nut	4	M5
E39	H3405D0663	Link ball	2	
E40	HF984F8001	Knee lifter connecting bar	1	
E41	HF982F8001	Main spring	1	
E42	HF988F8001	Lever(D)	1	
E43	HF993F8001	Shaft	1	

## E.UPPER FEED LIFTING ROCK SHAFT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
E44	H007013090	E-type retaining ring	1	
E45	H415060160	Screw	1	M6×16
E46	H104060250	Screw	1	M6×25
E47	HF990F8001	Knee lifter plate	1	
E48	H7316E8001	Nut	1	

# F.STITCH REGULATOR MECHANISM



From the library of: Diamond Needle Corp







## F.STITCH REGULATOR MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
F01	HF925H8001	Spring	1	
F02	HF924H8001	Washer	1	
F03	HF922H8001	Feed adjusting arm	1	
F04	HF923H8001	Pin	1	
F05	H431050080	Bolt	1	M5×8
F06	HF905H8001	Feed adjusting screw (long)	1	
F07	HA700F2030	Positioning pin	2	
F08	H3200F2110	Spring	2	
F09	HA109F0674	O ring	2	
F10	HF914H8001	Feed adjusting screw (short)	1	
F11	HA720F0687	Spring	2	
F12	HA720F0683	Support plate	2	
F13	HA7421F120	Feed adjusting dial	2	
F14	HF909H8001	Feed adjusting dial plate(L)	1	
F15	HA720F0685	Bushing	2	
F16	HA720F0686	Screw	2	
F17	HF918H8001	Feed adjusting dial plate(S)	1	
F18	HF928H8001	Reverse shaft bushing(L)	1	
F19	HF932H8001	Pin	1	
F20	H428060080	Bolt	2	M6×8
F21	HF930H8001	Reverse stitching arm(U)	1	
F22	HF934H8001	Pin	1	
F23	H428060060	Bolt	1	M6×6
F24	HF927H8001	Collor	1	
F25	HF933H8001	Rod	1	
F26	H007013050	E-tpye retaining ring 5	2	
F27	HF970H8001	Reverse stitching shaft	1	
F28	HF931H8001	Reverse shaft bushing(R)	1	
F29	H6511H8001	Pin	1	
F30	H4937L8001	Bolt	1	
F31	H4938L8001	Rubber ring	1	
F32	HF969H8001	Spring	1	
F33	HF968H8001	Reverse stitching lever	1	
F34	HA3411D308	Bolt	1	
F35	H4936L8001	Reverse stitching lever block	1	
F36	HA113F0684	Bolt	1	
F37	HF937E8001	Coupling	2	
F38	H403060100	Screw	4	M6×10
F39	HF947H8001	Pump	1	
F40	HF954H8001	Ring	1	
F41	HF951H8001	Ring	1	
F42	HF950H8001	Piston	1	
F43	HF953H8001	Piston	1	

## F.STITCH REGULATOR MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
F44	H005001060	Washer	1	
F45	H104060250	Screw(D)	1	M6×25
F46	HF939H8001	Bolt	1	
F47	HF937H8001	Reverse stitching arm(D)	1	
F48	HF941H8001	Spring pin	1	
F49	H003001060	Nut	1	
F50	HF943H8001	Rod	1	
F51	HF942H8001	Pull spring	1	
F52	H424100100	Thread pin	1	M10×10
F53	H3100D2090	Presser spring	1	
F54	HF963H8001	Key	1	
F55	HF966H8001	Oil seal	1	
F56	HF958H8001	Shaft	1	
F57	HF967H8001	Oil seal	1	
F58	HF961H8001	Guide	2	
F59	H005009050	Elastic washer	4	
F60	H415050160	Screw	4	M5×16

# G.FEEDING AND FEED LIFTING & ROTATING HOOK SHAFT MECHANISM



From the library of: Diamond Needle Corp


## G.FEEDING AND FEED LIFTING & ROTATING HOOK SHAFT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
G01	HF928I8001	Feed shaft	1	
G02	HF959G8001	Rubber cap	1	
G03	HF965G8001	Adjusting shaft collar	1	
G04	H415040120	Bolt	1	M4×12
G05	HF927E8001	Bushing(L)	1	
G06	HF931I8001	Thurst ring	1	
G07	H007009150	E-type retaining ring	1	
G08	HF941I8001	Tube	1	
G09	HF942I8001	Oil wick	1	
G10	HF937I8001	Bushing	4	
G11	HF945I8001	Washer	3	
G12	HF935I8001	Feed arm(L)	1	
G13	HF936I8001	Bolt(L)	2	
G14	HF956G8001	Oil joint	1	
G15	HF946I8001	Spring	2	
G16	H007013050	E-type retaining ring 5	1	
G17	HF944I8001	Pin	1	
G18	HF939I8001	Tube support	1	
G19	HF948I8001	Bolt	2	
G20	HF951I8001	Screw	2	
G21	HF950I8001	Feed dog	1	
G22	HF949I8001	Feed bracket	1	
G23	HF953I8001	Pin	1	
G24	HF929I8001	Oil seal	3	
G25	HF927E8001	Feed shaft bushing(L)	1	
G26	HF927I8001	Washer	4	
G27	H415060120	Bolt(R)	2	M6×12
G28	HF923I8001	Feed shaft arm(R)	2	
G29	H007013050	E-type retaining ring 5	4	
G30	HF926I8001	Pin	2	
G31	HF924E8001	Feed shaft bushing(R)	2	
G32	HF957I8001	Feed connecting arm(L)	1	
G33	HA719B0707	Rubber cap	1	
G34	H415050160	Bolt	1	M5×16
G35	HF958I8001	Pin(L)	1	
G36	HF961I8001	Oil wick	1	
G37	H401030080	Bolt	2	
G38	HF954I8001	Washer	2	
G39	HF952I8001	Feed link	2	
G40	HF959I8001	Shaft	1	
G41	HF965G8001	Adjusting shaft collar	2	
G42	H415040120	Bolt	2	M4×12
G43	HF927E8001	Bushing(L)	1	

## G.FEEDING AND FEED LIFTING & ROTATING HOOK SHAFT MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
G44	HF924E8001	Bushing(R)	1	
G45	H428060100	Bolt	2	M6×10
G46	H429060100	Bolt	2	M6×10
G47	HF975J8001	Coupling claw(L)	1	
G48	HF978J8001	Toothed wreath	1	
G49	HF977J8001	Coupling claw(R)	1	
G50	GB/T3452.1	O ring	1	11.8×1.8
G51	HF988I8001	Oil seal	1	
G52	HF987I8001	Bushing(L)	1	
G53	HF992I8001	Bolt	1	
G54	H34412C110	Plunger spring	1	
G55	HF966I8001	Plunger	1	
G56	HA110E0672	Oil feeding pipe	1	
G57	HF971I7101	Feed rod	1	
G58	HF905I8001	Lower shaft	1	
G59	HF963I8001	Feed cam	1	
G60	H428060050	Bolt	2	M6×5
G61	HF919I7101	Lower feed connecting rod assy	1	
G62	HF926I8001	Pin	1	
G63	H007013050	E-type retaining ring 5	2	
G64	HF961H8001	Slide block	2	
G65	HF925I8001	Back cylinder connection	1	
G66	HF960H8001	Pin	1	
G67	HF917I8001	Lower feed cam	1	
G68	H428060080	Bolt	2	M6×8
G69	HF990I8001	Bushing(R)	1	
G70	HF956G8001	Oil joint	1	
G71	HF991I8001	Sealing ring	1	
G72	HF915I8001	Disk	1	
G73	HF916I8001	Stunk screw	2	
G74	H007009220	Retainer ring	1	
G75	HF907I8001	Toothed belt	1	
G76	HF908I8001	Belt pulley(D)	1	
G77	HF911I8001	Piston	2	
G78	HF912I8001	Presser spring	2	
G79	HF910I8001	Body	1	
G80	H431060120	Adjusting screw	2	M6×12
G81	H431080120	Bolt	1	M8×12
G82	H430080120	Bolt	1	M8×12
G83	H003002060	Nut	2	M6

# H.HOOK SADDLE MECHANISM



From the library of: Diamond Needle Corp

# H.HOOK SADDLE MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
H01	H402025060	Screw	2	M2.5×6
H02	HF910J8001	Thread holding spring	1	
H03	HF908J8001	Fixed knife	1	
H04	H402025060	Screw	2	M2.5×6
H05	HF905J8001	Fixed knife support bracket	1	
H06	H415050250	Bolt	2	M5×25
H07	H005005050	Washer	2	
H08	HF989J8001	Washer	5	
H09	HF991J8001	Oil drip ring	1	
H10	HF997J8001	Bolt	2	
H11	HF995J8001	Shaft	1	
H12	HF92AJ8001	Oil wick	1	
H13	H424050200	Bolt	1	M5×20
H14	HF981J8001	Hook shaft	1	
H15	HF992J8001	Washer	1	
H16	HF984J8001	Ball bearing	3	
H17	HF983J8001	Gear	1	
H18	H431050050	Bolt	2	M5×5
H19	HF946J8001	Pin(L)	1	
H20	HF964J8001	Oil seal	2	
H21	HF966J8001	Bolt	3	
H22	HF965J8001	Screw	3	
H23	HF962J8001	Lower shaft holder	1	
H24	GB/T3452. 1	O ring	1	38. 7×1. 8
H25	HF963J8001	Ball bearing	2	
H26	H403030080	Screw	4	
H27	HF969J8001	Lower shaft gear	1	
H28	HF970J8001	Washer	1	
H29	HF967J8001	Driving shaft	1	
H30	HF973J8001	Collor	1	
H31	H415060200	Bolt	1	M6×20
H32	HF971J8001	Shaft	1	
H33	HF956G8001	Oil feeding pipe(S)	1	
H34	HF949J8001	Tube	1	
H35	HF945J8001	Horizontal hook base	1	
H36	H005013060	Wave washer	1	
H37	HF990J8001	Lubrication shaft	1	
H38	H007007260	Retainer ring	1	
H39	HF956J8001	Bushing	1	
H40	HF947J8001	Oil feeding pipe(M)	2	
H41	H402030040	Bolt	1	M3×4
H42	H415040080	Bolt(short)	6	M4×8
H43	H415040120	Bolt(long)	3	M4×12

# H.HOOK SADDLE MECHANISM


Fig. No.	Part No.	Description	Pcs.	Remarks
H44	H415030060	Bolt	2	M3×6
H45	H005004030	Washer	2	
H46	HF914J8001	Driving knife	1	
H47	HF913J8001	Driving knife shaft	1	
H48	HF90GJ8001	Opener	1	
H49	HF90HJ8001	Screw	2	
H50	HF90AJ8001	Oil wick	1	
H51	HF999J8001	Adjusting pin	1	
H52	HF90BJ8001	Adjusting guide rail	1	
H53	HF90DJ8001	Opener shaft	1	
H54	HF996J8001	Bearing	1	
H55	HF90FJ8001	Opener setting bracket	1	
H56	HF90EJ8001	Pin	1	
H57	HF917J8001	Bushing	1	
H58	H007013040	E-type retaining ring	1	
H59	HF950J8001	Oil wick	1	
H60	HF919J8001	Bushing	1	
H61	HF91CJ7101	Gear base assy	1	
H62	H431050060	Bolt	2	M5×6
H63	H005013050	Belleville spring washer	1	
H64	HF91IJ8001	Nut	1	
H65	HF91JJ8001	Hexagonal nut	1	
H66	HF91AJ8001	Gear	1	
H67	H431050050	Bolt	2	M5×5
H68	HF954J8001	Sheet packing	1	
H69	HF953J8001	Cover	1	
H70	HF958J8001	Oil seal	1	
H71	HF942J8001	Thread trimmer cam	1	
H72	H415040080	Bolt	3	M4×8
H73	HF985J7101	Horizontal hook	1	
H74	HF971B8001	Bobbin	1	
H75	HF931J8001	Driving knife arm(S)	1	
H76	H415040120	Bolt	1	M4×12
H77	HF934J8001	Pin	2	
H78	H007013040	E-type retaining ring	2	
H79	HF933J8001	Driving knife connection	1	
H80	HF928J8001	Soloid setting bracket	1	
H81	H415040080	Bolt	1	M4×8
H82	HF937J8001	Driving knife arm(L)	1	
H83	HF940J8001	Roller	1	
H84	H007013030	E-type retaining ring	1	
H85	H415040120	Bolt	1	M4×12
H86	HF920J8001	Collor	2	



# H.HOOK SADDLE MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
H87	H428050050	Bolt	2	M5×5
H88	HF922J8001	Solinoïd setting plate	1	
H89	H005018060	Washer	1	
H90	H415060120	Bolt	1	M6×12
H91	H415040100	Bolt	2	M4×10
H92	HF939J8001	Pin	1	
H93	HF925J8001	Thread trimmer solinoïd	1	
H94	H415060220	Bolt	2	M6×22
H95	HF92BJ8001	Spacer	1	
H96	HF92CJ8001	Eccentric collar	1	

# I.OIL LUBRICATION MECHANISM



From the library of: Diamond Needle Corp


# I.OIL LUBRICATION MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
101	H401050080	Bolt	1	M5×8
102	H005018050	Spacer	1	
103	HF909K8001	Oil wick support	1	
104	HF917K8001	Oil joint	1	
105	HF908K8001	Tube guide	1	
106	HF906K8001	Felt	1	
107	HF907K8001	Oil wick	1	
108	HF905K8001	Oil tube	1	
109	HF918K8001	Oil tube	1	
110	HF914K8001	Felt	1	
111	HF915K8001	Oil wick	1	
112	HF913K8001	Oil tube	1	
113	HF948K8001	Pipe	1	
114	HF950K8001	Oil tube	1	
115	HF949K8001	Hose	1	
116	HF936K8001	Oil pipe	1	
117	HF959K8001	Oil window	1	
118	HF957K8001	Oil pipe	1	
119	HF919K8001	Spring	1	
120	HF962K8001	Tape	1	
121	H802040160	Screw	2	4×16
122	HF960K8001	Guard plate	1	
123	HF956K7101	Valve	1	
124	HF955K8001	Main oil pipe	1	
125	HF920K8001	Oil joint	2	
126	HF921K8001	Oil pipe	1	
127	HF922K8001	Oil pipe	1	
128	HF938K8001	Oil joint	1	
129	HF939K8001	Oil pipe	1	
130	HF951K8001	Oil pipe setting plate	1	
131	H32311D606	Oil wick setting plate	2	M4×10
132	H415040100	Screw	2	
133	H005001040	Washer	2	
134	H3210K0671	T-joint	2	
135	HF942K8001	Hose	1	
136	HF947K8001	Hose	1	
137	HF946K8001	Oil wick	1	
138	HF943K8001	Oil pipe plate assy	1	
139	HF92FJ7101	Wire assy	1	
140	HF927K7101	Oil hose assy	1	
141	HF963K7101	Filter pot assy	2	
142	HF929K8001	Oil pipe	1	
143	HF930K8001	Support spring	1	

# I.OIL LUBRICATION MECHANISM

Fig. No.	Part No.	Description	Pcs.	Remarks
I44	HF923K8001	Oil pipe	1	
I45	H3210K0671	T-joint	1	
I46	HF924K8001	Oil pipe	1	
I47	HF925K8001	Oil pipe	1	
I48	HF926K8001	Support spring	2	
I49	HF932K8001	Felt part	1	
I50	HA300I2040	Cable tie	1	
I51	HF934K8001	Oil pipe	1	
I52	HF937K8001	Oil pipe	1	

# J.ACCESSORIES




From the library of: Diamond Needle Corp

# J.ACCESSORIES

Fig. No.	Part No.	Description	Pcs.	Remarks
J01	HA307J0671	Hinge support	2	
J02	HF914L8001	Hinge	2	
J03	H411060100	Screw	4	
J04	HF905L8001	Head cushion	2	
J05	HF971B8001	Bobbin	3	
J06	HA100J2170	Oil tank	1	
J07	H200400069	Oiler	1	
J08	HF974G8001	Neddle	4	
J09	HF913L8001	Detector setting plate	1	
J10	HA200J2030	Cotton stand assy	1	
J11	HA100J2180	Cover	1	
J12	HF904L8001	Oil plate	1	
J13	GB/T349	Nail	8	1.6×25
J14	HB00001025	Hexagonal wrench (2.5)	1	
J15	HB00001015	Hexagonal wrench (1.5)	1	
J16	HA300J2070	Screw driver(L)	1	
J17	HA300J2200	Screw driver(M)	1	
J18	HA300J2210	Screw driver(S)	1	
J19	HF908L8001	Belt guard(R)	1	
J20	HF915L8001	Rubber washer	1	
J21	H401060120	Bolt	1	
J22	HF907L8001	Belt guard(L)	1	
J23	HF911L8001	Bolt	1	
J24	H005001060	Washer	1	
J25	H7316E8001	Nut	1	
J26	H125080600	Screw	2	
J27	HF925L8001	Bow	1	
J28	H005001080	Spacer	2	
J29	H003002080	Nut	2	
J30	HF928L8001	Coupling	1	
J31	HF929L8001	Nylon washer	1	
J32	HF930L8001	Cushion	1	
J33	HF933L8001	Washer	1	
J34	HF931L8001	Cylinder	1	
J35	HF932L8001	Coupling	1	

# K.PNEUMATIC CONTROL UNIT



From the library of: Diamond Needle Corp

## K.PNEUMATIC CONTROL UNIT

Fig. No.	Part No.	Description	Pcs.	Remarks
K01	HF930M8001	Connecting box base	1	
K02	HF924M8001	PCB board	1	
K03	HF932M8001	Connecting box screw	2	
K04	H409040160	Screw	2	
K05	H415030120	Screw	2	
K06	HF931M8001	Connecting box cover	1	
K07	HF922E8001	Rheostat	1	
K08	HF926M7101	Rheostat wire assy	1	connect to CN3 of PCB board
K09	HF922C8001	Tension release solenoid	1	
K10	HF921J8001	Wire joint	6	connect to MT,ML,FK of PCB board
K11	HF925J8001	Trimming solenoid	1	
K12	HF92HJ8001	Wire joint	4	
K13	HF92EJ8001	H type wire joint	1	
K14	HF934M8001	Button set frame	1	
K15	HF933M8001	Button set board	1	
K16	HF937M8001	Button with light	3	
K17	HF937M8002	Button without light	2	
K18	HF928M7101	Button wire assy	1	connect to CN6 of PCB board
K19	H415040060	Screw	4	
K21	HF927M7101	Solenoid valve wire assy	1	connect to CN5 of PCB board
K22	HF929M7101	Count to alarm wire assy	1	connect to CN2 of PCB board
K23	HF925M7101	Control box wire assy	1	connect to CN1 of PCB board
K24	HF938M7101	Reset button assy	1	connect to CN4 of PCB board
K25	HF940M8001	Plotting	5	set inside the button
K26	HZ15040120	Screw	4	
K27	HF914M8002	Windpipe	1	φ 4(same letter matches)
K28	HF915M8001	Windpipe	1	φ 6
K30	HF917M8001	Solenoid valve set board	1	
K31	HF941M8001	Solenoid valve cover	1	
K32	HF907M8001	Solenoid valve	5	3V1-06-DC24V
K33	HF932L8001	Windpipe joint	1	
K34	H4921N8001	Windpipe joint	1	EPL6-01 φ 6-1/8"
K35	HF932L8001	Windpipe joint	4	EPL4-01 φ 4-1/8"
K36	HF913M8001	Throttle	1	ESL4-01 φ 4-1/8"
K37	HD492M8001	Plug	1	PT1/8"
K38	H4919N8001	Windpipe joint	1	EPL6-02 φ 6-1/4"
K39	H4914N8001	Windpipe joint	1	EPL8-02 φ 8-1/4"
K40	HF937E8001	Windpipe joint	3	EPL4-M5(AIRTAC)
K41	H4915N8001	Reducing valve	1	AFR2000
K42	HF931L8001	Cylinder	1	MSAL-U-25×56 (AIRTAC)
K43	H003002040	Nut	2	
K44	H005001040	Washer	4	
K45	H801050200	Screw	2	



# K.PNEUMATIC CONTROL UNIT

Fig. No.	Part No.	Description	Pcs.	Remarks
K46	H409040100	Screw	2	

From the library of: Diamond Needle Corp





**SHANGHAI HUIGONG NO.3 SEWING MACHINE FACTORY**

**ADD: 1418, Yishan Road, Shanghai, China**

**Zip Code: 201103**

**Overseas Business: TEL: 86-21-64853303 FAX: 86-21-64854304**

**E-mail: [highlead@online.sh.cn](mailto:highlead@online.sh.cn) <http://www.highlead.com.cn>**

The description covered in this manual is subject to change for improvement of the commodity without notice

2006.4. Printed