




Model **1344T29  
& T29A**

Revision 4.4 Updated June 22, 2016

# Technical Manual & Parts Lists



From the library of: Diamond Needle Corp

**Atlanta Attachment Company**

362 Industrial Park Drive

Lawrenceville, GA 30046

770-963-7369 • [www.atlatt.com](http://www.atlatt.com)



# ATLANTA ATTACHMENT COMPANY, INC.

## Confidential and Proprietary Information

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.

All materials contained herein are additionally protected by United States Copyright law and may not be used, disclosed, reproduced, distributed, published or sold without the express written consent of Atlanta Attachment Company, which consent may be withheld in Atlanta Attachment Company's sole discretion. You may not alter or remove any copyright, trademark or other notice from copies of these materials.

### **IMPORTANT**

**It is important to read and understand the information contained within this manual before attempting to operate the machine. Atlanta Attachment Co., Inc. shall not be held liable for damage resulting from misuse of the information presented within, and reserves the right to change the information contained within, without prior notification.**

# Contents

Important Safety Instruction .....	1
Liability .....	2
Safety Equipment on the Machines .....	3
Protective Eyewear .....	4
Important Notices.....	5
Maintenance .....	7
Repair .....	8
A Word to the End User.....	9
Safety Precautions.....	9
Parameter Settings 11344T29 Efka Motor .....	10
Parameters Settings 11344T29A Efka Motor .....	11
Assembly Drawings & Parts Lists .....	12
11344T29A Main Assembly.....	15
11344T29 Panel Binder Walking Foot .....	17
1344075 Generic Assembly, 1344T29'S.....	19
1335950 Undwinder Assembly.....	21
33008708 Ball Bearing Disc Assembly .....	22
1339-1500A Pneumatic Panel Assembly.....	23
1344027 Sewing Head Assembly .....	24
1344029 Linear Guide Assembly .....	25
4059-FP301D Foot Pedal Assembly.....	26
1344T29A-PD Pneumatic Diagram .....	27
1344T29-WD Wiring Diagram.....	28
1344T29A-WD Wiring Diagram.....	29

## Important Safety Instruction



This part of the Instruction Material is provided for the safe use of your equipment. It contains important information to help work safely with the unit and describes the dangers inherent in machinery. Some of these dangers are obvious, while others are less evident.

### Mandatory Information

All persons operating and/or working on the 1344T29A&B Panel Binder should read and understand all parts of the Safety Instructions. This applies, in particular, for persons who only operate and/or work on the unit occasionally (e.g. for maintenance and repair). Persons who have difficulty reading must receive particularly thorough instruction.

### Scope of the Instruction Material

- The Instruction Material comprises:
- Safety information
- Operator Instructions
- Electrical and Pneumatic diagrams

And may also include;

- A list of recommended spare parts
- Instruction Manual(s) for components made by other manufacturers
- The layout and installation diagram containing information for installation

### Intended Use

Our machines are designed and built in line with the state of the art and the accepted safety rules. However, all machines may endanger the life and limb of their users and/or third parties and be damaged or cause damage to other property, particularly if they are operated incorrectly or used for purposes other than those specified in the Instruction Manual.

### Exclusion of Misuse



Non-conforming uses include, for example, using the equipment for something other than it was designed for, as well as operation without duly installed safety equipment. The risk rests exclusively with the end user.

Conforming use of the machine includes compliance with the technical data, information and regulations in all parts of the complete Instruction Material, as well as compliance with the maintenance regulations. All local safety and accident prevention regulations must also be observed.

## Liability

The machine should only be operated when in perfect working order, with due regard for safety and the potential dangers, as well as in accordance with the Instruction Material. Faults and malfunctions capable of impairing safety should be remedied immediately. We cannot accept any liability for personal injury or property damage due to operator errors or non-compliance with the safety instructions contained in this booklet. The risk rests exclusively with the end user.

The Instruction Material should always be kept near the machine so that it is accessible to all concerned.

The local, general, statutory and other binding regulations on accident prevention and environmental protection must also be observed in addition to the Instruction Material. The operating staff must be instructed accordingly. This obligation also includes the handling of dangerous substances and provision/use of personal protective equipment.

The Instruction Material should be supplemented by instructions, including supervisory and notification duties with due regard for special operational features, such as the organization of work, work sequences, the personnel deployed, etc.

The personnel's awareness of the dangers and compliance with the safety regulations should be checked at irregular intervals.

## Choice and Qualification of Personnel

Ensure that work on the machine is only carried out by reliable persons who have been appropriately trained for such work - either within the company, by our field staff or at our office - and who have not only been duly appointed and authorized, but are also fully familiar with the local regulations. Work on the machine should only be carried out by skilled personnel, under the management and supervision of a duly qualified engineer.

This not only applies when the machine is used for production, but also for special work associated with its operation (start-up and maintenance), especially when it concerns work on the hydraulic or electrical systems, as well as on the software/serial bus system.

## Training

Everyone working on or with the machine should be duly trained and informed with regard to correct use of the safety equipment, the foreseeable dangers which may arise during operation of the machine and the safety precautions to be taken. In addition, the personnel should be instructed to check all safety mechanisms at regular intervals.

## Responsibilities

Clearly define exactly who is responsible for operating, setting-up, servicing and repairing the machine. Define the responsibilities of the machine operator and authorize him to refuse any instructions by third parties if they run contrary to the machine's safety. This applies in particular for the operators of machines linked to other equipment. Persons receiving training of any kind may only work on or with the machine under the constant supervision of an experienced operator. Note the minimum age limits permitted by law.

## A Word to the Operator

The greatest danger inherent in our machines: is that of fingers, hands or loose clothing being drawn into a machine by live, coasting or rotating tools or assemblies or of being cut by sharp tools or burned by hot elements.

### **ALWAYS BE CONSCIOUS OF THESE DANGERS!**

## Safety Equipment on the Machines



All machines are delivered with safety equipment, which shall not be removed or bypassed during operation.

The correct functioning of safety equipment on machines and systems should be checked every day and before every new shift starts, after maintenance and repair work, when starting up for the first time and when restarting (e.g. after prolonged shutdowns).

If safety equipment has to be dismantled for setting-up, maintenance or repair work, such safety equipment shall be replaced and checked immediately upon completing the maintenance or repair work. All protective mechanisms shall be fitted and fully operational whenever the machine is at a standstill or if it has been shut down for a longer period of time.

## Damage

If any changes capable of impairing safety are observed in the machine or its mode of operation, such as malfunctions, faults or changes in the machine or tools, appropriate steps must be taken immediately, the machine switched off and a proper lockout tagout procedure followed. The machine should be examined for obvious damage and defects at least once per shift. Damage found shall be immediately remedied by a duly authorized person before resuming operation of machine.

The machine should only be operated when in perfect working order and when all protective mechanisms and safety equipment, such as detachable protective mechanisms, emergency STOP systems, etc. are in place and operational.

## Faults or Errors

The machine must be switched off and all moving or rotating parts allowed to come to a standstill and secured against accidental restart before starting to remedy any faults or errors.


## Signs on the Machine

Safety and danger signs on the machine should be observed and checked at regular intervals to ensure that they are complete and undamaged. They should be clearly visible and legible at all times.

### Clothing, Jewelry, Protective Equipment

Long loose hair, loose-fitting clothes, gloves and jewelry, including rings, should be avoided in order to avoid injuries due to being caught, drawn in and wound up inside the machine.

## Protective Eyewear



Protective eyewear that has been tested by the local authorities should be worn whenever there is a possibility of loose or flying objects or particles such as when cleaning the machine with compressed air.

## Tools

Always count the number of tools in your possession before starting work on the machine. This will allow you to check that no tools have been left behind inside the machine. Never leave a tool in the machine while working.

## Oils, Lubricants, Chemicals

Note the applicable safety regulations for the product used.

## No Smoking, Fire, Explosion Hazard

Smoking and open flame (e.g. welding work) should be prohibited in the production area due to the risk of fire and explosions.

## Workplace

A clear working area without any obstructions whatsoever is essential for safe operation of the machine. The floor should be level and clean, without any waste.

The workplace should be well lit, either by the general lighting or by local lights.

## Emergency STOP

The emergency STOP buttons bring all machine movements to a standstill. Make sure you know exactly where they are located and how they work. Try them out. Always ensure easy access to the nearest emergency STOP button while working on the machine.

## First Aid

1. Keep calm even when injured.
2. Clear the operator from the danger zone. The decision of what to do and whether to seek additional assistance rests entirely with you, particularly if someone has been trapped.
3. Give First Aid. Special courses are offered by such organizations as the employers' liability insurance association. Your colleagues should be able to rely on you and vice versa.
4. Call an ambulance. Do you know the telephone numbers for the ambulance service, police and fire service?



## Important Notices

### Reporting and Fighting Fires

Read the instructions posted in the factory with regard to reporting fires and the emergency exits. Make sure you know exactly where the fire extinguishers and sprinkler systems are located and how they are operated. Pass on the corresponding information to the firemen when they arrive. Ensure there are enough signs to avoid fire hazards.

The following fire extinguishers may be used:

- Dry powder extinguishers, ABC fire-extinguishing powder.
- Carbon dioxide fire extinguishers to DIN 14461 for electronic components. Great care must be exercised when using carbon dioxide fire extinguishers in confined, badly ventilated rooms (see DIN 14406 and 14270).

Isolate the machine from the power supply if a fire breaks out. Do not use water on burning electrical parts until it is absolutely certain that they have been completely disconnected from the power supply. Burning oils, lubricants, plastics and coatings on the machine can give off gases and vapors that may be harmful to your health.

A qualified person should be consulted to repair the damage after a fire.

### Electrical Power Supply



Before undertaking any maintenance or repair work on the machine, switch off the electrical power to the machine at the main source and secure it with a padlock so that it cannot be switched on again without authorization.

In practice, this may mean that the technician, electrician and operator all attach their own padlock to the master switch simultaneously so that they can carry out their work safely. Locking extension plates should be available for multiple locks if required. The primary purpose for a lockout/tagout procedure is to protect workers from injury caused by unexpected energizing or start-up of equipment.

Energy sources (electrical/pneumatic/hydraulic, etc.) for the equipment shall be turned off or disconnected and the switches locked or labeled with a warning tag. It is the responsibility of the employer to establish control procedures. Follow lockout/tagout procedures before, setup and/or any service or maintenance work is performed, including lubrication, cleaning or clearance of jams.

**Caution: The machine is still not completely de-energized even when the master switch is off.**

- Electricity - The machine is always isolated from the electrical power supply whenever the master switch has been switched off. However, this does not apply for the power supply in the control cabinet, nor for equipment that does not draw its power via the master switch.
- Pneumatic / hydraulic energy - Almost all our machines carry compressed air. In addition to switching off the master switch, the air supply must also be disconnected and the machine checked to ensure it is depressurized before starting any work on the machine; otherwise the machine may execute uncontrolled movements.

- Kinetic energy - Note that some motors or spindles, for example, may continue to run or coast run on after being switched off.
- Potential energy - Individual assemblies may need to be secured if necessary for repair work.

## Delivery of the Machine/Packaging

Note any markings on the packaging, such as weights, lifting points and special information. Avoid temperature fluctuations. Condensation may damage the machine.

## Transport Damage

The packaging and machine must immediately be examined for signs of damage in transit. Such damage must be reported to the shipper/transporter within the applicable time limits. Contact Atlanta Attachment Company and/or your transport insurer immediately, if signs of damage are visible. Never operate a damaged machine.

## Interim Storage

If the machine has to be stored temporarily, it must be oiled or greased and stored in a dry place where it is protected from the weather in order to avoid damage. A corrosion-inhibiting coating should be applied if the machine has to be stored for a longer period of time and additional precautions taken to avoid corrosion.

## Transporting the Machine

Disconnect the machine from all external connections and secure any loose assemblies or parts. Never step under a suspended load. When transporting the machine or assemblies in a crate, ensure that the ropes or arms of a forklift truck are positioned as close to the edge of the crate as possible. The center of gravity is not necessarily in the middle of the crate. Note the accident prevention regulations, safety instructions and local regulations governing transport of the machine and its assemblies.

Only use suitable transport vehicles, hoisting gear and load suspension devices that are in perfect working order and of adequate carrying capacity. Transport should only be entrusted to duly qualified personnel.

Never allow the straps to rest against the machine enclosure and never push or pull sensitive parts of the machine. Ensure that the load is always properly secured. Before or immediately after loading the machine, secure it properly and affix corresponding warnings.

All transport guards and lifting devices must be removed before the machine is started up again. Any parts that are to be removed for transport must be carefully refitted and secured before the machine is started up again.

## Workplace Environment

Our machines are designed for use in enclosed rooms: Permissible ambient temperature approx. 5 - 40 °C (40 - 104 °F). Malfunctions of the control systems and uncontrolled machine movements may occur at temperatures outside this range.

Protect against climatic influences, such as electrostatic charges, lightning strikes, hail, storm damage, high humidity, salinity of the air in coastal regions.

Protect against influences from the surroundings: no structure-borne vibrations, no grinding dust, or chemical vapors.

Protect against unauthorized access.

Ensure that the machine and accessories are set up in a stable position.

Ensure easy access for operation and maintenance (Instruction Manual and layout diagram); also verify that the floor is strong enough to carry the weight of the machine.

## Local Regulations

Particular attention must be paid to local and statutory regulations, etc. when installing machines and the plant (e.g. with regard to the specified escape routes). Note the safety zones in relation to adjacent machines.

# Maintenance

## General Safety Instructions

The machine shall be switched off, come to a standstill and be secured so that it cannot be switched on again inadvertently before starting any maintenance work whatsoever. Use proper lockout/tagout procedures to secure the machine against inadvertent startup.

Remove any oil, grease, dirt and waste from the machine, particularly from the connections and screws, when starting the maintenance and/or repair work. Do not use any corrosive-cleaning agents. Use lint-free rags.

Retighten all screw connections that have to be loosened for the maintenance and repair work. Any safety mechanisms that have to be dismantled for setting-up, maintenance or repair purposes must be refitted and checked immediately after completing the work.

## Maintenance, Care, Adjustment

The activities and intervals specified in the Instruction Manual for carrying out adjustments, maintenance and inspections must be observed and parts replaced as specified.

All hydraulic and pneumatic lines should be examined for leaks, loose connections, rubbing and damage whenever the machine is serviced. Any defects found must be remedied immediately.

## Waste, Disassembly, Disposal

Waste products should be cleared from the machine as soon as possible as not to create a fire hazard. Ensure that fuels and operating lubricants, as well as replacement parts are disposed of in a safe and ecologically acceptable manner. Note the local regulations on pollution control.

When scrapping (disassembling) the machine and its assemblies, ensure that these materials are disposed of safely. Either commission a specialist company familiar with the local regulations or note the local regulations when disposing of these materials yourself. Materials should be sorted properly.

# Repair

## Replacement Parts

We cannot accept any liability whatsoever for damage due to the use of parts made by other manufacturers or due to unqualified repair or modification of the machine.

## Repair, Electrical

The power supply must be switched off (master switch off) and secured so that it cannot be switched on again inadvertently before starting any work on live parts.

Those parts of the machine and plant on which inspection, maintenance or repair work is to be carried out must be isolated from the power supply, if specified. The isolated parts must first be checked to determine that they are truly de-energized before being grounded and short-circuited. Adjacent live parts must also be isolated.

The protective measures implemented (e.g. grounding resistance) must be tested before restarting the machine after all assembly or repair work on electric parts.

Signal generators (limit switches) and other electrical parts on the safety mechanisms must not be removed or bypassed. Only use original fuses or circuit overloads with the specified current rating. The machine must be switched off immediately if a fault develops in the electrical power supply.

The electrical equipment of our machines must be checked at regular intervals and any defects found must be remedied immediately.

If it is necessary to carry out work on live parts, a second person should be on hand to operate the emergency OFF switch or master switch with voltage release in the event of an emergency. The working area should be cordoned off and marked by a warning sign. Only use electrically insulated tools.

## Ventilation/Hazardous Gases

It is the end users responsibility to ensure adequate ventilation is provided to exhaust any and all noxious or hazardous gases that may be present in the working environment.

## Hydraulic and Pneumatic Systems

Work on hydraulic or pneumatic equipment shall only be carried out by persons with training, knowledge and experience of hydraulic systems. Pressure lines shall be depressurized before starting any repair work.

## General Liability

Liability for machine damage and personal injury is extinguished completely if any unauthorized conversions or modifications are undertaken. The machine must not be modified, enlarged or converted in any way capable of affecting safety without the manufacturer's prior approval.

## Starting Machine Movements

Read the Instruction Manual carefully to establish which keys and functions start machine movements.

## A Word to the End User

The end user has sole responsibility to enforce the use of safety procedures and guards on the machine. Any other safety devices or procedures due to local regulations should be should be retrofitted in accordance to these regulations and/or the EC Directive on the safety of machines.

Operator's position must always be readily accessible. Escape routes must always be kept clear and safety areas should be identified.

## Safety Precautions

Safety should be a constant concern for everyone. Always be careful when working with this equipment. While normal safety precautions were taken in the design and manufacture of this equipment, there are some potential safety hazards.

**Everyone involved with the operation and maintenance of this equipment should read and follow the instructions in this manual.**

**Operate the equipment only as stated in this manual. Incorrect use could cause damage to the equipment or personal injury.**

**It is the owner's responsibility to make certain that the operator reads and understands this manual before operating this equipment. It is also the owner's responsibility to make certain that the operator is a qualified and physically able individual, properly trained in the operation of this equipment.**

Specific safety warning decals are located on the equipment near the immediate areas of potential hazards. These decals should not be removed or obliterated. Replace them if they become non-readable.

- ALWAYS keep safety shields and covers in place, except for servicing.
- ALWAYS operate equipment in daylight or with adequate working lights.
- Follow daily and weekly checklists, making sure hoses are tightly secured and bolts are tightened.
- ALWAYS watch and avoid holes or deep depressions.
- ALWAYS wear adequate eye protection when servicing the hydraulic system and battery.
- NEVER operate a poorly maintained machine.
- NEVER allow persons to operate this machine without proper instruction.
- NEVER put hands or feet under any part of the machine while it is running.
- NEVER attempt to make any adjustments or repairs to the machine while running. Repairs or maintenance should be performed by trained personnel only.
- NEVER work under the machine unless it is safely supported with stands, blocks or a hoist and blocks.
- NEVER touch hot parts of machine.

# Parameter Settings 11344T29 Efka Motor

PARAMETER	RANGE	11344T29	PARAMETER DESCRIPTION
Do this first	*****		Perform a master reset before programming, see below
290	0-26	0	Mode of operation. <b>MUST SET THIS PARAMETER FIRST!</b>
026		0	Treadle Pedal Config.
111	200-9900 rpm	2500	Maximum speed when "129" is 0, 1, or 2.
153	0-50	10	Braking power at standstill
161	0-1	1	Motor rotation, 1=CCW
240	0-66	7	Machine blocked
270	0-5	1	External handwheel sensor configuration. (Position 2)
271	0-255	180	Ref angle for Position 1 (Trim) from Position 2
272	150-1000	900	Drive ratio between motor pulley and handwheel pulley. If handwheel pulley is smaller than motor pulley, increase this value to slow down sewing head until measured speed matches speed set with parameter 111. (For Yamato and Pegasus, setting should be 100; for Rimoldi, setting should be 124)
436	x	0	Use code "5913". This disables an input that was causing box to reset itself.
401	0	0-1	Change from 0 to 1 to save parameters
<b>Front panel LED's:</b>			
LED 1:	Off		<b>Programming Instructions:</b> 1. Power on holding down the "P" button till "codE" is displayed. 2. Press ">>" once and enter the number "5913" 3. Press "E" once and "2.0.0." is displayed this is a parameter 4. Press ">>" to proceed to the parameter to be changed and press "E". 5. The value now shows in the screen, adjust to desired value. 6. Press "E" to enter value and continue with parameter setting. 7. Repeat for other parameters, press "P" once when complete. <b>8. Run sewing head to save parameters before powering down</b>
LED 2:	Off		
LED 3:	Off		
LED 4:	Off		
LED 5:	Off		
LED 6:	Off.		
LED 7:	ON, Stop at needle down.		
LED 8:	OFF		
<b>To Perform Master Reset of Parameters:</b>			
			1. Power on holding down the "P" button till "codE" is displayed.
			2. Press ">>" once and enter the number "5913"
			3. Press "E" twice and "093" is displayed.
			4. Press "+" once, "094" is displayed.
			5. Press "P" to exit programming mode with all default values.

# Parameters Settings 11344T29A Efka Motor

PARAMETER	RANGE	11344T29A AB321	PARAMETER DESCRIPTION
Do this first	*****		Perform a master reset before programming, see below
290	0-26	05	Mode of operation. <b>MUST SET THIS PARAMETER FIRST!</b>
026		0	treadle set-up for FP301
111	200-9900 rpm	2500	Maximum speed when "129" is 0, 1, or 2. (SET 117 THE SAME)
117	400-9900	2500	High lift speed (WHILE BINDER IS SHIFTED) SET SAME AS 111
137	0-1	1	High lift on (USED TO SHIFT BINDER)
153	0-50	35	Braking power at standstill
161	0-1	1	Motor rotation, 1=CCW
204	1-100	100	Foot lift sol power 100%
219	1-55	35	Braking power at stop
240	0-66	14	High lift input
242	0-66	7	Machine blocked
270	0-5	1	External handwheel sensor configuration. (Position 2)
271	0-255	246	Ref angle for Position 1 (Trim) from Position 2
272	150-1000	0870	Drive ratio between motor pulley and handwheel pulley. If handwheel pulley is smaller than motor pulley, increase this value to slow down sewing head until measured speed matches speed set with parameter 111. (For Yamato and Pegasus, setting should be 100; for Rimoldi, setting should be 124)
340		50	in1 Threshold (use 5913 access code)
436		0	Must use code "5913". This disables an input that was causing box to reset itself.
401		0-1	Change from 0 to 1 to save settings
<b>Front panel LED's:</b>			
LED 1:	Off		<b>Programming Instructions:</b>
LED 2:	Off		1. Power on holding down the "P" button till "codE" is displayed.
LED 3:	Off		2. Press ">>" once and enter the number "5913"
LED 4:	Off		3. Press "E" once and "2.0.0." is displayed this is a parameter
LED 5:	Off		4. Press ">>" to proceed to the parameter to be changed and press "E".
LED 6:	Off.		5. The value now shows in the screen, adjust to desired value.
LED 7:	ON, Stop at needle down.		6. Press "E" to enter value and continue with parameter setting.
LED 8:	OFF		7. Repeat for other parameters, press "P" once when complete.
			<b>8. Run sewing head to save parameters before powering down</b>
			<b>To Perform Master Reset of Parameters:</b>
			1. Power on holding down the "P" button till "codE" is displayed.
			2. Press ">>" once and enter the number "5913"
			3. Press "E" twice and "093" is displayed.
			4. Press "+" once, "094" is displayed.
			5. Press "P" to exit programming mode with all default values.

## Assembly Drawings & Parts Lists


The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.



**One-Stop Shopping**  
For Expendable Replacement Parts for AAC & Other Bedding Equipment Suppliers  
Toll Free: **1-866-885-5100**  
[www.atlantapartsdepot.com](http://www.atlantapartsdepot.com) • [sales@atlantapartsdepot.com](mailto:sales@atlantapartsdepot.com)








From the library of: Diamond Needle Corp

# 11344T29A Main Assembly

AAC Drawing Number 9001330 Rev 12

NO.	QTY	PART#	DESCRIPTION
1	1	0211-701FA	CABLE, I/O, EFKA, 6 FT
2	1	1278-6718A	BRKT,OPTO TOUCH SWITCH
3	1	1335950	UNWINDER ASSY, UNDER TBL
4	1	1339-1500A	PNEUMATIC PANEL ASSY
5	AR	1344T29A-PD	DIAGRAM, PNEUMATIC
6	AR	1344T29A-WD	DIAGRAM, WIRING
7	1	1344068	SHIFTING BINDER MOUNT
8	1	1344075	GENERIC ASSY, 1344T29'S
9	1	FFOTBVN6	SWITCH,OPTO-TOUCH
10	10	SN62X59	NEEDLE,SIZE 24/180



# 11344T29 Panel Binder Walking Foot

AAC Drawing Number 9001152 Rev 8

NO	QTY	PART #	DESCRIPTION
1	AR	221-TC092024	BINDER BLOCK,1-7/16-3/8
2	AR	1344T29-PD	DIAGRAM,PNEUMATIC
3	AR	1344T29-WD	DIAGRAM, WIRING
4	1	1345-004	BLOCK, STOP FOR BINDER
5	AR	4059-DC1PAR	PARAMETER LIST
6	1	1335950	UNWINDER ASSY, UNDER TBL
7	1	1338115	BRKT, TENSION FOLDER
8	1	1344075	GENERIC ASSY, 1344T29'S
9	1	AA198-5/32	REGULATOR,AIR
10	1	AAE45A24DM	VALVE,AIR,SOLENOID
11	1	AP-28-612SA	CABLE,FL, 24V PWR, IN1
12	1	F221-T004	SWING OUT MNT,W/ TENSION
13	1	F221-T008	TENSIONER BOX ASSY,2" MAX
14	1	RRBEEHIVEM	SPRING,MEDIUM BEEHIVE
15	1	SSAS016025	1/4X38X10-32, SHOULDER SC
16	2	SSBC98024	10-32 X 3/8 BUTTON CAP SC
17	1	SSSC95024	#10-24 X3/8, SOC CAP
18	2	SSSCM5X14	SCREW,SOC CAP,M5-0.8 X 14
19	1	WWF10	WASHER, FLAT, #10, COM
20	6	WWFS10	WASHER, FLAT, #10, SAE
21	5	WWL10	WASHER,LOCK,#10




# 1344075 Generic Assembly, 1344T29'S

AAC Drawing Number 1344075 Rev 0

NO	QTY	PART #	DESCRIPTION
1	1	0211-702A	CABLE,POS. SENSOR,6'
2	1	11271-100	UNDERTABLE MOUNT FOOT LIF
3	1	1278-6689B	BRACKET, EYE MOUNT
4	1	1344008	GUIDE, LEFT
5	1	1344012	MOUNT, GUIDE,LEFT
6	4	1344013	ROD, SS .75 X 20
7	1	1344014	MOUNT, GUIDE,RIGHT
8	2	1344015	PLATE, EDGE GUIDE
9	1	1344021	EDGE GUIDE, RIGHT
10	1	1344027	SEWING HEAD ASSEMBLY
11	1	1344037	PIPE,PVC,3/4",SCH40
12	2	1344038	PIPE,PVC,3/4",SCH40
13	4	1344039	PIPE,PVC,3/4",SCH40
14	1	1344T29-PD	DIAGRAM,PNEUMATIC
15	1	1344T29-WD	DIAGRAM, WIRING
16	1	1959-112	2 POS THREAD PLATE ASSY
17	1	1975-412A	PLATE,NUT,4-40,.95CTC
18	1	26151	TOOL TRAY, 1X3.5X9
19	1	4048-300U	TABLE TOP, 48X24,300U
20	1	4059061	COVER,FOOT PEDAL,UPPER
21	1	4059-DC04	MOUNT,UNIVERSAL,EFGA BOX
22	1	4059-DC50	MOTOR,L/S,HIGH TORQ
23	1	4059-FP301D	FOOT PEDAL ASSY,EFGA
24	1	781-7-1224	12" MAT. HLDR,CL,NON-ROT.
25	1	AAC6DP-3	CYLINDER,AIR,DA
26	1	AAFCT-11	CLEVIS, CYL, 5/16-24 ,1/4
27	1	AAQME-5-8	QUICK MALE ELBOW
28	1	EEFE-RR2	TAPE,REFLECTIVE,1" WIDE
29	1	FF19509	CABLE,3 COND,18 AWG,SJTOW
30	1	FFD2425F	RELAY,SSR,24VAC,25A
31	1	FFHBL4579C	RECEPTICAL,2 POLE,3W,15A
32	1	FFRK44T-4	CABLE,EYE,12',NO END
33	1	FFSM312LVQ	EYE,ELECTRIC,10-30VDC
34	1	K-4D	HD T LEG ADJ STAND
35	1	K-233	BOX,ELECTRICAL,SQUARE
36	1	K-234	COVER,4IN SQUARE
37	2	K-235	CONNECTOR,ROMEX,1/2"
38	1	K-3607T511	SASH CHAIN
39	1	K-CB600	MOTOR STARTER,ELEC
40	1	MMS064	HOOK, S, 1"
41	2	SSPS70048	4-40 X 3/4 PAN HD SLOTTED
42	2	SSZH#10064	SCREW,SHT.METAL HEX 10
43	4	TTH32415	HANDLE,THDED,1/4-20X7/8
44	2	WWFS10	WASHER, FLAT, #10, SAE
45	1	ZX3843	V-BELT,3/8 X 43

From the library of: Diamond Needle Corp






# 1335950 Undwinder Assembly

AAC Drawing Number 1335950 Rev 2

NO.	QTY	PART#	DESCRIPTION	NO.	QTY	PART#	DESCRIPTION
1	2	97-1711B	TUBE, 3/4 OD X 18.0L	44	1	GG157L050	BELT,GEAR,3/8P,1/2W
2	1	97-1711E	TUBE, 3/4 OD X 24.0L	45	2	MM132-1496	PLUG 1 X 2
3	1	211-057	PULLEY, 3/8P, 12T,1/2B	46	1	MM9208T38	MIRROR, 7.5 X 10.5
4	1	784B-2424	FLANGE, 23.50 SQUARE	47	5	MMFB4444	FOOT, RUBBER
5	1	1325-346	HOLDER,ROD,1/2 D,SLOT	48	2	NNE3/8-16	NUT, ELASTIC 3/8-16
6	2	1325-346A	HOLDER, ROD, 3/4", SLOT	49	5	NNH1/2-13	1/2-13 HEX NUT
7	1	1335-837A	ROD,1/2 DIA, 180 DEG	50	5	NNH1/4-20	1/4-20 HEX NUT
8	1	1335M-2046	PLATE,NUT,8-32@.43 CTC	51	3	NNH5/16-18	5/16-18 HEX NUT
9	1	1335M-4007	COVER, BELT	52	1	NNJ10-32	NUT,JAM,THIN #10-32
10	1	1347-001	EDGE GUIDE,SPLIT,(2 PCS)	53	4	NNK1/4-20	KEP NUT, 1/4-20
11	1	1961-311D	ROD,STRA,CRS,1/2X27.0L	54	1	PP12LF050-3/4	PULLEY,GEAR,3/8P,.50B,12T
12	1	1961-365	YOKE, BEARING	55	1	SSAS020128	5/16 X 2 1/4-20 SHLD, BOLT
13	2	3517	WASHER,THRUST,BRONZE	56	4	SSFC80024	#6-32 X 3/8 FLAT ALLEN
14	2	8732-0576	ROD, STRAIGHT, SS, 1/2 X	57	2	SSHC01048	1/4-20 X 3/4 HEX HEAD
15	1	23218DM	MOTOR ASSY,GEAR	58	2	SSHC01064	1/4-20 X 1 HEX HEAD
16	5	28201	BLOCK,CROSS,(LARGE)	59	5	SSHC01080	1/4-20 X 1-1/4 HEX HEAD
17	1	132556-273	LEG, 3/4 X 1-1/2 X 15 LG	60	4	SSHC01096	1/4-20 X 1-1/2 HEX HEAD
18	2	265155A	HOLDER, EYE, 1/2 BORE	61	5	SSHC01112	1/4-20 X 1-3/4 HEX HEAD
19	1	1335112	MOUNT,MOTOR	62	4	SSHC01160	1/4-20 X 2-1/2 HEX HEAD
20	1	1335115	MOUNT, PINCH ROLLER	63	1	SSHC10096	5/16-18 X 1-1/2 HEX HEAD
21	1	1335116	DRIVE ROD, ROLLER	64	1	SSHC25112	3/8-16 X 1-3/4 HEX HEAD
22	1	1335117	SHAFT, DRIVE ROLLER	65	1	SSHC25256	3/8-16 X 4 HEX CAP
23	1	1335139	ROD,SS,3/4 X 28.0L	66	4	SSPS70048	#4-40 X 3/4 PAN HD SLOT
24	1	1335189	LINK, IDLER ROLLER	67	1	SSSC01048	1/4-20 X 3/4 SOC CAP
25	1	1335497	ROLLER, FLUTTED, IDLER,	68	6	SSSC01064	1/4-20 X 1 SOC CAP
26	1	1335498	DRIVE ROLLER, FLUTTED	69	1	SSSC01096	1/4-20 X 1-1/2 SOC CAP
27	1	1335854	UNWINDER FRAME, UNDER	70	2	SSSC90024	#8-32 X 3/8 SOC CAP
28	1	1335858	HUB, UNWIND STAND	71	5	SSSC98024	#10-32 X 3/8 SOC CAP
29	1	1335859	HOLDER, ROD, 3/4",SIDE MT	72	3	SSSC98040	#10-32 X 5/8 SOC CAP
30	1	1335860	FRAME,BASE SUPPORT	73	1	SSSC98048	#10-32 X 3/4 SOC CAP
31	1	1335862	HOLDER, MIRROR	74	2	SSW#10	WING SCREW KNOB
32	1	1335864	BRACKET, CYLINDER	75	3	SSZS93032	SCREW, SHT.METAL 10 ZIP
33	1	33008708	DISC ASSY,8"	76	1	TTH32415	HANDLE,THDED,1/4-20X7/8
34	1	AAC8DP-3	CYLINDER,AIR,DA	77	2	WWF3/8	WASHER,FLAT,3/8
35	3	AAF1/8	1/8" PLASTIC CLAMP	78	4	WWF4	WASHER, FLAT #4
36	1	AAFBP-8C	BRKT,PIVOT,5/32 BORE	79	32	WWFS1/4	WASHER FLAT, 1/4
37	1	AAQME-5-10	ELBOW, MALE,5/32X10-32	80	1	WWFS3/8	WASHER, FLAT, 3/8
38	1	BBAW-3Z	BRG,ROD END,F, 10-32	81	1	WWFS5/16	WASHER, FLAT, 5/16
39	2	BBNTA613	BEARING,THRUST,375BORE	82	9	WWFS10	WASHER, FLAT #10
40	2	BBS8701-88	BEARING,BALL,.50IDX1.75OD	83	19	WWL1/4	1/4 LW
41	4	BBTRA613	WASHER,THRUST,STL, .375B	84	1	WWL5/16	5/16 LW
42	4	CCCL8F	CLAMP COLLAR- 1/2	85	2	WWL8	#8 LW
43	2	FFQM42VN6A	EYE,ELECTRIC,10-30VDC	86	8	WWL10	#10 LW

From the library of: Diamond Needle Corp




## 33008708 Ball Bearing Disc Assembly

AAC Drawing Number 9000904 Rev 4

NO.	QTY	PART#	DESCRIPTION
1	1	33008604	CONE, SPOOL
2	1	33008602	HUB, FLANGE 3/4 BORE
3	1	SEE CHART	SEE CHART
4	1	33008601	HUB, CENTER, 3/4 SHAFT
5	1	BB23216-88	BEARING,BALL,1.0B
6	1	RRLC026B1	SPRING,COMP .026X.18X.25
7	1	JJ012	3/16" STAINLESS BALL
8	1	SSSP01016	1/4-20 X 1/4 NYLOCK
9	1	SSSC01064	1/4-20 X 1 SOC CAP
10	2	SSFS80016	6-32 X 1/4, FLAT SLOT

-	BALL BEARING	DISC ASSEMBLY	33008732
3	1	33008632	DISC 32" DIA
-	BALL BEARING	DISC ASSEMBLY	33008724
3	1	33008624	DISC 24" DIA
-	BALL BEARING	DISC ASSEMBLY	33008716
3	1	33008616	DISC 16" DIA
-	BALL BEARING	DISC ASSEMBLY	33008708
18	1	SSW#1/4	WING SCREW KNOB




From the library of: Diamond Needle Corp

## 1339-1500A Pneumatic Panel Assembly

AAC Drawing Number 192058A Rev 3

NO.	QTY	PART #	DESCRIPTION
1	1	1338-024	Panel
2	1	AA198-5102	Regulator
3	2	AAEVQZ2121	Valve
4	2	AAQME-4-8	Quick Male Elbow
5	2	WWL10	Lock Washer
6	4	AAQPR-5-4	Reducer
7	4	FF264-311	Single Wago
8	3	FF264-341	Dual Wago
9	1	FF264-371	End Cap, Wago
10	2	SSSC98032	Screw, Socket Cap
11	4	SSSC70024	Screw, Socket Cap
12	4	WWF4	Flat Washer
13	2	WWFS10	Flat Washer




From the library of: Diamond Needle Corp

## 1344027 Sewing Head Assembly

AAC Drawing Number 1344027 Rev 6

NO.	QTY	PART#	DESCRIPTION
1	1	160071	COVER,END,MODIFIED
2	1	1344036	GAURD, FINGER, SINGER
3	1	267701-451M	BACK COVER,MOD
4	1	311-128	HUB, HANDWHEEL, TAPE MOUN
5	1	311-129	SLEEVE TAPE MOUNT ADJUST
6	1	32827M	FEED PLATE, MODIFIED
7	1	415026-451M	LEFT CLOTH PLATE
8	1	415028M	FRONT CLOTH PLATE
9	1	415036-451M	CLOTH PLATE, RIGHT
10	1	SSIN-300U194A	SEWING HEAD,SN,WF,FB,CS




From the library of: Diamond Needle Corp

## 1344029 Linear Guide Assembly

AAC Drawing Number 1344029 Rev 8

NO.	QTY	PART#	DESCRIPTION	NO.	QTY	PART#	DESCRIPTION
1	1	1344018	RAIL, LINEAR 12MM	9	1	NNJ7/16-20	NUT,JAM,7/16-20
2	1	1344025	BRKT, GUIDE MOUNT	10	1	NNJ10-32	NUT,JAM,THIN
3	1	1344028	BRKT, CYLINDER	11	2	SSBC05024	1/4-28 X 3/8
4	2	AA198RA510	FLOW CONTROL,5/32	12	2	SSBC95032	10-24 X 1/2
5	1	AAC022DXPM	CYL,MOD, DA, 9/16B, 2S,	13	4	SSFCM3X5	M3-0.50X5, SCEW
6	1	BBAW-3Z	BRG,ROD END,F, 10-32	14	2	SSSCM3x6	M3-0.5X__SCREW
7	1	MMGN12HZ0HN	LINEAR WAY	15	1	WWF3/8	WASHER,FLAT,3/8
8	1	NNH10-32	HEX-NUT 10-32 REG.	16	2	WWFS10	WASHER, FLAT



From the library of: Diamond Needle Corp

## 4059-FP301D Foot Pedal Assembly

AAC Drawing Number 9000033 Rev 5


NO	QTY	PART #	DESCRIPTION
1	AR	4059-EB301A	ACTUATOR, TREADLE, 9 PIN
2	1	26058	ROD, STRAIGHT, 1018
3	1	4059030	BASE, FOOT PEDAL, 12X18
4	1	4059033	FOOT PEDAL WELDMENT
5	1	A3502-4	FOOT PEDAL, BRACKET
6	2	MM94807A029	PUSHNUT, ROUND, 1/4 DIA
7	2	NNJ3/8-16	3/8-16 JAM NUT
8	2	NNK10-32	KEP NUT, 10-32
9	4	SSFPM5X10	SCREW, FLAT PHILLIPS
10	2	SSSS25096	3/8-16 SET SCREW, 1-1/2"



# 1344T29-WD Wiring Diagram

1344T29PAR  
USE CODE 5913

290	0	MODE. MUST SET THIS FIRST
026	04	TREADLE PEDAL CONFIG.
111	2500	MAX. SPEED
153	10	BREAKING POWER AT STAND STILL
161	1	ROTATION (CCW)
240	7	MACHINE BLOCK N.C.
270	1	HANDWHEEL SENSOR (NDL UP)
271	180	NEEDLE DOWN POSITION
272	900	TRANSMISSION RATIO
436	0	DISABLE AUTO SET-UP VIA RESISTOR
401	1	CHANGE FROM 0-1 TO SAVE PAR.



\*\* 4059-EXT7 EXTENSIONS WILL NOT WORK WITH ERA EB401 OR 4059-FP401B OR D'S (ANALOG TREADLE ACTUATORS)

3	2013	3/76	PO	RB	QTY.	ITEM	DESCRIPTION	PART NO.
2	2013	2/20	PO	RB	RECD.	NO.	STOCK SIZE	
1	199-07	10-30	RA	JT	NO.	FINISH	DETAILS	
NAME: DIAGRAM WIRING								
2nd DES. 11344T29								
MATERIAL								
NEXT ASSY 11344T29								
DES. BY P. DASHER								
DRA. NO. 125618B								
REV 3								
SCALE 1/6								
DATE: 9/28/07								
DWG. SIZE B								




182-07

The materials contained herein are confidential and proprietary information of Atlanta Attachment Company. In addition to any confidentiality and non-disclosure obligations that currently exist between you and Atlanta Attachment Company, your use of these materials serves as an acknowledgment of the confidential and proprietary nature of these materials and your duty not to make any unauthorized use or disclosure of these materials.



# 1344T29A-WD Wiring Diagram



From the library of: Diamond Needle Corp

# Atlanta Attachment Company (AAC) Statement of Warranty

## Manufactured Products

Atlanta Attachment Company warrants manufactured products to be free from defects in material and workmanship for a period of eight hundred (800) hours of operation or one hundred (100) days whichever comes first. Atlanta Attachment Company warrants all electrical components of the Serial Bus System to be free from defects in material or workmanship for a period of thirty six (36) months.

## Terms and Conditions:

- AAC Limited Warranty becomes effective on the date of shipment.
- AAC Warranty claims may be made by telephone, letter, fax or e-mail. All verbal claims must be confirmed in writing.
- AAC reserves the right to require the return of all claimed defective parts with a completed warranty claim form.
- AAC will, at its option, repair or replace the defective machine and parts upon return to AAC.
- AAC reserves the right to make the final decision on all warranty coverage questions.
- AAC warranty periods as stated are for eight hundred (800) hours or one hundred (100) days whichever comes first.
- AAC guarantees satisfactory operation of the machines on the basis of generally accepted industry standards, contingent upon proper application, installation and maintenance.
- AAC Limited Warranty may not be changed or modified and is not subject to any other warranty expressed or implied by any other agent, dealer, or distributor unless approved in writing by AAC in advance of any claim being filed.

## What Is Covered

- Electrical components that are not included within the Serial Bus System that fail due to defects in material or workmanship, which are manufactured by AAC are covered for a period of eight hundred (800) hours.
- Mechanical parts or components that fail due to defects in material or workmanship, which are manufactured by AAC.
- Purchased items (sewing heads, motors, etc.) will be covered by the manufacturers (OEM) warranty.
- AAC will assist in the procurement and handling of the manufacturers (OEM) claim.

## What Is Not Covered

- Parts that fail due to improper usage, lack of proper maintenance, lubrication and/or modification.
- Damages caused by; improper freight handling, accidents, fire and issues resulting from unauthorized service and/or personnel, improper electrical, plumbing connections.
- Normal wear of machine and parts such as Conveyor belts, "O" rings, gauge parts, cutters, needles, etc.
- Machine adjustments related to sewing applications and/or general machine operation.
- Charges for field service.
- Loss of time, potential revenue, and/or profits.
- Personal injury and/or property damage resulting from the operation of this equipment.

# Declaración de Garantía

## Productos Manufacturados

Atlanta Attachment Company garantiza que los productos de fabricación son libres de defectos de material y de mano de obra durante un periodo de ochocientos (800) horas de operación o cien (100) días cual llegue primero. Atlanta Attachment Company garantiza que todos los componentes del Serial bus son libres de defectos de material y de mano de obra durante un periodo de treinta y seis (36) meses.

## Términos y Condiciones:

- La Garantía Limitada de AAC entra en efecto el día de transporte.
- Reclamos de la Garantía de AAC pueden ser realizados por teléfono, carta, fax o correo electrónico. Todo reclamo verbal tiene que ser confirmado vía escrito.
- AAC reserva el derecho para exigir el retorno de cada pieza defectuosa con un formulario de reclamo de garantía.
- AAC va, según su criterio, reparar o reemplazar las máquinas o piezas defectuosas devueltas para AAC.
- AAC reserva el derecho para tomar la decisión final sobre toda cuestión de garantía.
- Las garantías de AAC tiene una validez de ochocientas (800) horas o cien (100) días cual llega primero.
- AAC garantiza la operación satisfactoria de sus máquinas en base de las normas aceptadas de la industria siempre y cuando se instale use y mantenga de forma apropiada.
- La garantía de AAC no puede ser cambiada o modificada y no está sujeta a cualquier otra garantía implicada por otro agente o distribuidor al menos que sea autorizado por AAC antes de cualquier reclamo.

## Lo Que Está Garantizado

- Componentes eléctricos que no están incluidos dentro del sistema Serial Bus que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un período de ochocientas (800) horas.
- Componentes mecánicos que fallen por defectos de materiales o de fabricación que han sido manufacturados por AAC son garantizados por un periodo de ochocientas (800) horas.
- Componentes comprados (Motores, Cabezales), son protegidos debajo de la garantía del fabricante.
- AAC asistirá con el manejo de todo reclamo de garantía bajo la garantía del fabricante.

## Lo Que No Está Garantizado

- Falla de repuestos al raíz de uso incorrecto, falta de mantenimiento, lubricación o modificación.
- Daños ocurridos a raíz de mal transporte, accidentes, incendios o cualquier daño como resultado de servicio por personas no autorizados o instalaciones incorrectas de conexiones eléctricas o neumáticas.
- Desgaste normal de piezas como correas, anillos de goma, cuchillas, agujas, etc.
- Ajustes de la máquina en relación a las aplicaciones de costura y/o la operación en general de la máquina.
- Gastos de Reparaciones fuera de las instalaciones de AAC
- Pérdida de tiempo, ingresos potenciales, y/o ganancias.
- Daños personales y/o daños a la propiedad como resultado de la operación de este equipo.



From the library of: Diamond Needle Corp

**Atlanta Attachment Company**  
362 Industrial Park Drive  
Lawrenceville, GA 30046  
770-963-7369  
[www.atlatt.com](http://www.atlatt.com)

**Printed in the USA**