





CATALOG NO. T105L

STYLES 53600

LIST OF PARTS FOR STYLES
53600 A
53600 H

Catalog No. T105 L

LIST OF PARTS

CLASS 53600

Styles

53600 A

53600 H

Streamlined Flat Bed Bag Closing Machines

Third Edition

Copyright 1957, 1962

By

Union Special Corporation
Rights Reserved in All Countries

UNION SPECIAL CORPORATION

INDUSTRIAL SEWING MACHINES

CHICAGO

Printed in U.S.A.

IDENTIFICATION OF MACHINE

Each UNION SPECIAL machine is identified by a Style number which is stamped into the name plate on the machine. Style numbers are classified as standard and special. Standard Style number have one or more letters suffixed, but never contain the letter "Z". Example: "Style 53600 A". Special Style numbers contain the letter "Z". When only minor changes are made in a standard machine a "Z" is suffixed to the standard Style number. Example: "Style 53600 AZ".

Styles of machines similar in construction are grouped under a class number which differs from the style number in that it contains no letters. Example: '53600'.

APPLICATION OF CATALOG

This catalog applies specifically to the Standard Styles of machines as listed herein. It can also be applied with discretion to some Special Styles of machines in this class. Reference to direction, such as right, left, front, back, etc., are given from the operator's position while standing at the machine. Operating direction of handwheel is toward the left.

STYLES OF MACHINES

Streamlined Flat Bed, High Throw, 1 1/2 Inch Needle Travel, Single Needle Machine, Enclosed Automatic Lubricating System From Two Reservoirs, Lateral Looper Travel, Mechanical Chain Cutter, Distance From Center Line of Needle to Lower Edge of Throat Plate Support 5/8 Inch.

- 53600 A For closing bags made from medium and heavy weight cotton, osnaburg, or burlap. Seam Specification 401-SSa-1 or 401-SSn-1. Stitch range 3 to 6 per inch.
- 53600 H For closing bags made from medium and heavy weight burlap and single ply or multi-wall paper. Seam Specification 401-SSa-1 or 401-SSn-1. Stitch range 3 to 5 per inch.

NEEDLES

Each UNION SPECIAL needle has both a type number and size number. The type number denotes the kind of shank, point, length, groove, finish and other details. The size number, stamped on the needle shank, denotes the largest diameter of blade measured in thousandths of an inch, midway between the shank and the eye. Collectively, the type number and the size is the complete symbol.

Standard needle for Style 53600 A is Type 144 G. It has a round shank, round point, No. 2 bag, double groove, spotted, short point, chromium plated - sizes 054, 200/080, 230/080, 230/090.

Standard needle for Style 53600 H is Type 943 G. It has a round shank, spear point, No. 2 bag, double groove, spotted, chromium plated - sizes 170/067, 185/073, 200/080, 230/090, 250/100.

To have needle orders promptly and accurately filled, an empty package, a sample needle, or the type and size number should be forwarded. Use description on label. A complete order would read as follows: "1000 Needles, Type 144 G, Size 200/080".

Selection of the proper needle size should be determined by size of thread used. Thread should pass freely through needle eye in order to produce a good stitch formation.

USE GENUINE NEEDLES AND REPAIR PARTS

Success in the operation of these machines can be secured only with genuine UNION SPECIAL Needles and Repair Parts as furnished by the Union Special Corporation, its subsidiaries and authorized distributors. They are designed according to the most approved scientific principles, and are made with utmost precision. Maximum efficiency and durability are assured.

Genuine needles are packaged with labels marked *Union Special*. Genuine repair parts are stamped with the Union Special trademark, U S Emblem. Each trademark is your guarantee of the highest quality in materials and workmanship.

IDENTIFYING PARTS

Where construction permits, each part is stamped with its part number. On some of the smaller parts, and on those where construction does not permit, an identification letter is stamped in to distinguish the part from similar ones.

Part numbers represent the same part, regardless of catalog in which they appear.

IMPORTANT! ON ALL ORDERS, PLEASE INCLUDE PART NAME AND STYLE OF MACHINE FOR WHICH PART IS ORDERED.

TERMS

Prices are strictly net cash and are subject to change without notice. All shipments are forwarded f.o.b. shipping point. Parcel Post shipments are insured unless otherwise directed. A charge is made to cover postage and insurance.

OILING

The oil has been drained from the machine before shipping, and the reservoirs must be filled before beginning to operate. Use a straight mineral oil with a Saybolt viscosity of 90 to 125 seconds at 100° Fahrenheit.

Oil is filled at the spring cap on the left side of the machine just below the pulley, and is checked at the sight gauge in front of the spring cap. The oil level should be kept near the top of this sight gauge. The oil cup, located on the left side of machine in back of the needle lever stud, should be filled twice daily.


The following is a numerical list of parts used in Styles 53600 A, 53600 H. Quantities, part numbers and descriptions are given. Unless otherwise specified, the parts listed are for both machines. Following the parts list are photographs of some of the major parts.


| Amt. | Part No. | Description | Amt. | Part No. | Description | Amt. | Part No. | Description |
|---------|--------------------|---|--------|----------------------|---|----------------|--------------------|---|
| 1 | 8 | Looper Drive Lever | 1 | 666-47 | Felt Oil Wick for 29126 CK | 1 | 15430 D | Nut for needle lever connecting rod tube |
| 3 | 18 | Shaft Nut for 29132 V, | 2 | 666-82 | Felt for 51145, 51145 C | 1 | 15465 F | 51216, right thread Looper Rocker Cone |
| 2 | PI18 | 51240 E, 51741 C Pin for 666-82 | 2 | 666-120 | Oil Wick for upper | | | for 29192P(22894W) |
| 3 | 20 | Washer for 539, 53659 H, 53758 | | | looper rocker shaft bushing and right | 1 | 20162 G | Sewing Head Adapter (22642, 22637 F) |
| 1 | 20 | Washer for 51170 E | ľ | | looper drive lever | 2 | 21114 M | Eyelet Locking Ring |
| 1 1 | 22 KH 50-703 | Screw for 51204 A | 5 | 666-148 | shaft bushing Oil Tube Fitting | 2 | 21114 M | for 51192 G Locking Ring for |
| - | Blk. | Lifter Lever Stop | 1 | 666-150 | Felt Wick for 53693 G | 1 | 21382 G-26 | 53659 H Pulley Rim (22569) |
| 1 | 50-760 | Pin for 53683 | 1 | 666-152 | Oil Wick for upper | 4 | 22513 | Screw for 35731 A |
| 1 | Blk. 50-864 | Oil Gauge for 53694 | 1 | 666-154 | crankshaft bushing Felt Wick for | 1 1 | 22519 H 22519 K | Screw for 51244 B Screw for 53625 A |
| | Blk. | Crankshaft Plug for | | | 53693 B | _ | | Style 53600 H |
| | | 29476 FV | 1 | 666-157 | Main Oil Wick, 45/16 inches long | 3 | 22524 | Screw for throat plate |
| | 5.0 | Man dia Tion Mark | 2 | 666-158 | Main Oil Wick, 115/32 inches long | 1 5 | 22537 22539 L | Screw for 53783 N Plug Screw |
| 1 10 | 56 CO67 D | Needle Bar Nut Oil Hole Plug | 1 | 666-159 | Main Oil Wick, | 2 | 22541 | Screw for 53682 S |
| 1 1 | CO67 H CO67 H | Cork for bed Cork for filler cap | 1 | 666-160 | 4 1/8 inches long Oil Wick for upper | 3 1 | 22541 B 22542 | Screw for 53682 R Screw for 51282 Y |
| 1 | 73 | Screw for looper | | | mainshaft bushing | 2 | 22542 | Screw for 53682 H |
| 1 1 | 73 73 C | Screw for 53659 G Feed Dog Adjusting | 1 | 666-162 | Main Oil Wick, 1 3/4 inches long | 1 2 | 22557 B 22559 A | Screw for 53783 L Bearing Cap Screw, |
| | 75 C | Screw Style 53600 H | 3 | 666-163 | Oil Wick for upper & lower feed rocker | 2 | 22559 B | lower, for 29105AB Bearing Cap Screw, |
| 1 1 | 77 | Screw for 80675 Screw for 51236 A | | | shaft and lower | | | upper, for 29105AB |
| 1 2 | 77 80 | Screw for 51054 Screw for 53680 F | 3 | 666-164 | main shaft bushing Oil Wick for right | 2 2 | 22559 E 22560 B | Screw for 29476 FV Screw for 53783 C |
| 2 | 80 | Screw for 53680 G | | - | and left knife lever | 1 | 22562 A 22564 | Screw for 51254 J Screw for 51054 |
| 1 2 | 87 U J87 J | Screw for 53659 J Screw for 51104 K | | | shaft and right looper drive lever | 3 | 22569 | Screw for 21382G-26 |
| 2 1 | 88 88 | Screw for 14649 Set Screw for 29132V | 1 | 666-16 5 | shaft bushing Oil Wick for right | 5 3 | 22569 B 22569 B | Screw for 51282 Y Screw for 53690 A |
| 2 | 88 | Screw for 53682 F | • | 000-105 | looper drive shaft | 1 | 22571 B | Plug Screw |
| 1 1 | 91 91 | Screw for 14527 K Screw for 14530 E | 1 | 666-170 | bushing Felt Wick for needle | $\frac{10}{2}$ | 22571 D 22580 | Plug Screw Plug Screw for oil |
| 1 | 93 | Screw for 14525 | 1 | 666-175 | lever | 1 | 22580 D | reservoir Set Screw for 52423 |
| 1 2 | 93 93 A | Screw for 53634 A Screw for 51115 B | | | Oil Wick for 29476 FV | 1 | 22585 | Screw for 53657 |
| 2 2 | 95 95 | Plug Screw Screw for 51147 | 1 | 666-176 | Oil Wick for lower looper rocker shaft | 1 1 | 22585 A 22585 B | Screw for 53670 Screw for 53634 G, |
| 1 | 95 | Screw for 53694 | 1 | 666-178 | Oil Wick | | | 53634 H |
| 1 2 | 96 97 A | Spot Screw for 52423 Screw for 29066 V | 1 | 666-205 | Oil Wick for lower crankshaft bushing | 1 2 | 22586 22587 E | Plug Screw for bed Screw for 29132 V |
| 2 | 97 A | Screw for 29132 V | 1 | 666-206 | Oil Wick for lower crankshaft bushing | 2 | 22593 | (large ball end) Screw for 51104 L, |
| 2 | 98 | (small ball end) Screw for 53634 | 1 | 667 B-12 | Pin for 53642 | 1 | | 53658 A |
| 2 2 | 98 98 | Screw for 53635 Screw for 53642 A | 1 4 | 667 B-12 667 C-12 | Pin for 53642 B Dowel Pin for | | 22597 22597 A | Spot Screw for 53621 Set Screw for 53621 |
| 1 | 98 | Screw for 53678 G | - | | 53680 D, 56380 E | 2 | 22637 F | Screw for 20162 G |
| 4 1 | 109 258 A | Tension Disc Nut for 666-28 | 2 2 | 668-27 668-27 | Eyelet for 51192 G Eyelet for 53659 H | 1 4 | 22642 22653 D-8 | Screw for 20162 G Socket Head Cap |
| 1 1 | 258 A 269 | Lock Nutfor 51745 Nut for 51240 E | 2 | 719 | Screw for 51150, 51250 E | Į | | Screw for 53680 D, 53680 E |
| 1 | 402 | Stud for 53783 A | 1 | 1280 | Nut for 53636 A | 2 | 22704 | Screw for 53659 A |
| 1 | 482 C | Collar for 53644 (22894 C) | 1 1 | 1280 9939 AA | Nut for 53657 A Feed Rocker Shaft | $\frac{1}{2}$ | 22726 A 22729 | Screw for 53659 J Screw for 51243 C |
| 1 | 539 | Frame Ndl. Thread Eyelet (20, 22848) | 1 1 | 12982 14525 | Nut for 51241 D Needle Guard for | 2 2 | 22729 C 22729 C | Screw for 51241 D Screw for 51741 C |
| 4 | 605 A | Screw for 53694 A | | | Style 53600 A(93) | 1 | 22747 | Screw for 41255 B |
| 1 1 | 652 D-8 660-212 | Washer for 22747 A Oil Seal Ring | 1 | 14527 F | Presser Foot for Style 53600 A | 1 | 22747 A | Screw for 51158 E (652 D-8) |
| 1 | 660-219 F | Cloth Plate Čover | 1 | 14527 K | Presser Foot Shank | 1 | 22747 B | Feed Dog Adjusting Screw Style 53600 A |
| 1 | 660-232 | Spring Pin Ball Bearing for | 1 | 14530 C | for 14527 F (91) Presser Foot | 1 | 22758 C | Screw for 53783 A |
| 1 | 666-28 | 53694 Oil Cup for 51250 E, | 1 | 14530 E | Bottom for 14527 F Presser Foot Shank | 1 | 22764 | Spot Screw for 29132 V |
| | | (258 Å) | | | for 53620 H (91) | 1 | 22768 | Screw for 51244 B |
| 1 1 | 666-29 666-29 | Oil Wick for 666-28 Oil Wick for 53693 A | 3 | 14649 | Collar for 8, 9939 AA (88) | 1 | 22794 | Hinge Screw for 14527 F |
| 1 1 | 666-29 | Oil Wick for 53693 F Felt Oil Wick for | 1 | 15430 C | Nut for needle lever connecting rod tube | 1 | 22794 | Hinge Screw for 53620 H |
| - | 666-47 | 53693 E | | | 51216, left thread | 1 | 22798 A | Screw for 51204 |


| Amt. | Part No. | Description | Amt. | Part No. | Description | Amt. | Part No. | Description |
|--------|---------------------|---|----------|----------------------|---|--------|------------------|--|
| 1 | 22829 | Lock Nut Screw | 1 | 51142 A | Feed Lift Eccentric | 1 | 52882 P | Gasket for 53682 R |
| | | for 51745 (258 A) | | | for 29476 BL for | 1 | 52883 R | Presser Foot Lifter |
| 3 1 | 22839 22839 C | Screw for 53694 Screw for 53680 F, | | | Style 53600 A, .112 inch throw (22894D) | 1 | 52883 S | Lever Bushing Spring for 53783 L |
| . * | 22000 0 | 53680 G | 1 | 51142 D | Feed Lift Eccentric | 1 | 52889 A | Presser Spring |
| 1 | 22848 | Screw for 539 | | | for 29476 DM for | 1 | 53556 C | Regulator |
| 1 2 | 22848 22848 | Screw for 51170 E Screw for 53657 | | | Style 53600 H, .140 inch throw (22894D) | 1 | 55550 C | Presser Bar Bush- ing, lower |
| í | 22848 | Screw for 53659 | 1 | 51145 | Feed Lift Eccentric | 1 | 53605 B | Feed Dog for Style |
| 1 | 22848 | Screw for 53659 H | ١. | | Link for 29476 BL | 1 | 53 6 05 H | 53600 A (22596) |
| 2 2 | 22848 22848 | Screw for 53682 C Screw for 53682 T | 1 | 51145 | Feed Lift Eccentric Link for 29476 DM | 1 | 53005 11 | Feed Dog for Style 53600 H (22519 K) |
| 2 | 22848 | Screw for 53682 V | 1 | 51145 C | Looper Avoid Eccen- | 1 | 53608 | Looper (73) |
| 1 | 22883 H | Adapter Plug Screw | · | İ | tric Link for | 1 | 53613 | Looper Rocker for 29192 P |
| 1 2 | 22889 A 22894 C | Adapter Screw for 539 Screw for 482 C | 1 | 51147 | 29476 LT Crankshaft Collar (95) | 1 | 53616 A | Needle Lever |
| 3 | 22894 C | Eccentric Set Screw | ī | 51150 | Needle Lever Thrust | | | Connecting Rod |
| 2 | 22894 D | for 29105 AB | 1 | 51158 E | Collar (719) | 1 | 53617 | Bearing, lower Needle Bar, marked |
| 4 | 22094 D | Eccentric Spot Screw for 29105 AB | 1 | 91190 E | Needle Lever Thread Eyelet (652 D-8, | 1 | 50011 | "DS" (56) |
| 1 | 22894 D | Spot Screw for | | | 22747 A, 43443 Q) | 1 | 53620 H | Presser Foot for |
| 1 | 22894 D | 51142 A Spot Screw for | 1 | 51170 E | Frame Needle Thread Guide (20, | 1 | 53621 | Style 53600 H Pulley Hub (22597, |
| * [| 22054 D | 51142 D | l | [| 22848) | | | 22597 A) |
| 1 | 22894 J | Set Screw for | 1 | 51170 E | Filler Cord Guide | 1 1 | 53622 | Main Shaft |
| 1 | 22894 K | 53636 H Spot Screw for | | | for Style 53600 H (20, 22848) | * | 53624 B | Throat Plate for Style 53600 A |
| | | 53636 H | 2 | 51192 B | Tension Post Fer- | ١, | #0004 == | (22524) |
| 1 | 29066 V | Needle Lever Connec- | 2 | 51192 G | rule Tension Eyelet | 1 | 53624 H | Throat Plate for Style 53600 H |
| | | ting Rod Upper Bearing Assembly | 1 | 51192 G 51204 | Cast-off Wire for | | | (22524) |
| 1 | 29105 AB | Looper Drive Eccen- | | · | Style 53600 A | 1 | 53625 A | Needle Guard for |
| l | | tric Assembly, | 1 | 51204 A | (22798 A) Cast-off Wire Sup- | | | Style 53600 H (22519 K) |
| 1 | 29126 CK | .374 inch throw Feed Driving Eccen- | 1 | 31204 A | port for Style | 1 | 53634 | Feed Bar (98) |
| | | tric Assembly, .200 | | | 53600 A (22 KH) | 1 | 53634 A | Feed Bar Arm |
| | | inch throw (eccen- tric No. 53636 H) | 1 | 51216 | Needle Lever Connec- ting Rod Tube | 1 | 53634 B | (93, 53634 C) Feed Bar Shaft |
| 1 | 29132 V | Knife Lever Eccentric | | | (15430 C, 15430 D) | 2 | 53634 C | Washer for 75 C, |
| 1 |] | Assembly, 160 | 1 | 51236 A | Pin for 51145 (77) | 1 | 53634 G | 53634 A |
| 1 | 29192 P | inch throw (18) Looper Rocker | 1 1 | 51236 A 51240 E | Pin for 51145 C (22768) Connecting Rod | 1 | 33034 G | Feed Dog Holder for Style 53600 A |
| · · | | Assembly | " | | (18, 269) | ١. ا | 50004 TT | (22585 B, 22747 B) |
| 1 1 | 29348 D 29476 BL | Ndl. Lev. Assm. Feed Lift Eccentric | 1 | 51241 D | Looper Connecting Rod Ball Joint, | 1 | 53634 H | Feed Dog Holder for Style 53600 H |
| - 1 | 20410 DL | Assembly, .112 inch | | | left (12982) | | | (73 C, 22585 B) |
| | | throw for Style | 1 | 51242 M | Washer for 52841 G | 1 | 53635 | Feed Rocker (98) |
| 1 | 29476 DM | 53600 A Feed Lift Eccentric | 2 1 | 51243 C 51244 B | Ball Stud Fork (22729) Looper Rocker Shaft | 1 | 53636 | Connecting Rod for 29126 CK |
| - T | | Assembly, .140 inch | - | 0.2211.23 | Arm (22768, 22519 H) | 1 | 53636 A | Feed Rocker Stud |
| | l | throw for Style | 1 | 51246 | Nut for 29192 P | 1 | 53636 B | (1280) Feed Drive Bushing |
| 1 | 29476 FV | 53600 H Crankshaft Assembly | 1 | 51250 E | Needle Lever Stud for 29348 D (719) | * | 22020 D | for 29126 CK |
| | i | 1.132 inch throw | 1 | 51254 D | Needle Bar Bushing, | 2 | 53636 C | Thrust Washer |
| 1 | 29476 LT | Looper Avoid Eccentric Assembly, .112 | 1 | 51254 J | lower Needle Bar Conn. | 1 | 53636 H | Feed Drive Eccentric, 200 inch throw for |
| l | | inch throw | | | for 29348 D (22562 A) | İ | | 29126 CK (22894 J, |
| 2 | 35731 A | Presser Bar Connec- | 1 | 51256 C | Presser Bar Spring | 1 | 53642 | 22894 K) |
| | | ting Guide Plate (22513) | 1 1 | 51282 Y 51282 Z | Head Cover (22569B) Gasket for 51282 Y | | JJV#4 | Looper Drive Lever for Style 53600 A |
| 1 | 39552 C | Washer for 53783 N | 2 | 51292 | Tension Post | ١, | 50040 | (667 B-12) |
| 1 | 41255 B | Fork for 29132 V | 2 1 | 51292 C 51292 F-2 | Tension Nut Tension Spring for | 1 | 53642 A | Looper Drive Lever Rocker (98) |
| 1 | 43443 Q | (22747) Nut for 22747 A | l | 01696 F-6 | looper Style 53600 A | 1 | 53642 B | Looper Drive Lever |
| 1 | 51004 | Auxiliary Cast-off | 1 | 51292 F-5 | Tension Spring for | l | | for Style 53600 H |
| 2 | 51054 | for Style 53600 A Link Pin for 29348 D | 1 | 51292 F-8 | looper Style 53600 H Tension Spring, | 1 | 53642 G | (667 B-12) Looper Drive Plunger |
| - | 21004 | (77, 22564) | 1 | | needle | 1 | 53642 H | Plunger Spring |
| 1. | 51104 K | Auxiliary Cast-off | 1 | 51741 C | Looper Connecting | 1 | 53642 J | Looper Drive Lever Lock Plunger Stud |
| | | Support for Style 53600 A (J87 J) | 1 | | Rod Ball Joint, right (18) | 4 | 53 6 42 N | Looper Drive and |
| 1 | 51104 L | Cast-off Wire for | 1 | 51741 E | Washer for 51741 C | ŀ | | Feed Rocker |
| | | Style 53600 A | 1 | 51745 | Looper Rocker Cone Stud for 29192 D | 1 | 53644 | Bushing Looper Rocker Shaft |
| 1 | 51115 B | (22593) Needle Lever for | | | Stud for 29192 D (258 A, 22829, | 2 | 53644 A | Looper Rocker Shaft |
| - | | 29348 D (77, 93 A, | ١. | | 51246) | ١, | E0654 | Bushing |
| 1 | 51134 P | 22564) Lubricating Felt | 1 | 51957 D 52423 | Presser Bar Take-up for Style | 1 | 53654 | Needle Bar Bushing, upper |
| 1 | 51134 R | Lubricating Felt | • | | 53600 Å (96, | 1 | 53657 | Cast-off Support |
| . | | Guard | | E2041 A | 22580 D) | I | | Plate for Style |
| 1 | 51142 A | Looper Avoid Eccen- tric for 29476 LT. | 1 | 52841 G | Locking Stud for 53642 A (51242 M, | | | 53600 A (22585, 22848) |
| | | .112 inch throw | | | 52841 H) | 1 | 53657 A | Supp. Plate Stud for |
| ı | 1 | (22894 D) | 1 | 52841 H | Nut for 52841 G | • | · | Style 53600 A (1280) |


| mt. | Part No. | Description | Amt. | Part No. | Description | Amt. | Part No. | Description |
|-----|----------|----------------------|------|------------------|-----------------------|------|------------------|----------------------|
| 2 | 53658 A | Cast-off Plate | 1 | 53682 C | Hinge for cloth plate | 1 | 53 6 93 E | Oil Tube for crank- |
| _ | | Eyelet for Style | i | | cover, right (22848) | | | shaft |
| | | 53600 A (22593) | 1 | 53682 E | End Cover, bottom | 1 | 53693 F | Oil Tube for knife |
| 1 l | 53659 | Thread Eyelet for | 2 | 53682 F | End Cover Hinge Pin | | | eccentric |
| _ | | Style 53600 A | ţ. | } | (88) | 1 | 53693 G | Oil Tube for looper |
| i | | (22848) | 1 | 53682 H | Cloth Plate Cover | | | drive eccentric |
| 1 | 53659 A | Thread Guard for | 1 | | Spring (22542) | 3 | 53693 H | Oil Seal Washer |
| _ | | Style 53600 A | 1 | 53 6 82 J | Latch Pin | 1 | 53694 | Oil Reservoir (22839 |
| | | (22704) | 1 | 53682 K | Cloth Plate Cover | 1 | 53694 A | Oil Reservoir Cover |
| 1 | 53659 G | Looper Thread Pull- | | | Spring Clamp Plate | | | (605 A) |
| _ | | off for Style | 1 | 53682 L | Cloth Plate Cover | 1 | 53 6 94 B | Oil Reservoir Cover |
| | | 53600 H (73) | | | Hinge Pin, right | | | Gasket |
| 1 | 53659 H | Looper Thread Pull- | 1 | 53682 P | End Cover Latch Pin | 2 | 53694 C | Oil Tube Coupling |
| _ | | off Eyelet for Style | | | Spring | 1 | 53694 D | Oil Filter for 53694 |
| . 1 | | 53600 H (20, 22848) | 1 | 53682 R | Chamber Cover | 1 | 53694 E | Bushing for 53694 |
| 1 | 53659 J | Looper Thread Pull- | l | | (22541 B) | 2 | 53 6 94 F | Gasket for 53694 |
| - | | off Wire for Style | 1 | 53682 S | End Cover Hinge | 1 | 53694 G | Oil Reservoir Wick |
| | | 53600 H (22726 A) | | - · | Pin Bar (22541) | 1 | 53694 H | Elbow for 53694 |
| 1 | 53670 | Knife, upper | 1 | 53682 T | Cover Plate for Style | 1 | 53758 | Thread Eyelet |
| _ | | (22585 Å, 53678 N) | 1 | | 53600 H (22848) | | | (20, 22848) |
| 1 | 53678 C | Knife Lever Spring | 1 | 53682 U | Cloth Plate Cover, | 1 | 53783 A | Presser Foot Lifter |
| 2 | 53678 D | Knife Rocker Shaft | | | right | | | Lever Link |
| | | Bushing | 1 | 53 6 82 V | Cloth Plate Cover, | | | (402, 22758 C) |
| 1 | 53678 F | Knife Arm Shaft | 1 | 1 | left (22848) | 1 | 53783 C | Presser Bar Connec |
| 1 | 53678 G | Knife Lever (98) | 1 | 53683 | Presser Foot Lifter | | | tion and Guide |
| 1 | 53678 N | Washer for 22585 A | 1 | 53690 A | Main Shaft Housing | • | | (225 6 0 B) |
| 1 | 53680 D | Throat Plate Support | Į. | | (22569 B) | 1 | 53783 L | Presser Foot Lifter |
| - | | Bracket, left | 1 | 53690 B | Bushing for 53690A | | | Lever Bell Crank |
| | | (667 C-12, | 3 | 53690 C | Main Shaft Bushing, | | | (22557 B) |
| | | 22653 D-8) | 1 | | lower | 1 | 53783 M | Presser Foot Lifter |
| ı | 53680 E | Throat Plate Support | 1 | 53693 | Oil Tube for main | | | Lever Connecting |
| | | Bracket, right | 1 | | oil wick | | | Rod |
| | | (667 C-12, | 1 | 53693 A | Oil Tube for looper | 1 | 53783 N | Presser Foot Lifter |
| | | 22653 D-8) | 1 | | connecting rod ball | | | Lever, internal |
| 1 | 53680 F | Throat Plate Support | 1 | 1 | joint, left | | | (22537, 39552 C) |
| - | | for Style 53600 H | 1 | 53693 B | Oil Tube for looper | 1 | 56354 A | Needle Lever Link |
| | * | (80, 22839 C) | 1 | | avoid eccentric | | | for 29348 D |
| 1 | 53680 G | Throat Plate Support | 1 | 53693 C | Oil Tube for feed | 1 | 56390 E | Crankshaft Bearing |
| | | for Style 53600 A | | | eccentric connect- | | | Housing Gasket |
| | | (80, 22839 C) | | | ing rod | 1 | 61351 C | Washer for 53678 C |
| | | , | | | O - | 1 | 80675 | Knife, stationary |

NOTE: Numbers in parenthesis following parts' description indicate the screws, nuts, etc., used to attach or hold these parts.











41255 B (Spot) 22587 E(Set) 29132 V





Here are Oil Specifications for Union Special Sewing Machines

Specification 174 specifies a high quality petroleum oil, viscosity 100 seconds at 100°F. Recommended for all oiling applications on high speed machines.

Specification 175 specifies a high quality petroleum oil, viscosity 100 seconds at 100°F., water white or with a maximum A.S.T.M. color number of 1. For use where freedom from oil staining is paramount.

Specification 87 specifies a high quality petroleum oil, viscosity 300 seconds at $100^{\rm OF}$.

Specification 100 specifies a general purpose high quality grease for use in ball bearings and transmitters. It is similar to commercial N.L.G.I., grease No. 3. Where No. 3 grease is not obtainable, No. 2 may be used.

UNION SPECIAL

| OMICH SELECIAL | | | |
|---------------------------|---------|---------|---------|
| SPECIFICATION NO. | 174 | 175 | 87 |
| Viscosity S.S.U. at 100°F | 90-125 | 90-125 | 300-350 |
| Flash (Min.) | 350 | 350 | 350 |
| Pour (Max.) | 20 | 20 | 20 |
| Color A.S.T.M. (Max.) | 3 | 1 | 3 |
| Neutralization No. (Max.) | 0.10 | 0.10 | 0.10 |
| Viscosity Index | | | |
| (D & D Min.) | 85 | 85 | 85 |
| Compounding | None | None | None |
| Copper Corrosion (Max.) | 1A | 1A | 1A |
| *Anline No. | 175-225 | 175-225 | 175-225 |
| | | | |

*Used with Buna N Rubber "O" Retainers



NOTE 1: The use of non-corrosive additives in oils meeting above classification is desirable but not essential. These may include:

- 1. Oxidation inhibitors
- 2. Rust inhibitors
- 3. Lubricity additives
- 4. Anti-oxidants
- 5. Film strength additives


These additives must be completely soluble in the oil and not removable by wick feeding nor shall they separate.

NOTE 2: Oils containing the following type additives shall not be used at any time:

- 1. Extreme pressure additives—corrosive
- 2. Tackiness or adhesive additives
- Lead soap additives
 Detergents



UNION SPECIAL CORPORATION



WORLDWIDE SALES AND SERVICE

Union Special Corporation maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special Corporation representatives and service technicians are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a qualified representative to serve you.

Corporate
Office:

One Union Special Plaza Huntley, IL 60142 Phone: 847•669•5101

Fax: 847 • 669 • 4454

European Distribution Center:

Union Special GmbH Raiffeisenstrasse 3

D-71696 Möglingen, Germany

Tel: 49 • 07141 • 247 • 0 Fax: 49 • 7141 • 247 • 100 Brussels, Belgium
Charlotte, N.C.
El Paso, TX
Hong Kong, China
Huntley, IL
Leicester, England
Lille, France
Miami, FL
Milan, Italy
Möglingen, Germany
Montreal, Quebec
Osaka, Japan
Santa Fe Springs, CA

Other Representatives throughout all parts of the world.



