

PARTS LIST

Model 206RBATC

Model 206RBATCL




Fig. 1





Fig. 2



30102 - DC 24V  
30104 - DC 40V







Fig. 4

PC24V-18A01  
DC40V-18A02













Fig. 8




8132



18358


6332

300120




11969


10747




15571



18084



10748




18324

18344





6052



30194



6051




8123






8121



8120



8118



10780

R. 9