

Edgewater Machine Company Inc.

13-20 131st. Street
College Point, NY 11356 U.S.A.

Phone: 718-539-8200
Fax: 718-358-4648
Email: info@edgewatermachine.com

Designers and Manufacturers
of Special Machinery

Pattern Examples for the Emco 1x3 and 1x6 Quilting Machines

Version 05.13



**The Highest Quality Machine
Built in America
Since 1944**

User's Guide for the Emco Pattern Booklet

Most patterns in this book whether a 1x3, or a 1x6, can be altered to allow it to be used on your particular machine.

As an example, a pattern such as a 1x6, which is a 12 inch repeat pattern can be resized to run on a 1x3 machine which normally has patterns that are 6 inches long. And the opposite is also true. Smaller patterns can be enlarged to 12 inches long to run on the 1x6 machines.

All types of machines can run any 1x3 pattern which is 6 inches long.

However there are some exceptions. Some patterns in this booklet were designed strictly for computer driven machines. These patterns will not be suitable for mechanical cam driven machines. Please view the bottom of each pattern design page to see if the pattern is usable on your type machine. If assistance is needed, please ask our factory for advise when selecting pattern designs in order to determine if the pattern will work on your type of machine. You may also see some patterns with initials following the three digit pattern number. These patterns are usually custom made patterns for customers. If you have a special request please feel free to inquire about a custom designed pattern.

If you have any difficulty selecting patterns, or understanding how patterns are used on certain machines, please contact our factory for assistance.

Edgewater Machine Company Inc.

13-20 131st. Street
College Point, NY 11356 U.S.A.
Phone: 718-539-8200
Fax: 718-358-4648
Email: info@edgewatermachine.com
Website: www.edgewatermachine.com

Explanation of Terminology used on Pattern Pages

Each pattern page consists of a sample needle setting shown on the appropriate needle bars. Under the sample needle setting is listed the number of the pattern, the label given to the sample needle setting, the amount of throw the pattern has in inches, and the length in inches of one repeat cycle of the pattern.

Needle bars:

Can be 1x3 as shown or 1x3x6.

Each number represents the number of inches between needle bars.

In this case the 1 indicates the first (front) needle bar. The 3 indicates 3 inches between the first and next needle bar.

Dotted line shows one repeat cycle of the pattern. The label "Repeat =6" indicates this one cycle is 6 inches long.

The label "Throw=3" indicates the pattern moves 3 inches to the side and then back 3 inches.

Some pattern sheets will show more than one needle setting.

Pattern numbers:

The first 3 digits are the number of the pattern. The next digit tells you the approximate throw in inches rounded to the nearest whole number. The last digit indicates the typical needle bar to use on the machine. In this case the pattern number is a 514 with 3 inches of throw and usually used on a 1x3 machine, of which the needle bars are 3 inches apart.



The "X" represents a needle.
The empty box indicates no needle.

Typical label given to needle setting.

The number of the pattern.

Amount of throw (carriage travel) that the pattern moves in inches side to side.


Length of one cycle of the pattern, in inches.



Another pattern example follows this page.

Another Example of Pattern Page Explanations

In this example the pattern 206-4-6 has 4 inches of side to side carriage travel (throw) and is 12 inches long in one repeat cycle.



The three needle bars as shown in this example has 1" needle spacing, and each needle bar is 3 inches apart.

This pattern shows the dotted line as one repeat cycle. It is 12 inches long and has 4 inches of throw.




Emco Pattern 104-1-6

3 x 6 Needle Setting

Throw = 1.3


Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



Emco Pattern 110-1-3	1 x 3 Needle Setting	Throw = 1.0	Repeat = 6	1/3 Scale
----------------------	----------------------	-------------	------------	-----------



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 111-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 111-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 112-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

6	☒	☐	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	
1	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 112-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 113-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 113-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 113-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 201-1-3

2 x 3 Needle Setting

Throw = 1.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 201-1-3

1 x 3 Needle Setting

Throw = 1.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-2-3

1 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	


Emco Pattern 206-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-3-6

Universal Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-4-c

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 206-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 207-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 207-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 207-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 208-1-3

1 x 3 Needle Setting

Throw = .9

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 210-1-3

1 x 3 Needle Setting

Throw = 1.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 213-2-3

2 x 3 Needle Setting

Throw = 1.8

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 213-3-3

3 x 3 Needle Setting

Throw = 3.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

6	☒	☐	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	
1	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 213-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 213-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 213-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 219-2-3

2 x 3 Needle Setting

Throw = 1.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 226-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

3	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐
1	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-2-3

1 x 3 Needle Setting

Throw = 2.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-3-6

Universal Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 227-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 300-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 301-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 301-2-3

1 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 301-2-3

1 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale






Emco Pattern 301-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 301-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 301-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐	☐	☐


Emco Pattern 303-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 303-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐	☐	


Emco Pattern 304-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 304-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 304-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 305-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 305-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 309-1-3

1 x 3 Needle Setting

Throw = .7


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 337-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 337-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



Special Pattern. Requires special gearing, 43-50-60 and a 132 tooth ratchet.


Emco Pattern 337-2-6

1 x 3 Needle Setting

Throw = 2.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 337-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 337-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 340-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 340-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



6	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
1	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐	


Emco Pattern 340-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 340-3-6

Universal Needle Setting

Throw = 3.0


Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	☐	☒


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine


[illegible]

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 340-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐


Emco Pattern 340-4-6

3 x 3 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 340-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



Clo


Emco Pattern 340-6-6

Universal Needle Setting

Throw = 6.0


Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 402-2-3

1 x 3 Needle Setting

Throw = 2.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 402-3-3

3 x 3 Needle Setting

Throw = 3.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 404-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 404-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 404-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 404-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



6	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
1	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 405-2-6

3 x 6 Needle Setting

Throw = 2.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 405-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 405-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 405-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 406-2-6

3 x 6 Needle Setting

Throw = 2.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 406-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 406-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 407-2-3

2 x 3 Needle Setting

Throw = 2.8

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 508-1-3

1 x 3 Needle Setting

Throw = 1.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

31

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 514-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



6	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
1	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 514-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-3-6

Universal Needle Setting


Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-4-6

Universal Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 514-6-6

3 x 3 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 515-3-3

3 x 3 Needle Setting

Throw = 2.6


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 525-1-3	1 x 3 Needle Setting	Throw = 1.0	Repeat = 6	1/3 Scale
----------------------	----------------------	-------------	------------	-----------



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 525-2-3

1 x 3 Needle Setting

Throw = 2.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

3	☒	☒	☒	☒	☒	☒	☒	☒	☒	☐	☒	☐	☒	☐	☒	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐
1	☒	☒	☒	☒	☒	☒	☒	☒	☒	☒	☐	☒	☐	☒	☐	☒	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☒

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 582-3-3

3 x 3 Needle Setting

Throw = 3.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]


1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 600-2-6

3 x 6 Needle Setting

Throw = 2.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐


Emco Pattern 600-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 600-6-3

3 x 3 Needle Setting

Throw = 6.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 603-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 605-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 606-1-3

1 x 3 Needle Setting

Throw = 1.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 608-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale






Emco Pattern 608-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 608-6-6

6 x 6 Needle Setting

Throw = 6.0


Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 669-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 693-1-3

2 x 3 Needle Setting

Throw = 1.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 713-1-3

1 x 3 Needle Setting

Throw = 1.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 714-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 714-3-6

Universal Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 714-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 714-6-6

Universal Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 717-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 717-2-3

1 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐


Emco Pattern 717-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 717-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 717-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 717-6-6

6 x 6 Needle Setting

Throw = 6.0


Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 718-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 719-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 719-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 725-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



6	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
1	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐


Emco Pattern 725-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale






Emco Pattern 725-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 730-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 740-3-3

3 x 3 Needle Setting

Throw = 3.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]


1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 749-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale






Emco Pattern 749-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 752-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 752-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐


Emco Pattern 752-4-6

3 x 3 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 752-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale






Emco Pattern 754-4-6

4 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 754-4-6

Universal Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 756-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 756-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale






Emco Pattern 756-4-6

3 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 756-6-6

4 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 758-5-6

4 x 6 Needle Setting

Throw = 5.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 763-2-3

3 x 3 Needle Setting

Throw = 2.8


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

3	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐
1	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐


Emco Pattern 764-3-3

3 x 3 Needle Setting

Throw = 3.1

Repeat = 6


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 772-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 772-3-6

3 x 6 Needle Setting


Throw = 2.8

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 772-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 787-2-3

1 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 787-4-6

3 x 6 Needle Setting

Throw = 4.0


Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale





3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 793-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 800-2-3

2 x 3 Needle Setting

Throw = 2.0


Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1

1/3 Scale



Embroidery Type Machine




Emco Pattern 800-3-6

3 x 6 Needle Setting

Throw = 3.0


Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 800-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 800-6-c

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 814-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 815-2-3

2 x 3 Needle Setting

Throw = 2.5

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 815-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 820-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 826-1-3

1 x 3 Needle Setting

Throw = .6

Repeat = 6

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 834-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale




Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



[illegible]


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 836-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 836-3-c

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 836-3-m

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 836-3-n

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 836-3-q

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 836-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 836-4-c

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 836-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 836-6-c

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 836-s-m

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 837-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 837-3-c

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 837-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 837-4-c

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 837-6-6

6 x 6 Needle Setting

Throw = 6.0


Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

Emco Pattern 837-6-c	6 x 6 Needle Setting	Throw = 6.0	Repeat = 12	1/3 Scale
----------------------	----------------------	-------------	-------------	-----------



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 837-6-k

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



Emco Pattern 838-2-3	2 x 3 Needle Setting	Throw = 2.0	Repeat = 6	1/3 Scale
----------------------	----------------------	-------------	------------	-----------





3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 838-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 838-3-a

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 838-3-b

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	


Emco Pattern 838-3-c

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6


1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☐	☐	☒	☐	☐

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 838-4-6

4 x 6 Needle Setting

Throw = 4.0


Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 838-4-q

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 838-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale






Emco Pattern 838-6-k

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 839-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 840-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale




Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale

[illegible]

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 841-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 842-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 902-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale





3	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐
1	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	


Emco Pattern 909-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6


1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 910-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 910-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 910-6-6

3 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 912-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 913-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	


Emco Pattern 913-3-3

3 x 3 Needle Setting


Throw = 3.0

Repeat = 6

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 913-6-3

3 x 3 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐


Emco Pattern 913-6-6

3 x 3 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 914-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 916-4-6

3 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 916-4-6

4 x 6 Needle Setting

Throw = 4.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 916-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☒ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale





3	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐
1	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐


Emco Pattern 917-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 917-3-3

2 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 917-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 917-6-6

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 919-2-3

2 x 3 Needle Setting

Throw = 2.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



1/3 Scale






Emco Pattern 919-6-6

6 x 6 Needle Setting

Throw = 6.0


Repeat = 12

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

[illegible]

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐


Emco Pattern 920-3-3

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 920-3-6

3 x 6 Needle Setting

Throw = 3.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine



3	☒	☐	☐	☐	☐	☐	☒	☐	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐
1	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☒	☐	☐	☐	☐	☐


Emco Pattern 920-3-c

3 x 3 Needle Setting

Throw = 3.0

Repeat = 6

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 920-4-6

4 x 6 Needle Setting


Throw = 4.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine

1/3 Scale

Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine




Emco Pattern 920-6-c

6 x 6 Needle Setting

Throw = 6.0

Repeat = 12

1/3 Scale



Usable on these type machines: ☐ Cam Driven ☒ Computer Driven ☒ Embroidery Type Machine