

HISTORICAL COPY  
DO NOT REMOVE

---

List of Parts Complete

for

Machine No. 109-223

List of Parts Complete  
for  
Machine No. 103-223

| No.     | Name  |
|---------|---|
| *133117 | Arm, upper and lower (solid) with 948E and 133126 |
| 57202   | Arm Oil Tube for oiling 64267                     |
| 56003   | " " " with 52045, for oiling 133025               |
| 13862   | " " " " 52045, for oiling 133087                  |
| 52045   | 2 " " " Packing (cotton)                          |
| 127905  | " Rock Shaft                                      |
| 127907  | " " " 127905 with 64253, 64254 and 133067         |
| 42365   | " " " Back Bearing; Oil Pad (felt)                |
| 64386   | " " " Bushing (back)                              |
| 446 C   | " " " " " Set Screw                               |
| 64388   | " " " " (intermediate)                            |
| 423 C   | " " " " " Set Screw                               |
| 52045   | 2 " " " " Oil Pad (cotton)                        |
| 64253   | " " " Collar with two 624C                        |
| 624 C   | 2 " " " " Set Screw                               |
| 64254   | " " " Crank (back) with four 1149C                |
| 1149 C  | 4 " " " " " Set Screw                             |
| 133067  | " " " " (front) with 443C                         |
| 127838  | " " " " " Pin                                     |
| 443 C   | " " " " " Set Screw                               |
| 54105   | " " " Flanged Bushing                             |
| 52045   | " " " " " Oil Pad (cotton)                        |
| 453 C   | " " " " " Set Screw                               |

| No.      | Name  |
|----------|---|
| 18154    | Arm Rock Shaft Front Bearing Oil Pad (felt)                     |
| 127913   | " Rotary Shaft with 14980 and 57924                             |
| 127914   | " " " 127913 with 64368 and 127900                              |
| 133120   | " " " Bushing (front)   |
| 57791    | " " " " (intermediate) with 49093 and 64305                     |
| 49093    | Arm Rotary Shaft Bushing Oil Pad (braided cotton) long          |
| 64305    | Arm Rotary Shaft Bushing Oil Pad (braided cotton) short         |
| 832 C    | Arm Rotary Shaft Bushing Set Screw                              |
| 51321 C  | " " " " (front) Set Screw                                       |
| 54003    | " " " Collar with three 12593                                   |
| 1259 C 3 | " " " " Set Screw   |
| 61441    | " " " Flanged Bushing with 49093 and 64305                      |
| 49093    | Arm Rotary Shaft Flanged Bushing Oil Pad (braided cotton) long  |
| 64305    | Arm Rotary Shaft Flanged Bushing Oil Pad (braided cotton) short |
| 159 F 3  | Arm Rotary Shaft Flanged Bushing Screw                          |
| 57824    | " " " Oil Pad (felt)  |
| 127918   | " " " " Tube with 64503   |
| 64503    | " " " " Oil Pad (braided cotton)                                |
| 144 D    | " " " Screw   |
| 15196    | " Side Cover  |
| 190 J    | " " " Screw   |
| 133068   | Cloth Plate with four 57404, for 133069                         |
| 133070   | " " " " 57404, for 133071                                       |
| 57404 4  | " " Oil Tube  |

|         |   |   |
|---------|---|---|
| 61500   |   | Cloth Plate Slide   |
| 127501  |   | Cloth Plate Slide complete, Nos. 61500, two 52683 and four 725J   |
| 52683   | 2 | Cloth Plate Slide Spring  |
| 57334   | 2 | Cloth Plate Slide Spring Bracket  |
| 193 E   | 4 | " " " " " Screw   |
| 725 J   | 4 | " " " " " Screw   |
| 133069  |   | Cloth Plate complete, for 1 1/4 in. feed roll, for general work, Nos. 127501, 133068, two 57334 and four 193E |
| 133071  |   | Cloth Plate complete, for 2 in. feed roll, for general work, Nos. 127501, 133070, two 57334 and four 193E     |
| 898 D   |   | Cloth Plate Screw (large)   |
| 1011 F  | 2 | " " " (small)   |
| 127882  |   | " " Support Bracket with 29627, 50524C, 51250C and two 1520J  |
| 51250 C |   | Cloth Plate Support Bracket Adjusting Screw (bottom)  |
| 50524 C |   | " " " " " (top)   |
| 1520 J  | 2 | " " " " " Nut   |
| 29627   |   | " " " " Dowel Pin   |
| 146 E   |   | " " " " Screw   |
| 64267   |   | Crank Connecting Rod with two each 896E and 1057E   |
| 64366   |   | Crank Connecting Rod 64267 with 50069C  |
| 50069 C |   | " " " Ball Screw Stud (upper)   |
| 1516 E  |   | " " " " " Nut   |
| 64268   |   | " " " " " Washer  |
| 896 E   | 2 | Crank Connecting Rod Cap (lower) Screw  |
| 1057 E  | 2 | " " " " (upper) Screw   |
| 57288   |   | " " " Oil Case with 57290, 57291 and four each 185E and 448C  |

From the library of Diamond Needle Corp

| No.       | Name   |
|-----------|--|
| 57290     | Crank Connecting Rod Oil Case Cap                                      |
| 57291     | " " " " " Packing (felt)   |
| 185 E 4   | " " " " " Screw  |
| 448 C 4   | " " " " " Set Screw  |
| 127923    | Face Plate   |
| 46111     | Face Plate Pin   |
| 1423 J    | " " Screw  |
| 61018     | Feed Bar with two 624C   |
| 61459     | " " 61018 with 127744  |
| 57225     | " " Hinge Pin  |
| 624 C 2   | " " " " Set Screw  |
| 61495     | " Dog, 17 teeth (13 teeth to the inch) for general work for 61496      |
| 127505    | Feed Dog, 13 teeth (10 teeth to the inch) for 127553                   |
| 57293     | " " Packing .005 in. thick   |
| 57294     | " " " .012 in. thick   |
| 57321     | " " " .021 in. thick   |
| 1255 C    | " " Screw  |
| 51061 C 2 | " Eccentric Body Set Screw   |
| 127849    | " " Connection with 127848 and 127851                                  |
| 127850    | " " " 127849 with 127508 and 127788                                    |
| 127848    | Feed Eccentric Connection Oil Cup                                      |
| 127851    | " " " " " Oil Pad (braided Cotton)                                     |
| 217 E     | Feed Eccentric Set Screw   |
| 127508    | Feed Eccentric (adjustable) complete, Nos. 217E, 50653C and two 51061C |
| 127744    | Feed Lifting Connection  |
| 127745    | " " Eccentric with two 457C  |
| 457 C 2   | " " " Set Screw  |

| No.       | Name  |
|-----------|---|
| 50653 C   | Feed Regulating Screw   |
| 127509    | " Rocking Frame with four 624C                                  |
| 127788    | " " " Bar   |
| 624 C 2   | " " " " Set Screw   |
| 57234     | " " " Hinge Pin   |
| 57235 2   | " " " " " Bushing   |
| 449 C 2   | " " " " " Set Screw   |
| 624 C 2   | " " " " " Set Screw   |
| 127512    | " Roll (lower) 1 1/4 in. wide with two 435C, for general work   |
| 127513    | Feed Roll (lower) 2 in. wide with two 435C                      |
| 131176    | Feed Roll (lower) Clutch (brake)                                |
| 131177    | " " " " ((drive)  |
| 68149     | " " " " (brake) Connection with 440C, 1700J and two 50083C      |
| 440 C     | Feed Roll (lower) Clutch (brake) Connection Adjusting Screw     |
| 1700 J    | Feed Roll (lower) Clutch (brake) Connection Adjusting Screw Nut |
| 50083 C 2 | Feed Roll (lower) Clutch (brake) Set Screw                      |
| 127530    | " " " " " Stop Block  |
| 158 E 2   | " " " " " " " Screw   |
| 68150     | " " " " ((drive) Connection with two 50083C                     |
| 50083 C 2 | Feed Roll (lower) Clutch (drive) Connection Set Screw           |
| 127931    | " " " " " Cover   |
| 50004 B 2 | " " " " " " Screw   |
| 68151 6   | " " " " " Roller  |
| 68152 6   | " " " " " Plunger   |

| No.    |   | Name   |
|--------|---|--|
| 68153  | 6 | Feed Roll (lower) Clutch Roller Spring   |
| 127932 |   | " " " " Shaft  |
| 133105 |   | " " " " " 127932 with 131182<br>for 133106   |
| 127522 |   | Feed Roll (lower) Clutch Shaft Bracket with 448C   |
| 133106 |   | Feed Roll (lower) Clutch Shaft Bracket complete,<br>Nos. 127522, 127530, 127934, 133105, two 158E and<br>three 62562         |
| 62562  | 3 | Feed Roll (lower) Clutch Shaft Bracket Collar with<br>two 465C   |
| 465 C  | 6 | Feed Roll (lower) Clutch Shaft Bracket Collar Set<br>Screw   |
| 948 D  | 4 | Feed Roll (lower) Clutch Shaft Bracket Screw   |
| 127934 |   | " " " " " Spacing Collar   |
| 68155  |   | Feed Roll (lower) Clutch Sleeve with four 1149C  |
| 1149 C | 4 | " " " " " Set Screw  |
| 131182 |   | Feed Roll (lower) Clutch complete, Nos. 68149, 68150,<br>68155, 131176, 131177 and six each 58611, 68151,<br>68152 and 68153 |
| 58611  | 6 | Feed Roll (lower) Clutch Wearing Plate   |
| 54458  |   | Feed Roll (lower) Connecting Rod with two 896E   |
| 68016  |   | " " " " " 54458 with 54456   |
| 896 E  | 2 | " " " " " Cap Screw  |
| 1257 C |   | " " " " " Hinge Screw  |
| 1620 E |   | " " " " " " " Nut  |
| 443 C  | 2 | " " " " Eccentric Body Set Screw   |
| 7071   |   | " " " " Clamping Washer  |
| 217 E  |   | " " " " " " Screw  |
| 54456  |   | Feed Roll (lower) Eccentric (adjustable) complete,<br>Nos. 217E, 1103C, 7071 and two 443C                                    |
| 1103 C |   | Feed Roll (lower) Eccentric Regulating Screw   |
| 127514 | 2 | " " " " Guard with 208C  |

| No.       | Name   |
|-----------|--|
| 208 C : 2 | Feed Roll (lower) Guard Clamping Screw   |
| 127515    | " " " " Shaft  |
| 127516    | " " " " " Bracket with 624C  |
| 448 C     | " " " " " Set Screw  |
| 624 C     | " " " " " Set Screw  |
| 435 C 2   | " " " Set Screw  |
| 127532    | " " (upper) 1 1/4 in. wide, with two 435C, for 127936  |
| 127533    | Feed Roll (upper) 2 in. wide, with two 435C  |
| 127534    | Feed Roll (upper) Bar  |
| 127935    | " " " " Bracket with 453C  |
| 127936    | Feed Roll (upper) Bar Bracket complete, for general work, Nos. 72D, 194D, 226J, 866C, 913D, 1330C, 1876, 11193, 23404, 127534, 127536, 127542, 127543, 127544, 127935 and 127939 |
| 1193 E    | Feed Roll (upper) Bar Bracket Screw (lower)  |
| 50267 E   | " " " " " " (upper)  |
| 127536    | " " " " Collar with 448C, for 127936   |
| 1876      | " " (upper) Bar Collar Roller and Screw Stud   |
| 448 C     | " " " " " Set Screw  |
| 23404     | " " " " Spring   |
| 127537    | " " " Bell Crank   |
| 64 D      | " " " " " Hinge Screw  |
| 1620 E    | " " " " " " " Nut  |
| 127543    | " " " Lifter   |
| 866 C     | " " " " Hinge Screw  |
| 127939    | " " " " Link   |
| 74 D      | " " " " " Connecting Screw   |



| No.     | Name  |
|---------|---|
| 72 D    | Feed Roll (upper) Lifter Link Hinge Screw                 |
| 127545  | " " " " " Spring  |
| 226 J   | " " " " " Screw   |
| 11193   | " " " " " Steady Pin                                      |
| 194 D   | " " " " " Stop Screw                                      |
| 1330 C  | " " " " " Stop Screw                                      |
| 913 D   | " " " " Pressure Regulating Thumb Screw                   |
| 435 C 2 | " " " " Set Screw   |
| 127546  | " " " " Shaft for 1 1/4 in. Feed Roll                     |
| 127547  | " " " " " 2 in. Feed Roll                                 |
| 127538  | " " " " Bracket for 1 1/4 in. Feed Roll                   |
| 127540  | " " " " " 2 in. Feed Roll                                 |
| 127542  | " " " " Shaft Bracket Guide Pin                           |
| 453 C   | " " " " " " " Set Screw                                   |
| 127950  | Looper  |
| 61264   | " Carrier with two 5037SE                                 |
| 61474   | " " Packing   |
|         | Note: When ordering No. 61474 state thickness required.   |
| 127746  | Looper Carrier Rock Shaft with 177C                       |
| 61461   | Looper Carrier Rock Shaft 127746 with 61361               |
| 127790  | " " " " Connection with two each 171E, 1057E and 1485E    |
| 133131  | Looper Carrier Rock Shaft Connection 127790 with 133130   |
| 133130  | Looper Carrier Rock Shaft Connection Ball Stud for 133131 |
| 177 C   | Looper Carrier Rock Shaft Connection Ball Stud Set Screw  |
| 171 E 2 | Looper Carrier Rock Shaft Connection Cap (lower) Screw    |

| No.      | Name  |
|----------|---|
| 1485 E 2 | Looper Carrier Rock Shaft Connection Cap (upper) Screw (left end)       |
| 1057 E 2 | Looper Carrier Rock Shaft Connection Cap (upper) Screw                  |
| 61361    | Looper Carrier Rock Shaft Hinge Pin (eccentric)                         |
| 61031    | " " " " " " Bushing   |
| 1299 C   | " " " " " " Set Screw   |
| 127760   | Looper Carrier Rock Shaft Hinge Pin Handle with 453C and 1299C          |
| 133121   | Looper Carrier Rock Shaft Hinge Pin Handle 127760 with 1094F and 133124 |
| 1299 C   | Looper Carrier Rock Shaft Hinge Pin Handle Position Screw               |
| 453 C    | Looper Carrier Rock Shaft Hinge Pin Handle Set Screw                    |
| 133123   | " " " " " " Lock Stud   |
| 133124   | " " " " " " " " Plate   |
| 1094 F   | " " " " " " " " " Screw   |
| 133125   | Looper Carrier Rock Shaft Hinge Pin Lock Stud Spring                    |
| 717 C    | " " " " " " Position Screw  |
| 1698 E   | " " " " " " " " Nut   |
| 51279 C  | Looper Carrier Screw  |
| 1698 E   | " " " " Nut   |
| 127597   | " Driving Shaft with two 61039  |
| 127900   | " " " 127597 with 127745  |
| 133126   | " " " Bracket   |
| 948 E    | " " " " Screw   |
| 133127   | Looper Driving Shaft Bushing  |
| 51322 C  | " " " " Set Screw   |
| 133128   | " " " Hole Plug   |

From the library of: Diamond Needle Corp

| No.     | Name  |
|---------|---|
| 46200   | Looper Driving Shaft Oil Pad (felt) for oiling<br>127597                  |
| 12147   | Looper Driving Shaft Oil Pad (felt) for oiling<br>61361 and 127597        |
| 2117    | Looper Driving Shaft Pin  |
| 61039   | 2 " " " Plug  |
| 1498 C. | " " " Set Screw   |
| 61279   | " Protector Stud  |
| 453 C   | 2 " " " Set Screw   |
| 50379 F | 2 " Set Screw   |
| 127929  | Machine Pulley (single belt groove) 3 5/16 in. pulley,<br>with two 51283C |
| 51283 C | 2 Machine Pulley Set Screw  |
| 57244   | Needle Bar (hollow)   |
| 127548  | " " 57244 with 127549   |
| 38456   | " " Bushing (lower)   |
| 1133 E  | " " " " Set Screw   |
| 133085  | " " " (upper)   |
| 1133 E  | " " " " Set Screw   |
| 133086  | " " Connecting Link   |
| 133087  | " " " " 133086 with 133088  |
| 57940   | Needle Bar Connecting Link Hinge Stud                                     |
| 1520 E  | " " " " " " Nut   |
| 133088  | " " " " Oil Pad (felt)  |
| 133129  | " " " " 133087 with 57940 and<br>133113                                   |
| 133113  | Needle Bar Connecting Stud with 50379C and two 187E                       |
| 187 E   | 2 " " " " Clamping Screw  |
| 127549  | " Clamp with two 50014F   |

From the library of: Diamond Needle Corp.

| No.       | Name                                     |
|-----------|--|
| 57319     | Needle Guard (left) with 50239C          |
| 57320     | " " (right) with 50239C                  |
| 57251     | " " Bar                                  |
| 127753    | " " " Bracket (left) with 440C           |
| 177 C     | " " " " " Screw                          |
| 127754    | " " " " (right) with 440C                |
| 177 C     | " " " " " Screw                          |
| 57254     | " " " Holder                             |
| 29627     | " " " Dowel Pin                          |
| 50154 D 2 | " " " " Screw                            |
| 440 C 2   | " " " Set Screw                          |
| 50239 C 2 | " " " Set Screw                          |
| 50014 F 2 | " " " Set Screw                          |
| 57255     | Presser Bar                              |
| 133090    | " " Bushing (lower)                      |
| 1133 E    | " " " " Set Screw                        |
| 38456     | " " " (upper)                            |
| 1133 E    | " " " " Set Screw                        |
| 127836    | " " Guide                                |
| 61049     | " " " Connecting Stud with 453C          |
| 453 C     | " " " " " Set Screw                      |
| 133133    | " " Lifter                               |
| 57258     | " " " Hinge Pin                          |
| 447 C     | " " " " " Set Screw                      |
| 1872      | " " " Roller and Stud                    |
| 194 J     | " " " Stop Screw                         |
| 127551    | " " " Lifting Bracket with 460C and 1872 |

| No.     | Name  |
|---------|---|
| 127841  | Presser Bar Lifting Lever   |
| 61075   | " " " " Connecting Stud   |
| 460 C   | " " " " " " Set Screw   |
| 61167   | " " " " Extension   |
| 162 J 2 | " " " " " Screw   |
| 57978   | " " " " Spring  |
| 802 D   | " " " " Hinge Screw   |
| 38467   | Presser Bar Spring (flat)   |
| 38468   | " " " Stud  |
| 18055   | " Foot Hinge Pin  |
| 61373   | " " Plate   |
| 61371   | " " Shank   |
| 61246   | Presser Foot (hinged) complete for general work<br>Nos. 18055, 61371 and 61373    |
| 176 J   | Presser Foot Screw  |
| 574 W   | Pressure Regulating Thumb Screw   |
| 1539 W  | " " " " Lock Nut  |
| 133097  | Slack Thread (upper) Controller Body  |
| 127961  | " " " " Spring  |
| 127739  | " " " " " Collar  |
| 211 E   | " " " " " Screw   |
| 133098  | Slack Thread (upper) Controller complete, Nos. 211E,<br>127739, 127961 and 133097 |
| 211 E   | Slack Thread (upper) Controller Screw   |
| 127963  | " " Regulator   |
| 127758  | " " " Holder with 624C  |
| 61281   | " " " " Crank with 187E and<br>1963   |
| 187 E   | Slack Thread Regulator Holder Crank Clamping Screw                                |

| No.     |   | Name  |
|---------|---|---|
| 1963    |   | Slack Thread Regulator Holder Crank Roller and Stud |
| 624 C   |   | " " " Set Screw                                     |
| 2102    | 4 | Tension (under thread) Disc                         |
| 51570 C | 2 | " " " Regulating Thumb Nut                          |
| 50326 C | 2 | " " " Screw Stud                                    |
| 59539   | 2 | " " " " " 50326C with 51570C                        |
| 59534   | 2 | " " " Spring  |
| 59537   | 2 | " " " " Bushing (large)                             |
| 59538   | 2 | " " " " " (small)                                   |
| 57076   | 2 | " " " Thread Guide                                  |
| 2102    | 4 | Tension (upper thread) Disc                         |
| 51570 C | 2 | " " " Regulating Thumb Nut                          |
| 50326 C | 2 | " " " Screw Stud                                    |
| 59539   | 2 | " " " " " 50326C with 51570C                        |
| 59535   | 2 | " " " Spring  |
| 59537   | 2 | " " " " Bushing (large)                             |
| 59538   | 2 | " " " " " (small)                                   |
| 57976   | 2 | " " " Thread Guide                                  |
| 127971  |   | " Plate with 439D                                   |
| 439 D   |   | " " Position Stud                                   |
| 57265   |   | " " Spring  |
| 665 E   |   | " " " Screw   |
| 32572   | 2 | " Releasing Disc                                    |
| 57266   |   | " " Lever   |
| 61164   |   | " " " Connection                                    |
| 193 C   | 2 | " " " " Set Screw                                   |
| 788 D   |   | " " " Hinge Screw                                   |

| No.    | Name   |
|--------|--|
| 127377 | Tension Releasing Pin (large))   |
| 133066 | " " " (small))   |
| 127978 | " " Plate  |
| 691 C  | " " " Screw  |
| 127806 | Thread (under) Eyelet (back)) with 127812  |
| 691 J  | " " " " Screw  |
| 127812 | " " " " Thread Guide   |
| 127984 | " " " (front)  |
| 127986 | " " " " Post   |
| 127987 | " " " " " 127986 with 203J and 127984  |
| 448 C  | Thread (under) Eyelet (front) Post Set Screw (left)  |
| 430 C  | " " " " " " " (right)  |
| 203 J  | " " " " Screw  |
| 61103  | " " Protector  |
| 397 F  | " " " Screw  |
| 127989 | " " Take-up  |
| 190 B  | " " " Screw  |
| 127990 | " " " Driving Crank with 14543   |
| 1454 E | Thread (under) Take-up Driving Crank Clamping Screw  |
| 1131 C | " " " " " Hinge Screw  |
| 1520 E | " " " " " " " Nut  |
| 127991 | " " " Eccentric with two 4460  |
| 127992 | Thread (under) Take-up Eccentric Connection with 50240E, 127951, 127994, 127995 and two 127843 |
| 127993 | Thread (under) Take-up Eccentric Connection 127992 with 127991                                 |
| 127848 | 2 Thread (under) Take-up Eccentric Connection Oil Cup  |
| 127994 | " " " " " " " Oil Pad (back) braided cotton  |

| No.     | Name   |
|---------|--|
| 127851  | Thread (under) Take-up Eccentric Connection Oil Cup<br>Oil Pad (front) braided cotton    |
| 50240 E | Thread (under) Take-up Eccentric Connection Oil Cup Oil<br>Plug Screw                    |
| 127995  | Thread (under) Take-up Eccentric Connection Oil Cup<br>Oil Plug Screw Washer (leather)   |
| 446 C   | Thread (under) Take-up Eccentric Set Screw   |
| 127996  | " " " Eyelet (left)  |
| 203 E   | " " " " " Set Screw  |
| 127997  | " " " " (right)  |
| 203 E   | " " " " " Set Screw  |
| 127998  | " " " Packing (.015" thick)  |
| 127999  | " " " " (.025" Thick)  |
| 128000  | " " " " (.060" Thick)  |
| 133001  | " " " Shaft  |
| 133002  | " " " " Bracket with two 203E  |
| 133003  | Thread (under) Take-up Shaft Bracket complete, Nos.<br>127990, 133001, 133002 and 133004 |
| 575 E   | Thread (under) Take-up Shaft Bracket Screw (left)  |
| 129 E   | " " " " " " (right)  |
| 133004  | Thread (under) Take-up Shaft Collar with two 446C  |
| 446 C 2 | " " " Shaft Collar Screw   |
| 133005  | " (upper) Eyelet (back)  |
| 178 C   | " " " " " Set Screw  |
| 133017  | " " " Nipper Body  |
| 131039  | " " " " Hole Plug  |
| 50554 C | " " " " " Set Screw  |
| 68130   | " " " " Disc (inside)  |
| 68131   | " " " " " Washer (fiber)   |



| No.  | Name  |
|--|---|
| 133018   | Thread (upper) Nipper Disc (outside)  |
| 1698 C   | " " " " " Nut   |
| 34099  | " " " " " Washer  |
| 68133  | " " " Roller  |
| 68134  | " " " " Hinge Pin   |
| 133019   | " " " Spacing Collar  |
| 133023   | " " " Stud  |
| 133024   | " " Nipper Stud complete, Nos. 68133, 68134 and 133023  |
| 13218  | Thread (upper) Nipper Stud Spring   |
| 133025   | Thread (upper) Nipper complete, Nos. 1698C, 13218, 34099, 68130, 68131, 133017 to 133019 and 133024 |
| 133029   | Thread (upper) Nipper Thread Guide  |
| 207 J  | " " " " " Screw   |
| 133030   | " " Oil Cup   |
| 133031   | " " " " 133030 with 133032  |
| Note: No. 133031 is not regular fitting of machine, if desired it must be so stated on order |   |
| 133032   | Thread (upper) Oil Cup Oil End (felt)   |
| 50004 W  | " " " " Screw   |
| 133033   | " " Take-up   |
| 50379 C  | " " " Set Screw   |
| 61496  | Throat Plate for 61495  |
| 127553   | Throat " " 127505   |
| 691 F 2  | Throat Plate Screw  |