

# Singer 127-1

HISTORICAL COPY

DO NOT REMOVE

**LIST OF PARTS  
COMPLETE**



**Machine No. 127-1**

---

**THE SINGER MANUFACTURING COMPANY**

# HISTORICAL COPY

NUMBERING DEPARTMENT

MAY 9, 1912

## DO NOT REMOVE

### LIST OF PARTS COMPLETE

FOR

# MACHINE NO. 127-1

For family use, vibrating shuttle with shuttle ejector.

*55501	Arm with 443A and 8206.....
2002	" Dowel Pin.....
8203	" Rock Shaft with 122E.....
122E	" " " Adjusting Screw.....
8204	" " " Centre (upper).....
301A	" " " Screw Centre.....
1508E	" " " " Nut.....
649E	" Screw.....
8341	" Shaft.....
8206	" " Bushing.....
443A	" " " Set Screw.....
8300	" Side Cover.....
286D	" " " Thumb Screw.....
2007	" Spool Pin.....
8879	" " " Washer (cloth).....
15282	Balance Wheel, 2½ in. pulley.....
*3328	Bed.....
256B	Clamp Stop Motion Clamp Screw.....
248A	" " " " Stop Screw.....
2020	" " " " Washer.....
*15312	" " " " Flanged Bushing.....
15313	" " " " " 15312 with two 462C.....
2022	Clamp Stop Motion Flanged Bushing Pin.....
462C	" " " " " Set Screw.....
15314	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15313.....
8210	Face Plate with 2827.....
219A	" " " Screw.....
2827	" " " Thread Guard with 8505.....
8505	" " " " Rivet.....
32562	Feed Cam with 1285C.....
1285C	" " " Set Screw.....
8321	" Dog, four teeth at right of needle (square corners).....



**BOBBIN WINDER (Automatic)**

8342	Bobbin Winder Back Centre.....
8256	" " " " Head.....
8343	" " " " Spring.....
8344	" " Bracket (belt cover).....
158B	" " " Screw.....
8257	" " Cam.....
219A	" " " Screw.....
8345	" " Frame.....
80272	" " Friction Washer.....
50101B	" " Hinge Screw.....
1718H	" " " " Nut.....
15287	" " Friction Ring (rubber).....
50102A	" " Spindle.....
15288	" " Pulley.....
8346	" " Thread Guide.....
92B	" " " Hinge Screw.....
8260	" " " Spring.....
8261	" " Worm Wheel.....
2749	" " Friction Washer.....
50104B	" " Screw Stud (eccentric).....
1718H	" " " " Nut.....
8347	Bobbin Winder (automatic) complete, Nos. 92B, 219A, 2749, 8256, 8257, 8260, 8261, 8342 to 8346, 15287, 15288, 50101B, 50102A, 50104B, 80272 and two 1718H.....

**HAND ATTACHMENT**

8377	Body.....
33647	" Bracket.....
183D	" " Screw.....
8380	Crank Handle (wood).....
8433	" " Spindle.....
8434	" " " 8433 with 8382.....
8382	" " Washer.....
8280	" Hinge Pin.....
8435	" Lever.....
8281	" Lock Pin.....
8282	" " Spring.....
8436	Crank complete, Nos. 8380, 8434 and 8435.....
33642	Driver.....
33643	" Finger.....
83644	" " 33643 with 8390, 8391 and 33645.....
8386	" " Hinge Pin.....

8387	Driver Finger Lock Pin.....
8388	" " " " Spring.....
33645	" " Sheath (leather).....
8390	" " " Plate.....
8391	" " " Staple.....
8392	Gear with 8281 and 8282.....
8393	" Cover.....
399A	" " Screw.....
659D	" Screw Stud.....
8394	Pinion.....
2532	" Dowel Pin.....
660D	" Screw Stud.....
33646	Hand Attachment complete, Nos. 137E, 659D, 660D, 2532, 8280, 8377, 8386 to 8388, 8392 to 8394, 8436, 33642, 33644, 33647 and two each 183D and 399A.....
137E	Hand Attachment Screw.....