

SINGER

188K

NUMERICAL LIST OF PARTS FOR MACHINE I88K

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
76	Knee Lifter Lifting Rod Screw	1518	Feed Lifting Rod Nut	52045	Arm Oil Tube Packing	99662	Feed Reverse Lever Return Spring
NN128	Tension Thumb Nut	1518	Feed Regulator Nut	52083	Thread Take-up Spring Regulator	99663	Needle Bar
145	Rotating Hook Gear Case Screw	1519	Feed Bar Nut	52130	Take-up Lever Eyelet Bushing	99664	Needle Bar Crank
145	Feed Lifting Rod Cap Screw	1520	Presser Bar Screw Nut	52237	Hook Bobbin Case, complete	99665	Presser Bar
157	Feed Lifting Clamping Screw	1521	Knee Lifter Rod Lock Nut	52280	Feed Lifting Cap Oil Pad	99671	Rotating Hook Shaft
157	Feed Rock Shaft Crank Screw	1813	Feed Lifting Roller and Stud	52454	Thread Retainer	99672	Rotating Hook Shaft Bushing (back)
158	Bobbin Winder Bracket Screw	2102	Tension Disc	55623	Bobbin	99673	Rotating Hook Shaft Bushing (front)
161	Feed Regulator Bracket Screw	2824	Bed Slide Spring	56019	Bed Slide, complete	99674	Slack Thread Regulator
178	Knee Lifter Bracket Screw	5596	Knee Lifter Bell Crank	56024	Feed Connecting Link	99678	Thread Guard
190	Bobbin Winder Arm Screw	5601	Knee Lifter Hinge Pin	56027	Feed Lifting Rock Shaft	99679	Take-up Lever Hinge Pin
193	Bobbin Winder Bracket Screw	8879	Arm Spool Pin Washer	56028	Feed Lifting Rock Shaft, complete	99680	Thread Take-up, complete
225	Slack Thread Adjusting Screw	11170	Presser Bar Spring Washer	56029	Feed Lifting Rock Shaft Crank	99681	Bobbin Winder, complete
248	Clamp Stop Motion Stop Screw	12329	Tension Releasing Lever Spring	56032	Feed Regulating Stud Head	99682	Knee Lifter Lifting Lever
256	Clamp Stop Motion Clamp Screw	12398	Tension Releasing Hinge Pin	56033	Feed Regulating Stop Pin	99685	Rotating Hook Shaft Oil Pad
313	Feed Bar Screw Centre	12403	Arm Spool Thread Eyelet	56034	Feed Regulating Stud Lock Pin	99686	Arm Shaft Bushing Oil Pad
375	Feed Connecting Hinge Screw	12416	Knee Lifter Rod Joint	56035	Feed Regulating Stud Lock Pin Spring	99687	Arm Shaft Bushing Oil Tube
375	Feed Forked Hinge Screw	12431	Bed Slide	56039	Feed Rock Shaft	99690	Set Of Mated Gears
375	Feed Lifting Rod Hinge Screw	15072	Bobbin Winder Position Pin	56040	Feed Rock Shaft, complete	99691	Tension Flange Washer
375	Feed Regulator Hinge Screw	15287	Bobbin Winder Friction Ring	56042	Needle Bar Bushing (upper)	99692	Tension, complete
443	Arm Shaft Bushing Set Screw	15288	Bobbin Winder Pulley	56044	Needle Clamp	99693	Tension Screw Stud
443	Rotating Hook Set Screw	24040	Needle Bar Connecting Link	56046	Presser Bar Spring	105046	Bobbin Winder Frame
443	Rotating Hook Bushing Set Screw	24041	Needle Bar Connecting Stud	56056	Tension Releasing Lever	105047	Bobbin Winder Spindle
448	Thread Take-up Pin Set Screw	24131	Arm Oil Tube	56065	Throat Plate	125326	Bobbin Winder Tripping Arm
448	Thread Take-up Regulator Set Screw	24894	Needle Bar Connecting Link with Stud	56070	Arm Shaft Position Pin	125395	Bobbin Winder Tension Bracket
453	Presser Bar Set Screw	29532	Needle Bar Oil Cup	56071	Knee Lifter Lever Bracket	125396	Bobbin Winder Tension Bracket, complete
SS551	Feed and Feed Lifting Set Screw	29633	Feed Rock Shaft Crank	56072	Knee Lifter Bell Crank Bracket	125462	Bobbin Winder Stop Latch Spring
SS552	Feed and Feed Lifting Position Screw	32574	Tension Releasing Pin	56073	Knee Lifter Bell Crank Spring	125476	Bobbin Winder Bracket
624	Thread Retainer Set Screw	32618	Clamp Stop Motion Flanged Bushing	56074	Knee Lifter Bell Crank, complete	127323	Needle Bar Thread Guard
647	Arm Shaft Gear Case Screw	32619	Clamp Stop Motion, complete	56076	Knee Lifter Lever Link	140138	Bobbin Winder Tension Screw
691	Throat Plate Screw	32755	Face Plate Thread Guard	56077	Knee Lifter Lever Link Rivet	140184	Rotating Hook Drain Plug
725	Bed Slide Spring Screw	32758	Thread Take-up Spring	56104	Feed Rock Shaft Connecting Rod	140545	Needle Clamp Screw
SS744	Tension Screw Stud	36555	Thread Cutter and Holder	56105	Feed Rock Shaft Connecting Rod Cap	140706	Needle Bar Clamping Screw
775	Needle Bar Cap Screw	45268	Bobbin Winder Stop Latch	66601	Bobbin Winder Frame Spring	142005	Rotating Hook Grease Fitting
794	Needle Bar Adjusting Screw	45339	Tension Regulating Engaging Pin	66670	Bobbin Winder Frame	143014	Arm Shaft Bevel Gear (lower)
866	Knee Lifter Hinge Screw	45847	Bobbin Tension Spring	99601	Feed Dog	143015	Arm Shaft Bevel Gear (upper)
1036	Thread Take-up Position Screw	45864	Tension Indicator Flange	99615	Feed and Feed Lifting Eccentric	143081	Rotating Hook Shaft Bevel Gear
1053	Rotating Hook Guard Screw	45866	Tension Indicator	99616	Feed Forked Connection	143295	Set of Mated Gears
1058	Presser Bar Lifter Screw	45869	Tension Spring	99624	Feed Bar	143346	Rotating Hook Bobbin Case Holder
1065	Needle Bar Crank Screw	45874	Face Plate Guard	99625	Needle Bar Bushing	144790	Rotating Hook Gear Case, complete
1082	Pressure Regulating Thumb Screw	45915	Bobbin Tension Disc	99627	Arm Oil Tube	161066	Presser Foot
1120	Feed Regulator Set Screw	45916	Bobbin Tension Disc Washer	99634	Thread Take-up Crank	166035	Thread Take-up Lever, complete
1120	Feed Reverse Set Screw	50053	Arm Side Cover Thumb Screw	99635	Arm Oil Tube	171502	Stop Motion Clamp Washer
1133	Arm Shaft Bushing Set Screw	50053	Face Plate Thumb Screw	99636	Arm Oil Tube	173548	Hand Wheel
1133	Needle Bar Set Screw	50117	Feed Dog Screw	99637	Arm Shaft Oil Tube	173616	Face Plate Thread Guard Rivet
1133	Needle Bar Bushing Set Screw	50190	Presser Foot Thumb Screw	99643	Arm Shaft	174036	Feed Regulator Spring Bracket
1143	Feed Reverse Set Screw	50191	Feed Lifting Rock Shaft Screw Centre	99644	Arm Shaft Bevel Gear	174042	Rotating Hook
1148	Clamp Stop Motion Set Screw	50191	Feed Rock Shaft Screw Centre	99645	Arm Shaft Bevel Gear Case	174043	Rotating Hook
1253	Rotating Hook Set Screw	50192	Feed Regulating Stud	99646	Arm Shaft Flanged Bushing (back)	174044	Rotating Hook
1259	Arm Shaft (horizontal) Gear Set Screw	50193	Feed Regulating Cap Screw	99647	Arm Shaft Flanged Bushing (front)	174045	Rotating Hook
1259	Arm Shaft Gear (lower) Set Screw	50305	Tension Stud Set Screw	99648	Arm Shaft	174046	Rotating Hook, complete
1259	Arm Shaft Gear (upper) Set Screw	51303	Bobbin Winder Stop Latch Screw	99649	Arm Shaft Flanged Bushing (lower)	189802	Arm Shaft Oil Tube
1259	Rotating Hook Gear Set Screw	51319	Bobbin Winder Frame Hinge Screw	99650	Arm Shaft Flanged Bushing (upper)	270874	Rotating Hook Thread Guard
1259	Thread Take-up Crank Set Screw	51354	Face Plate Screw	99651	Arm Side Cover	270876	Rotating Hook Section
1367	Rotating Hook Section Screw	52016	Presser Bar Lifter	99654	Arm Top Cover		
1513	Feed Lifting Screw Centre Nut	52022	Thread Take-up Lever	99657	Face Plate		
1513	Feed Rock Shaft Screw Centre Nut	52024	Thread Take-up Lever Link	99659	Feed Regulator		
1518	Feed Connecting Screw Nut	52028	Knee Lifter Connecting Rod	99660	Feed Regulator Hinge Stud		
1518	Feed Forked Hinge Screw Nut			99661	Feed Reverse Lever		