


SINGER
221-1/221K1/221K4/221K5

List of Parts-Machines Nos. 221-1, 221K1, 221K4 and 221K5

193898
(196326 AND 199005 SWITCH, 221K4)
(45948, 221K5)



45925

193891
(221-1, 221K1, 221K5)