


**SINGER**  
261U11,U12,U13

# SINGER<sup>®</sup>

261U/11/12/13  
PARTS




● When ordering, state color required.  
 ■ When ordering, state gauge required.

\* A Trademark of THE SINGER COMPANY  
 Copyright © 1987 SINGER SEWING MACHINE COMPANY  
 All Rights Reserved Throughout The World


Form U3433 (Rev. 2881)  
 Part No. 409820-002 Rev. 11  
 Printed in Japan

170  
 420-  
 169-  
 415-



From the library of: Diamond Needle Corp

372827  
Per. Marquet



From the Library of: **Diamond Needle Co.**

Use **SINGER** OIL, "TYPE A" or "Type C". Use "TYPE C" OIL when an oil is desired which will produce minimum stain on fabrics even after long period of storage.

Twenty One  
 Screws

LIST OF PARTS FOR 261-11, 12 and 13 MACHINES

CODE	PART NO.	DESCRIPTION	MACHINE VARIETY
1	143646	Bed Cover Reinforcing Plate Gasket	261-11, 12, 13
2	143614	Bed Oil Shield (felt, lower)	261-11, 12, 13
3	143552	Bushing (back) complete, 143485 with 143551	261-11, 12, 13
4	143485	Bushing (back) complete, 143485 with 143551	261-11, 12, 13
5	143551	Oil Seal (Rubber)	261-11, 12, 13
6	143	Set Screw	261-11, 12, 13
7	143486	Bushing (front)	261-11, 12, 13
8	545407	Ball Screw Stud Nut	261-11, 12, 13
11	416005	Clamping Screw	261-11, 12, 13
12	143484	Looper Holder Shaft	261-11, 12, 13
13	139509	Gasket (3)	261-11, 12, 13
14	416042	Oil Plug (3)	261-11, 12, 13
15	454 (830)	Set Screw	261-11, 12, 13
16	50225 (809)	Screw (2)	261-11, 12, 13
18	139181	Thread Cutter	261-11, 12, 13
19	143524	Thread Cutter Support and Guide	261-11, 12, 13
20	456	Set Screw	261-11, 12, 13
21	416144	Adjusting Screw	261-11, 12, 13
23	139120	Looper Thread Guide Bracket Holder	261-11, 12, 13
24	416149	Screw Stud (2)	261-11, 12, 13
25	143480	Position Pin (2)	261-11, 12, 13
26	143467	Looper Gate (left) 143466 with 143470 and 51282(819), for Throat Plates 3/4 inch wide	261-11, 12, 13
27	143470	Looper Gate (left) 143468 with 143470 and 51282(819), for Throat Plates 7/8 inch wide	261-13
28	51282(819)	Lock Spring	261-11, 12, 13
29	143465	Looper Gate (left), for Throat Plates 3/4 inch wide	261-11, 12, 13
29	143465	Looper Gate (left), for Throat Plates 7/8 inch wide	261-13
29	143465	Looper Gate (left), for Throat Plates 7/8 inch wide	261-13
30	143483	Looper Holder Bushing Eccentric (2)	261-11, 12, 13
31	46276	Looper Position Pin (2)	261-11, 12, 13
32	416095	Looper Holder Clamping Screw (2)	261-11, 12, 13
33	416089	Looper Holder (front)	261-11, 12, 13
34	416079	Looper Holder (back)	261-11, 12, 13
35	440393	Looper Clamping Screw (2)	261-11, 12, 13
36	416127	Driving Arm Connection with four 45432	261-11, 12, 13
37	416132	Cap Screw (4)	261-11, 12, 13
39	1047(819)	Set Screw	261-11, 12, 13
41	32355	Looper Driving Arm complete	261-11, 12, 13
42	416027	Looper Holder Shaft Collar with 416005	261-11, 12, 13
43	416005	Clamping Screw	261-11, 12, 13
44	416(839)	Set Screw	261-11, 12, 13
45	139074	Looper Eccentric Connection Slide Block	261-11, 12, 13
46	416148	Looper Eccentric Connection Slide Block Stud	261-11, 12, 13
47	416126	Bushing Cover Screw (4)	261-11, 12, 13
48	416049	Bed Cover Hole Plug Screw	261-11, 12, 13
49	143435	Bed Cover Hole Plug Screw Gasket	261-11, 12, 13
50	140295	Bed Cover Screw (14)	261-11, 12, 13
51	416068	Bed Cover	261-11, 12, 13
52	143434	Bed Cover Gasket (Cork)	261-11, 12, 13
53	445023	Tension Regulating Thumb Nut (2)	261-11, 12, 13
54	143657	Tension Spring Bushing (Large) (2)	261-11, 12, 13
55	131741	Tension Spring (2)	261-11, 12, 13
55	143656	Tension Spring (2)	261-11, 12, 13
56	492538	Tension Spring Bushing (small) (2)	261-11, 12, 13
57	32322	Tension Releasing Disc (2)	261-11, 12, 13
58	2102	Tension Disc (4)	261-11, 12, 13
59	416017	Tension Screw Stud (2)	261-11, 12, 13
60	54988	Tension Releasing Pin (2)	261-11, 12, 13
61	131696	Tension Thread Guide (2)	261-11, 12, 13
62	146776	Presser Bar Lifting Bracket Lifter	261-11, 12, 13
63	307(819)	Presser Bar Lifting Bracket Lifter Hinge Screw	261-11, 12, 13
64	416081	Presser Bar Lifting Lever	261-11, 12, 13
65	306(819)	Presser Bar Lifting Lever Hinge Screw	261-11, 12, 13
66	416134	Tension Screw Stud 416011 (2) with 416021 (2)	261-11, 12, 13
67	504376	Presser Bar Lifting Lever Extension Screw (2)	261-11, 12, 13
68	416230	Hinge Screw (2)	261-11, 12, 13
69	146620	Tension Releasing Shaft Crank Connection Link	261-11, 12, 13
70	416021	Tension Releasing Shaft Crank with 504134	261-11, 12, 13
72	504134	Tension Releasing Shaft Crank Set Screw	261-11, 12, 13
73	149511-001	Presser Bar Lifting Lever Spring	261-11, 12, 13
75	1443(802)	Lap Seam Feller Clamping Plate Screw (2)	261-11, 12, 13
76	121449	Lap Seam Feller Clamping Plate	261-11, 12, 13
77	416036	Lap Seam Feller Slide	261-11, 12, 13
78	68003	Tension Releasing Shaft	261-11, 12, 13
79	121596	Lap Seam Feller, Adjustable	261-11, 12, 13
80	161427	Lap Seam Feller with yielding lower scroll and adjustable top scroll	261-12
80	121669	Lap Seam Feller, Adjustable	261-11, 12, 13
80	229	Screw (4)	261-11, 12, 13
81	140064(809)	Face Plate Screw (lower) (4)	261-11, 12, 13
82	154795	Looper Thread Guide Screw	261-11, 12, 13
83	416086	Looper Thread Guide Bracket	261-11, 12, 13
84	143487	Looper Thread Guide	261-11, 12, 13
85	32322	Looper (back) for 1/8 inch gauges	261-11, 12, 13
85	32322	Looper (back) for 1/4 inch gauges	261-11, 12, 13
85	32322	Looper (back) for 5/16 inch and 3/16 inch gauges	261-11, 12, 13
85	32322	Looper (back) for 1/4 inch gauges	261-11, 12, 13
85	32322	Looper (front) for 1/8 inch gauges	261-11, 12, 13
85	32322	Looper (front) for 5/16 inch and 3/16 inch gauges	261-11, 12, 13

From the library of: [www.digitallibrary.org/](http://www.digitallibrary.org/)

LIST OF PARTS FOR 261-11, 12 and 13 MACHINES

CODE	PART NO.	DESCRIPTION	MACHINE VARIETY
327	143612	Arm Rotary Shaft Sprocket Wheel with two each 416014 and 202253	261-11, 12, 13
328	416014	Sprocket Wheel Set Screw (2)	261-11, 12, 13
329	202253	Sprocket Wheel Spring Flange (2)	261-11, 12, 13
330	544332	Bed Rotary Shaft Belt Guard Set Screw (2)	261-11, 12, 13
331	416069	Bed Rotary Shaft Belt Guard with two 544322	261-11, 12, 13
332	143544	Thread Tube (belt guard) with four 139152	261-11, 12, 13
333	416137	Thread Tube (belt guard) Set Screw (3)	261-11, 12, 13
334	139162	Thread Tube (belt guard) Bushing (4)	261-11, 12, 13
335	416046	Bed Rotary Shaft Sprocket Wheel Set Screw (2)	261-11, 12, 13
336	143675	Bed Rotary Shaft Sprocket Wheel with 202253 and two 416046	261-11, 12, 13
337	50608(813)	Plug Screw (2)	261-11, 12, 13
338	139017	Plug Screw Washer (2)	261-11, 12, 13
339	456(830)	Slide Block Stud Set Screw (in 416074)	261-11, 12, 13
340	416074	Loopers Avoiding Eccentric Forked Connection Bracket with 456(830)	261-11, 12, 13
341	143458	Loopers Avoiding Eccentric Forked Connection Slide Block	261-11, 12, 13
342	416073	Loopers Avoiding Eccentric with two 504048	261-11, 12, 13
343	143444	Bed Rotary Shaft Bushing, Flanged (right)	261-11, 12, 13
344	504022(803)	Bed Rotary Shaft Bushing, Flanged (right) Set Screw	261-11, 12, 13
345	416028	Thread (Loopers) Take-up with two 544306	261-11, 12, 13
347	416093	Oil Reservoir complete, Nos. 143509, 143542, 143601, 164133, 164134, 416053, two each 164132, 416008 and three 545109	261-11, 12, 13
348	143542	Oil Reservoir Screen Frame	261-11, 12, 13
349	443509	Oil Reservoir Screen	261-11, 12, 13
350	545109	Oil Reservoir Screen Frame Screw (3)	261-11, 12, 13
351	143508	Oil Reservoir Gasket	261-11, 12, 13
352	966(819)	Oil Reservoir Screw (21)	261-11, 12, 13
353	164134	Oil Reservoir Sight Gauge Window Retainer Gasket (2)	261-11, 12, 13
354	164132	Oil Reservoir Sight Gauge Window	261-11, 12, 13
355	164133	Oil Reservoir Sight Gauge Window	261-11, 12, 13
356	416008	Oil Reservoir Sight Gauge Window Retainer Screw (3)	261-11, 12, 13
357	143601	Sight Gauge Background Disc	261-11, 12, 13
360	416053	Oil Reservoir Drain Plug	261-11, 12, 13
366	416016	Bed Rotary Shaft Screw (right)	261-11, 12, 13
367	139036	Bed Rotary Shaft Belt Guard Cover 139035 with 139037	261-11, 12, 13
369	264715	Bed Rotary Shaft Belt	261-11, 12, 13
369	139037	Belt Guard Cover Gasket (cork)	261-11, 12, 13
371	139035	Belt Guard Cover	261-11, 12, 13
371	416121	Machine Pulley with two 51283(830)	261-11, 12, 13
372	416039	Machine Pulley with two 51283(830)	261-11, 12, 13
372	51283(830)	Machine Pulley Set Screw (2)	261-11, 12, 13
374	545361	Belt Guard Cover Screw (2)	261-11, 12, 13
386	143336	Arm Rotary Shaft Screw Plug (front) Washer	261-11, 12, 13
387	416145	Arm Rotary Shaft Screw Plug (front)	261-11, 12, 13
388	416006	Thread (Loopers) Take-up Cover Position Screw Stud	261-11, 12, 13
389	413521	Thread (Loopers) Thread Tube Cover 143521 with 139171 and two 229(309)	261-11, 12, 13
390	143522	Thread (Loopers) Tube Cover 143522	261-11, 12, 13
391	139167	Thread (Loopers) Tube Bushing (4)	261-11, 12, 13
392	445029	Thread (Loopers) Tube complete with 20995 and four 139167	261-11, 12, 13
393	416118	Arm Rotary Shaft Bevel Gear (right hand spiral) with 549084 and two 545068	261-11, 12, 13
394	594956	Slide Block Guide Screw Washer (2)	261-11, 12, 13
395	430(830)	Tension (Loopers) Body Set Screw	261-11, 12, 13
396	146609	Presser Bar Lifting Lever Extension	261-11, 12, 13
397	143654	Arm Rotary Shaft Sprocket Wheel Oil Retaining Ring	261-11, 12, 13
398	143682	Oil Return Tube	261-11, 12, 13
399	133292	Oil Reservoir Tube Head and Screen	261-11, 12, 13
400	440103	Bed Rotary Shaft Bushing (left) Oil Tube, with 143124 and 416064	261-11, 12, 13
402	158045	Arm Shaft Sprocket Wheel Spacing Washer	261-11, 12, 13
403	146039	Machine Mounting Bracket (Long) Screw (2)	261-11, 12, 13
403	144475	Needle Bar Connecting Link Screw Cap Disc	261-11, 12, 13
404	175032	Presser Bar Spring Washer	261-11, 12, 13
405	32381	Needle Guard	261-11, 12, 13
406	416014	Needle Guard Holder	261-11, 12, 13
407	416135	Needle Guard Screw	261-11, 12, 13
408	416141	Needle Guard Screw	261-11, 12, 13
415	416038	Arm Hole Plug Screw	261-11, 12, 13
417	139017	Arm Hole Plug Screw Washer	261-11, 12, 13
417	416007	Thread (needle) Take-up Plate Spring Screw	261-11, 12, 13
416	68164	Thread (upper) Take-up plate Spring	261-11, 12, 13
417	54095	Thread (upper) Take-up Plate	261-11, 12, 13
419	337	Thread (needle) Take-up Extension Screw	261-11, 12, 13
420	139196	Thread (needle) Take-up Extension	261-11, 12, 13
421	416031	Tension (needle thread) Regulating Thumb Nut Locking Spring	261-11, 12, 13
422	143628	Thread (needle) Take-up complete, Nos. 54095, 68164, 139196, 416007, 416033	261-11, 12, 13
423	2793-01	Needle (143X825)	261-11
	2793-01	Needle (149X825)	261-12
	3631-05	Needle (1-3X3)	261-13

From the original of the

LIST OF PARTS FOR 26-11, 12 and 13 MACHINES

CODE	PART NO.	DESCRIPTION	MACHINE VARIETY
229	146672	Arm Rotary Shaft Flanged Bushing (front)	26-11, 12, 13
230	145503	Arm Rotary Shaft Bushing (center)	26-11, 12, 13
231	416124	Arm Rotary Shaft Flanged Bushing (center) Set Screw	26-11, 12, 13
232	139111	Needle Barb Connecting Stud Slide Block (wood)	26-11, 12, 13
233	416044	Arm Rotary Shaft Flanged Bushing (front) Set Screw	26-11, 12, 13
234	416119	Arm Rotary Shaft Thrust Collar with two 504134	26-11, 12, 13
235	504134	Arm Rotary Shaft Thrust Collar Set Screw (2)	26-11, 12, 13
236	146633	Thread (needle) Eyelet (side of arm)	26-11, 12, 13
237	139198	Thread (needle) Take-up (auxiliary)	26-11, 12, 13
238	7071	Thread (needle) Eyelet (side of arm) Position Screw Washer	26-11, 12, 13
239	54242	Thread (needle) Take-up (auxiliary) Clamp	26-11, 12, 13
240	416133	Thread (needle) Take-up (auxiliary) Clamp Screw	26-11, 12, 13
241	416008	Thread (needle) Eyelet (side of arm) Position Screw	26-11, 12, 13
243	416125	Thread (needle) Eyelet (side of arm) Position Screw	26-11, 12, 13
244	143503	Oil Pipe complete, No. 143503 with 143065 and 416062	26-11, 12, 13
245	416062	Oil Pipe	26-11, 12, 13
246	143065	Oil Pipe Clamping Sleeve Nut	26-11, 12, 13
247	143071	Oil Pipe Clamping Sleeve	26-11, 12, 13
248	146908	Oil Pump Body Position pin (2)	26-11, 12, 13
249	143570	Needle Bar Connecting Stud Slide Block Guide	26-11, 12, 13
250	140180(809)	Thread Guide (front of arm)	26-11, 12, 13
252	144645	Thread Guide (front of arm) Screw	26-11, 12, 13
253	416101	Bed Rotary Shaft Bushing (intermediate)	26-11, 12, 13
257	416044	Oil Tube Connection	26-11, 12, 13
258	416083	Set Screw	26-11, 12, 13
259	416082	Tension (Loopers thread) complete, Nos. 416087 two each 143514, 416082 and four 10106	26-11, 12, 13
260	416009	Tension Screw Stud 416051 with 416002 (2)	26-11, 12, 13
261	143914	Tension Regulating Turn Nut (2)	26-11, 12, 13
262	10106	Tension Spring (2)	26-11, 12, 13
263	10106	Tension 2186 Nut	26-11, 12, 13
264	416051	Tension Screw Stud (2)	26-11, 12, 13
265	416097	Looper Thread Set	26-11, 12, 13
266	416136	Oil and Loop Guard Screw (2)	26-11, 12, 13
267	143199	Oil and Loop Guard	26-11, 12, 13
268	143199	Arm Top Cover Screw (2)	26-11, 12, 13
269	416117	Arm Top Cover	26-11, 12, 13
272	146508	Arm Top Cover	26-11, 12, 13
273	416020	Arm Top Cover Jacket	26-11, 12, 13
274	143372	Oil Lead	26-11, 12, 13
275	549084	Arm Rotary Shaft Bevel Gear Position Screw	26-11, 12, 13
276	416061	Arm Shaft (upright) Bevel Gear (upper), left hand spiral with two 545068	26-11, 12, 13
277	545068	Set Screw (2)	26-11, 12, 13
278	416066	Arm Shaft (upright)	26-11, 12, 13
279	147111-901	Arm Shaft (upright) Bushing (upper)	26-11, 12, 13
281	416305	Arm Shaft (upright) Bushing (lower)	26-11, 12, 13
283	416067	Arm Shaft (upright) Collar with two 146068	26-11, 12, 13
284	545183	Oil Pump Body Screw (2)	26-11, 12, 13
285	416111	Oil Pump Body 416112 with three 416065	26-11, 12, 13
286	416113	Oil Pump Body	26-11, 12, 13
287	416090	Oil Pipe with 143124 and 416064	26-11, 12, 13
288	416126	Oil Pipe with 143124 and 416064	26-11, 12, 13
289	416100	Oil Tube complete with two each 143124 and 416064	26-11, 12, 13
290	143659	Bed Rotary Shaft	26-11, 12, 13
291	544306	Thread (Looper) Take-up Set Screw (2)	26-11, 12, 13
292	416263	Oil Pump Impeller	26-11, 12, 13
293	443552	Oil Pump Impeller Locking Screw	26-11, 12, 13
294	146000	Oil Pump Cover	26-11, 12, 13
295	146057	Oil Pump Screen	26-11, 12, 13
296	146653	Oil Pump Screen Frame	26-11, 12, 13
297	139912	Thread (Looper) Thread Tube Cover Hinge Plate (left) 139912 with 23422	26-11, 12, 13
298	139920	Thread (Looper) Thread Tube Cover Hinge Plate (right) Spacing Collar with two 504246	26-11, 12, 13
299	545193	Thread (Looper) Thread Tube Cover Hinge Plate (front) 139920 with 139921	26-11, 12, 13
300	140061(490)	Oil Pump Screen Frame Screw (3)	26-11, 12, 13
301	139170	Cover Hinge Plate Screw (2)	26-11, 12, 13
302	139170	Thread (Looper) Thread Tube Cover Hinge Plate (2)	26-11, 12, 13
303	139171	Cover Hinge Pin (2)	26-11, 12, 13
304	229(309)	Cover Catch	26-11, 12, 13
305	139173	Cover Catch Screw (2)	26-11, 12, 13
306	416030	Cover Lock Spring	26-11, 12, 13
307	416136	Cover Lock Spring Retaining Plate	26-11, 12, 13
308	20995	Cover Lock Spring Screw (2)	26-11, 12, 13
309	416070	Cover Lock Spring Position Spring	26-11, 12, 13
310	504048	Bed Rotary Shaft Bushing (right) Spacing Collar with two 504246	26-11, 12, 13
311	416142	Spacing Collar Set Screw (4)	26-11, 12, 13
312	146790	Arm Rotary Shaft Flanged Bushing (back) Oil Pump Tube Holder Screw	26-11, 12, 13
313	416124	Oil Pump Tube	26-11, 12, 13
314	416124	Arm Rotary Shaft Flanged Bushing (back) Set Screw	26-11, 12, 13
315	146111	Arm Rotary Shaft Flanged Bushing (back)	26-11, 12, 13
316	416133	Thread Guide Straker Screw	26-11, 12, 13
317	146391	Oil Flow Body	26-11, 12, 13
318	143961	Oil Flow Body Jacket (2)	26-11, 12, 13
319	143062	Oil Flow Window	26-11, 12, 13
320	143062	Oil Flow Window	26-11, 12, 13
321	143062	Oil Flow Window	26-11, 12, 13
322	143062	Oil Flow Window	26-11, 12, 13
323	143062	Oil Flow Window	26-11, 12, 13
324	416136	Oil Flow Window Lip Screw (4)	26-11, 12, 13
325	50342(809)	Thread (Looper) Thread Guide Screw (4)	26-11, 12, 13
326	416034	Thread (Looper) Thread Guide Bracket	26-11, 12, 13
327	416142	Guide Bracket Support Screw (upper)	26-11, 12, 13
328	139125	Guide Bracket Support	26-11, 12, 13
329	139125	Guide Bracket Support Screw (lower)	26-11, 12, 13
330	416136	Guide Bracket Support	26-11, 12, 13

S  
26

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14



LIST OF PARTS FOR 261-11, 12 and 13 MACHINES

CODE	PART NO.	DESCRIPTION	MACHINE VARIETY
146	21488	Presser Foot Plate and Yielding Heel Connection	261-11
147	139135	Presser Foot Plate (front)	261-12
148	139281	Thread (Looper) Thread Tube (side of bed)	261-11, 12, 13
149	1251(805)	Feed Dog Screw	261-11, 12, 13
150	443(830)	Feed Bar Hinge Pin Set Screw Lock Nut	261-11, 12, 13
151	545407	Feed Bar Hinge Pin Set Screw Lock Nut	261-11, 12, 13
152	416145	Feed Bar Hinge Pin (eccentric)	261-11, 12, 13
153	139086	Feed Bar Hinge Pin Slide Block	261-11, 12, 13
154	504084	Connection Screw (short)	261-11, 12, 13
155	545385	Connection Screw (Long)	261-11, 12, 13
156	140440(819)	Needle Bar Bushing (upper) Oil Plug Screw	261-11, 12, 13
157	416112	Needle Bar Bushing (upper) Set Screw	261-11, 12, 13
158	1133(830)	Needle Bar Bushing (upper) Set Screw	261-11, 12, 13
160	416105	Arm Rotary Shaft 416097 with 416045, 143236 and 416122	261-12
161	416106	Arm Rotary Shaft 416098 with 416045, 143236 and 416122	261-13
162	416107	Arm Rotary Shaft 416099 with 416045, 143236 and 416122	261-11, 12, 13
163	416122	Needle Bar Connecting Link with 14475, 139533 and 416123	261-11, 12, 13
164	140061	Clamping Screw	261-11, 12, 13
165	416183	Needle Bar Connecting Stud with 140061(805) and 143619	261-11, 12, 13
166	139533	Needle Bar Connecting Link Screw Cap	261-11, 12, 13
167	416097	Arm Rotary Shaft with 504095, 416048 and 504120	261-11
168	416098	Arm Rotary Shaft with 504095, 416048 and 504120	261-12
169	51460	Arm Rotary Shaft with 504095, 416048 and 504120	261-13
170	416033	Needle Bar Crank Position Screw	261-11, 12, 13
171	20799-001	Needle Bar Crank Position Screw	261-11, 12, 13
172	20799-002	Needle Bar Bushing (lower)	261-11, 12, 13
173	1133(830)	Needle Bar Bushing (lower) Set Screw	261-11, 12, 13
174	146573	Needle Bar Bushing (lower) Set Screw	261-11, 12, 13
175	139126	Needle Bar Thread Needle	261-11, 12, 13
176	149233	Needle Clamp Thread Needle	261-11, 12, 13
177	144489	Needle Bar Complete, for 3/16 inch to 3/32 inch gauges, Nos. 139126 and 146573 (NOTE: State gauge required.)	261-11, 12, 13
178	691(806)	Throat Plate Screw (3)	261-11, 12, 13
179	139533-009	Throat Plate for 1/8 inch and 5/16 inch gauges (NOTE: State gauge required.)	261-11, 12, 13
180	22572-012	Throat Plate for 3/16 inch gauge	261-12
181	139541-016	Throat Plate for 1/4 inch gauge (NOTE: State gauge required.)	261-11
182	139389-000	Throat Plate for 3/16 inch to 1/4 inch gauges (NOTE: State gauge required.)	261-13
183	139388-000	Throat Plate for 3/16 inch and 1/4 inch gauges (NOTE: State gauge required.)	261-11, 12, 13
184	416074	Oil Connection	261-11, 12, 13
185	416001	Oil Connection Screw (2)	261-11, 12, 13
186	143459	Slide Block Cover (back)	261-11, 12, 13
187	143460	Slide Block Cover (front)	261-11, 12, 13
188	540030	Forked Connection Crank Clamping Screw	261-11, 12, 13
189	416075	Looper Avoiding Ejectors Forked Connection Crank with 540030	261-11, 12, 13
190	416075	Needle Bar Bushing (lower and upper) Oil Wick complete, Nos. 146703, 146804 and two 146730	261-11, 12, 13
191	416075	Oil Wick Clip (2)	261-11, 12, 13
192	146586	Oil Wick Clamp and Retainer	261-11, 12, 13
193	146584	Needle Bar Bushing Oil Wick	261-11, 12, 13
194	416083	Needle Bar Connecting Stud Slide Block Guide Screw (2)	261-11, 12, 13
195	416083	Needle Bar Bushing (left) and Looper Avoid Brackets Oil Tube with two washers 143124 and 416061	261-11, 12, 13
196	416085	Slide Block Cover Screw (2)	261-11, 12, 13
197	225(805)	Oil Tube Clamping Screw (2)	261-11, 12, 13
198	416085	Oil Tube Clamping Sleeve (2)	261-11, 12, 13
199	416085	Oil Tube Clamping Sleeve (2)	261-11, 12, 13
200	139154	Thread (Looper) Take-up Stripper	261-11, 12, 13
201	139144	Thread (Looper) Take-up Stripper Plate Bracket 416084 with 240 300, 7071, 5128(909), 139145, 139146, 139147, 139148, 139149, 139150, 139151, 139152, 139153, 139154, 139155, 139156, 139157, 139158, 139159, 139160, 139161, 139162, 139163, 139164, 139165, 139166, 139167, 139168, 139169, 139170, 139171, 139172, 139173, 139174, 139175, 139176, 139177, 139178, 139179, 139180, 139181, 139182, 139183, 139184, 139185, 139186, 139187, 139188, 139189, 139190, 139191, 139192, 139193, 139194, 139195, 139196, 139197, 139198, 139199, 139200, 139201, 139202, 139203, 139204, 139205, 139206, 139207, 139208, 139209, 139210, 139211, 139212, 139213, 139214, 139215, 139216, 139217, 139218, 139219, 139220, 139221, 139222, 139223, 139224, 139225, 139226, 139227, 139228, 139229, 139230, 139231, 139232, 139233, 139234, 139235, 139236, 139237, 139238, 139239, 139240, 139241, 139242, 139243, 139244, 139245, 139246, 139247, 139248, 139249, 139250, 139251, 139252, 139253, 139254, 139255, 139256, 139257, 139258, 139259, 139260, 139261, 139262, 139263, 139264, 139265, 139266, 139267, 139268, 139269, 139270, 139271, 139272, 139273, 139274, 139275, 139276, 139277, 139278, 139279, 139280, 139281, 139282, 139283, 139284, 139285, 139286, 139287, 139288, 139289, 139290, 139291, 139292, 139293, 139294, 139295, 139296, 139297, 139298, 139299, 139300, 139301, 139302, 139303, 139304, 139305, 139306, 139307, 139308, 139309, 139310, 139311, 139312, 139313, 139314, 139315, 139316, 139317, 139318, 139319, 139320, 139321, 139322, 139323, 139324, 139325, 139326, 139327, 139328, 139329, 139330, 139331, 139332, 139333, 139334, 139335, 139336, 139337, 139338, 139339, 139340, 139341, 139342, 139343, 139344, 139345, 139346, 139347, 139348, 139349, 139350, 139351, 139352, 139353, 139354, 139355, 139356, 139357, 139358, 139359, 139360, 139361, 139362, 139363, 139364, 139365, 139366, 139367, 139368, 139369, 139370, 139371, 139372, 139373, 139374, 139375, 139376, 139377, 139378, 139379, 139380, 139381, 139382, 139383, 139384, 139385, 139386, 139387, 139388, 139389, 139390, 139391, 139392, 139393, 139394, 139395, 139396, 139397, 139398, 139399, 139400, 139401, 139402, 139403, 139404, 139405, 139406, 139407, 139408, 139409, 139410, 139411, 139412, 139413, 139414, 139415, 139416, 139417, 139418, 139419, 139420, 139421, 139422, 139423, 139424, 139425, 139426, 139427, 139428, 139429, 139430, 139431, 139432, 139433, 139434, 139435, 139436, 139437, 139438, 139439, 139440, 139441, 139442, 139443, 139444, 139445, 139446, 139447, 139448, 139449, 139450, 139451, 139452, 139453, 139454, 139455, 139456, 139457, 139458, 139459, 139460, 139461, 139462, 139463, 139464, 139465, 139466, 139467, 139468, 139469, 139470, 139471, 139472, 139473, 139474, 139475, 139476, 139477, 139478, 139479, 139480, 139481, 139482, 139483, 139484, 139485, 139486, 139487, 139488, 139489, 139490, 139491, 139492, 139493, 139494, 139495, 139496, 139497, 139498, 139499, 139500, 139501, 139502, 139503, 139504, 139505, 139506, 139507, 139508, 139509, 139510, 139511, 139512, 139513, 139514, 139515, 139516, 139517, 139518, 139519, 139520, 139521, 139522, 139523, 139524, 139525, 139526, 139527, 139528, 139529, 139530, 139531, 139532, 139533, 139534, 139535, 139536, 139537, 139538, 139539, 139540, 139541, 139542, 139543, 139544, 139545, 139546, 139547, 139548, 139549, 139550, 139551, 139552, 139553, 139554, 139555, 139556, 139557, 139558, 139559, 139560, 139561, 139562, 139563, 139564, 139565, 139566, 139567, 139568, 139569, 139570, 139571, 139572, 139573, 139574, 139575, 139576, 139577, 139578, 139579, 139580, 139581, 139582, 139583, 139584, 139585, 139586, 139587, 139588, 139589, 139590, 139591, 139592, 139593, 139594, 139595, 139596, 139597, 139598, 139599, 139600, 139601, 139602, 139603, 139604, 139605, 139606, 139607, 139608, 139609, 139610, 139611, 139612, 139613, 139614, 139615, 139616, 139617, 139618, 139619, 139620, 139621, 139622, 139623, 139624, 139625, 139626, 139627, 139628, 139629, 139630, 139631, 139632, 139633, 139634, 139635, 139636, 139637, 139638, 139639, 139640, 139641, 139642, 139643, 139644, 139645, 139646, 139647, 139648, 139649, 139650, 139651, 139652, 139653, 139654, 139655, 139656, 139657, 139658, 139659, 139660, 139661, 139662, 139663, 139664, 139665, 139666, 139667, 139668, 139669, 139670, 139671, 139672, 139673, 139674, 139675, 139676, 139677, 139678, 139679, 139680, 139681, 139682, 139683, 139684, 139685, 139686, 139687, 139688, 139689, 139690, 139691, 139692, 139693, 139694, 139695, 139696, 139697, 139698, 139699, 139700, 139701, 139702, 139703, 139704, 139705, 139706, 139707, 139708, 139709, 139710, 139711, 139712, 139713, 139714, 139715, 139716, 139717, 139718, 139719, 139720, 139721, 139722, 139723, 139724, 139725, 139726, 139727, 139728, 139729, 139730, 139731, 139732, 139733, 139734, 139735, 139736, 139737, 139738, 139739, 139740, 139741, 139742, 139743, 139744, 139745, 139746, 139747, 139748, 139749, 139750, 139751, 139752, 139753, 139754, 139755, 139756, 139757, 139758, 139759, 139760, 139761, 139762, 139763, 139764, 139765, 139766, 139767, 139768, 139769, 139770, 139771, 139772, 139773, 139774, 139775, 139776, 139777, 139778, 139779, 139780, 139781, 139782, 139783, 139784, 139785, 139786, 139787, 139788, 139789, 139790, 139791, 139792, 139793, 139794, 139795, 139796, 139797, 139798, 139799, 139800, 139801, 139802, 139803, 139804, 139805, 139806, 139807, 139808, 139809, 139810, 139811, 139812, 139813, 139814, 139815, 139816, 139817, 139818, 139819, 139820, 139821, 139822, 139823, 139824, 139825, 139826, 139827, 139828, 139829, 139830, 139831, 139832, 139833, 139834, 139835, 139836, 139837, 139838, 139839, 139840, 139841, 139842, 139843, 139844, 139845, 139846, 139847, 139848, 139849, 139850, 139851, 139852, 139853, 139854, 139855, 139856, 139857, 139858, 139859, 139860, 139861, 139862, 139863, 139864, 139865, 139866, 139867, 139868, 139869, 139870, 139871, 139872, 139873, 139874, 139875, 139876, 139877, 139878, 139879, 139880, 139881, 139882, 139883, 139884, 139885, 139886, 139887, 139888, 139889, 139890, 139891, 139892, 139893, 139894, 139895, 139896, 139897, 139898, 139899, 139900, 139901, 139902, 139903, 139904, 139905, 139906, 139907, 139908, 139909, 139910, 139911, 139912, 139913, 139914, 139915, 139916, 139917, 139918, 139919, 139920, 139921, 139922, 139923, 139924, 139925, 139926, 139927, 139928, 139929, 139930, 139931, 139932, 139933, 139934, 139935, 139936, 139937, 139938, 139939, 139940, 139941, 139942, 139943, 139944, 139945, 139946, 139947, 139948, 139949, 139950, 139951, 139952, 139953, 139954, 139955, 139956, 139957, 139958, 139959, 139960, 139961, 139962, 139963, 139964, 139965, 139966, 139967, 139968, 139969, 139970, 139971, 139972, 139973, 139974, 139975, 139976, 139977, 139978, 139979, 139980, 139981, 139982, 139983, 139984, 139985, 139986, 139987, 139988, 139989, 139990, 139991, 139992, 139993, 139994, 139995, 139996, 139997, 139998, 139999, 140000, 140001, 140002, 140003, 140004, 140005, 140006, 140007, 140008, 140009, 140010, 140011, 140012, 140013, 140014, 140015, 140016, 140017, 140018, 140019, 140020, 140021, 140022, 140023, 140024, 140025, 140026, 140027, 140028, 140029, 140030, 140031, 140032, 140033, 140034, 140035, 140036, 140037, 140038, 140039, 140040, 140041, 140042, 140043, 140044, 140045, 140046, 140047, 140048, 140049, 140050, 140051, 140052, 140053, 140054, 140055, 140056, 140057, 140058, 140059, 140060, 140061, 140062, 140063, 140064, 140065, 140066, 140067, 140068, 140069, 140070, 140071, 140072, 140073, 140074, 140075, 140076, 140077, 140078, 140079, 140080, 140081, 140082, 140083, 140084, 140085, 140086, 140087, 140088, 140089, 140090, 140091, 140092, 140093, 140094, 140095, 140096, 140097, 140098, 140099, 140100, 140101, 140102, 140103, 140104, 140105, 140106, 140107, 140108, 140109, 140110, 140111, 140112, 140113, 140114, 140115, 140116, 140117, 140118, 140119, 140120, 140121, 140122, 140123, 140124, 140125, 140126, 140127, 140128, 140129, 140130, 140131, 140132, 140133, 140134, 140135, 140136, 140137, 140138, 140139, 140140, 140141, 140142, 140143, 140144, 140145, 140146, 140147, 140148, 140149, 140150, 140151, 140152, 140153, 140154, 140155, 140156, 140157, 140158, 140159, 140160, 140161, 140162, 140163, 140164, 140165, 140166, 140167, 140168, 140169, 140170, 140171, 140172, 140173, 140174, 140175, 140176, 140177, 140178, 140179, 140180, 140181, 140182, 140183, 140184, 140185, 140186, 140187, 140188, 140189, 140190, 140191, 140192, 140193, 140194, 140195, 140196, 140197, 140198, 140199, 140200, 140201, 140202, 140203, 140204, 140205, 140206, 140207, 140208, 140209, 140210, 140211, 140212, 140213, 14021	



LIST OF PARTS FOR 261-11, 12 and 13 MACHINES

CODE	PART NO.	DESCRIPTION	MACHINE VARIETY
86	32824	Looper (front) for 1/4 inch gauge	261-11, 12, 13
87	143474	Looper Gate (right) 143473 with 143477 and 51282(819), for Throat Plates 3/4 inch wide	261-11, 12, 13
	143476	Looper Gate (right) 143475 with 143477 and 51282(819), for Throat Plates 7/8 inch wide	261-11, 12, 13
88	143477	Looper Gate (right) Lock Spring	261-11, 12, 13
89	51282(819)	Looper Gate (right) Lock Spring Screw	261-11, 12, 13
90	143473	Looper Gate (right) for Throat Plates 3/4 inch wide	261-11, 12, 13
	143475	Looper Gate (right) for Throat Plates 7/8 inch wide	261-11, 12, 13
91	143478	Looper Gate Hinge Pin (2)	261-11, 12, 13
92	416043	Looper Eccentric Collar and Support with 416020 and two 545390	261-11, 12, 13
93	139337-000	Feed Dog 21 teeth (16 teeth to the inch), for 1/8 inch and 5/32 inch gauges (NOTE: State gauge required.)	261-11, 12
	22571-012	Feed Dog (14 teeth to the inch), for 3/16 inch gauge, for Chaining-off	261-11
	139340-016	Feed Dog, 19 teeth (14 teeth to the inch), for 1/4 inch gauge (NOTE: State gauge required.)	261-11
	139388-000	Feed Dog, 16 teeth (12 teeth to the inch), for 3/16 inch and 1/4 inch gauges (NOTE: State gauges required.)	261-12
	139414-000	Feed Dog, 11 teeth (8 teeth to the inch), for 3/16 inch to 1/4 inch gauges (NOTE: State gauge required.)	261-13
	143448	Feed Bar	261-11, 12, 13
95	504691	Plug Screw	261-11, 12, 13
96	416020	Clamping Screw	261-11, 12, 13
97	139665	Link Hinge Pin (2)	261-11, 12, 13
	139064	Connecting Link	261-11, 12, 13
98	139064	Set Screw	261-11, 12, 13
99	1047(830)	Set Screw	261-11, 12, 13
	446(830)	Set Screw	261-11, 12, 13
101	139534	Looper Driving Arm Hinge Stud	261-11, 12, 13
102	545390	Set Screw (2)	261-11, 12, 13
103	139330	Bed Rotary Shaft Bushing (left) Cover	261-11, 12, 13
104	139330	Bed Rotary Shaft Bushing (left) Cover	261-11, 12, 13
105	143643	Bed Rotary Shaft Bushing (left) for Pinx	261-11, 12, 13
106	143644	Bed Rotary Shaft Bushing (left)	261-11, 12, 13
107	416044	Set Screw	261-11, 12, 13
108	143462	Looper Eccentric Connector with 143473	261-11, 12, 13
109	416021	Looper Eccentric and Feed Lifting Eccentric with two 143628	261-11, 12, 13
110	545068	Looper Eccentric and Feed Lifting Eccentric Set Screw	261-11, 12, 13
111	416040	Feed Lifting Eccentric Forked Connection	261-11, 12, 13
112	143451	Feed Lifting Eccentric Forked Connection Slide Block	261-11, 12, 13
113	143450	Feed Eccentric Slide Block	261-11, 12, 13
114	416071	Feed Eccentric (Adjustable) complete, Nos. 7071, 416139 and two 51061(830)	261-11, 12, 13
115	416139	Feed Eccentric Clamping Washer Screw	261-11, 12, 13
116	51061(830)	Set Screw (2)	261-11, 12, 13
117	416018	Feed Regulating Screw	261-11, 12, 13
118	7071	Feed Eccentric Clamping Washer	261-11, 12, 13
119	416017	Tension Bracket Screw	261-11, 12, 13
120	416052	Pressure Regulating Thum Screw	261-11, 12, 13
121	416021	Pressure Regulating Thum Screw Nut	261-11, 12, 13
122	139158	Thread (Looper) Thread Guide (2)	261-11, 12, 13
	139158	Thread (needle) Thread Guide (2)	261-11, 12, 13
123	416032	Thread (needle) Thread Guide Bracket	261-11, 12, 13
124	139177	Thread (needle) Eyelet	261-11, 12, 13
125	416138	Thread (needle) Eyelet Screw	261-11, 12, 13
126	32933	Presser Bar Spring Guide Pin	261-11, 12, 13
127	416003	Presser Bar Spring Guide Pin	261-11, 12, 13
128	545454	Stop Screw	261-11, 12, 13
129	416070	Stop Screw Nut	261-11, 12, 13
130	446159	Tension Needle Thread Regulating Throat Stop Screw Guide with 446159	261-11, 12, 13
131	416025	Presser Bar Spring	261-11, 12, 13
132	143447	Tension (needle thread) Bracket (NOTE: State color required.)	261-11, 12, 13
133	143543	Face Plate	261-11, 12, 13
134	416115	Face Plate Gasket	261-11, 12, 13
135	416005	Clamping Bar Lifting Bracket with 416005	261-11, 12, 13
136	446151	Presser Bar Bushing (lower)	261-11, 12, 13
137	416116	Presser Bar Stop with 446154	261-11, 12, 13
138	416134	Clamping Screw	261-11, 12, 13
	416134	Presser Foot Screw	261-11, 12, 13
139	416041	Presser Bar	261-11, 12, 13
140	1133(805)	Presser Bar Bushing (lower) Set Screw	261-11, 12, 13
141	139138-000	Presser foot (triple hinged) complete, for 1/8 inch and 5/32 inch gauges, Nos. 37160, 139134, 139135, 139137, 146167 and three 26276 (NOTE: State gauge required.)	261-12
	139233-000	Presser foot (triple hinged) complete, for 3/16 inch and 1/4 inch gauges	261-12
	139423-000	Presser foot (triple hinged) complete, for 3/16 inch and 1/4 inch gauges	261-12
	21492-006	Presser foot (triple hinged) complete, for 1/8 inch and 1/4 inch gauges	261-11
	21492-012	Presser foot (triple hinged) complete, for 1/8 inch gauge	261-11
	21492-016	Presser foot (triple hinged) complete, for 3/16 inch gauge	261-11
	21492-016	Presser foot (triple hinged) complete, for 3/16 inch gauge	261-11
142	37160	Presser foot plate connection spring, for 1/4 inch gauge	261-12, 13
	21489	Presser foot plate and retaining feed connection springs	261-12, 13
143	26276	Presser foot plate and retaining feed connection springs	261-12, 13
	26276-004	Hinge Pin	261-12, 13
144	139134	Presser foot plate (back) (NOTE: State gauge required.)	261-11, 12, 13
	21487-008	Presser foot plate, for 1/8 inch gauge	261-11, 12, 13
144	21487-012	Presser foot plate, for 5/32 inch gauge	261-11, 12, 13
	21487-012	Presser foot plate, for 3/16 inch gauge	261-11, 12, 13
145	21487-016	Presser foot plate, for 1/4 inch gauge	261-11, 12, 13
146	139137	Presser foot Shank	261-11, 12, 13
147	21490	Presser foot Shank	261-11, 12, 13
	146154	Presser foot plate connection	261-11, 12, 13

Downloaded from www.industrydocuments.ucsf.edu