

SINGER


307G2

FORM 21097
(1059)
PRINTED IN U. S. A.

LIST OF PARTS COMPLETE
FOR
MACHINE No. 307G2

THE SINGER MANUFACTURING COMPANY

SINGER 30782



Get the full line of: Diamond Needle Cases



LIST OF PARTS COMPLETE

FOR

MACHINE NO. 307G2

Single Needle, Lock Stitch, Transverse Hook, Drop Feed Mechanism
Makes Straight or Zig-Zag Stitches. For General Tailoring Work.

No.	Name
506727	Arm with 1259AL and four 140543L
506728	Arm and Bed, Nos. 500203E, 506727, 506737, two 506507 and three 500204E
506502	Arm Cross Shaft
506503	Arm Cross Shaft Bushing (fork end)
506504	Arm Cross Shaft Clamping Bushing
140346AL	Arm Cross Shaft Clamping Bushing Set Screw
506505	Arm Cross Shaft Driving Worm with two 1259AL
1259AL	Arm Cross Shaft Driving Worm Set Screw (2)
506729	Arm Cross Shaft Spiral Gear and Needle Bar Frame Pitman Eccentric
506507	Arm Dowel Pin (2)
506508	Arm Oil Tube, for oiling Arm Cross Shaft Spiral Gear and Needle Bar Frame Pitman Eccentric and Needle Vibrator Zero Position Lever Swivel Stud Slide Block (3)
506509	Arm Oil Tube, for oiling Arm Shaft Bushing (back)
506510	Arm Oil Tube, for oiling Arm Shaft Bushing (intermediate)
506511	Arm Oil Tube, for oiling Feed Eccentric
500203E	Arm Screw (long)
500204E	Arm Screw (short) (3)
506730	Arm Shaft
506731	Arm Shaft 506730 with 500147F, 506523 and 506761
506732	Arm Shaft Bushing (back)
1485X	Arm Shaft Bushing (back) Cap Screw (4)
506733	Arm Shaft Bushing (front)
506734	Arm Shaft Bushing (front) Oil Tube
204329	Arm Shaft Bushing (front) Oil Tube Packing (felt)
202423	Arm Shaft Bushing (front) Oil Tube Packing (wick)
309C	Arm Shaft Bushing (front) Set Screw
506519	Arm Shaft Bushing (intermediate)
140346AL	Arm Shaft Bushing (intermediate) Set Screw
506726	Arm Shaft Connection Belt
506735	Arm Shaft Connection Belt Pulley with two each 500205AL and 506736
500205AL	Arm Shaft Connection Belt Pulley Set Screw (2)
506736	Arm Shaft Connection Belt Pulley Spring Ring (2)
506523	Arm Shaft Packing (cotton)

No.	Name
500147F	Arm Shaft Screw
506524	Arm Side Cover (back)
140240W	Arm Side Cover (back) Thumb Screw (2)
506526	Arm Side Cover (front)
506693	Arm Side Cover (front) 506526 with two 500169X
506737	Bed
506527	Bed Cover Plate
691AL	Bed Cover Plate Screw (2)
506738	Bed Slide
506739	Bed Slide Spring
238X	Bed Slide Spring Screw (2)
506655	Bell Crank
506656	Bell Crank 506655 with 502136 and 502137
502136	Bell Crank Bracket
178E	Bell Crank Bracket Screw (2)
506638	Bell Crank Connecting Rod
506740	Bell Crank Connecting Rod Joint
50391XC	Bell Crank Connecting Rod Joint Hinge Screw
1708X	Bell Crank Connecting Rod Lock Nut
506741	Bell Crank Connecting Rod Retaining Pin
502137	Bell Crank Hinge Pin
502139	Bell Crank Spring
506663	Bell Crank complete, Nos. 502139 and 506656
106502	Belt Guard with two SS706X
106504	Belt Guard Holder
1259AL	Belt Guard Holder Set Screw
SS 706X	Belt Guard Set Screw
500166J	Clamp Stop Motion Clamp Screw
248A	Clamp Stop Motion Clamp Stop Screw
171502	Clamp Stop Motion Clamp Washer
506742	Clamp Stop Motion Flanged Bushing with 435AL and 500206AL
500206AL	Clamp Stop Motion Flanged Bushing Position Screw
435AL	Clamp Stop Motion Flanged Bushing Set Screw
140543L	Class Number Plate Drive Screw (2)
506533	Face Plate
506680	Face Plate 506533 with 506681
506681	Face Plate Oil Tube
164X	Face Plate Screw (2)
506534	Feed Bar
506535	Feed Bar 506534 with 506686 and two 208AL
506743	Feed Bar Hinge Pin (eccentric)
624ALX	Feed Bar Hinge Pin Set Screw
506537	Feed Connecting Rod with two 50073C
50073C	Feed Connecting Rod Cap Screw (2)

No.	Name
140346AL	Feed Regulator Segment Bushing Set Screw
506564	Feed Regulator Segment Connecting Arm
500209K	Feed Regulator Stop Screw
1258AL	Feed Regulator Stop Screw Adjusting Screw
506755	Feed Regulator Stop Screw Adjusting Screw Washer
506756	Feed Regulator Stop Screw Bushing
506757	Feed Regulator Stop Screw Bushing 506756 with 1258AL, 500209K and 506755
1259AL	Feed Regulator Stop Screw Bushing Set Screw
506758	Feed Eock Shaft with 624ALX
506759	Feed Rock Shaft Adjusting Collar with two 1259AL
1259AL	Feed Rock Shaft Adjusting Collar Set Screw (2)
506567	Feed Rock Shaft Bushing (back)
140346AL	Feed Rock Shaft Bushing (back) Set Screw
506568	Feed Rock Shaft Bushing (front)
140346AL	Feed Rock Shaft Bushing (front) Set Screw
506569	Feed Rock Shaft Crank with 1186C
1186C	Feed Rock Shaft Crank Clamping Screw
506570	Feed Rock Shaft Crank Hinge Pin
500207C	Feed Rock Shaft Crank Hinge Pin Set Screw
506664	Lifting Lever
500162X	Lifting Lever Hinge Screw
506665	Lifting Lever Pitman Rod
506666	Lifting Lever Pitman Rod Connection
500162X	Lifting Lever Pitman Rod Connection Hinge Screw (2)
506740	Lifting Lever Pitman Rod Joint (2)
50391XC	Lifting Lever Pitman Rod Joint Hinge Screw (2)
1708X	Lifting Lever Pitman Rod Lock Nut (2)
506525	Machine Pulley
506760	Needle Bar with 189774
224340	Needle Bar Connecting Link
506682	Needle Bar Connecting Link Guide Bar
500210C	Needle Bar Connecting Link Guide Bar Screw (2)
202333	Needle Bar Connecting Link Stud with 202254
202254	Needle Bar Connecting Link Stud Oil Packing (wick)
200383C	Needle Bar Connecting Link Stud Position Screw
200383C	Needle Bar Connecting Link Stud Set Screw
210544	Needle Bar Connecting Stud with 202299
202299	Needle Bar Connecting Stud Oil Packing (wick)
210882	Needle Bar Connecting Stud Swivel with 200392C
200392C	Needle Bar Connecting Stud Swivel Set Screw
506761	Needle Bar Crank with 200335C, 200428C, 202333 and two 200383C
506573	Needle Bar Crank Oil Guard
200428C	Needle Bar Crank Position Screw
200335C	Needle Bar Crank Set Screw

No.	Name
506762	Needle Bar Frame with 238X, 189532 and 500207C
506575	Needle Bar Frame Guide Stud
500207C	Needle Bar Frame Guide Stud Set Screw
506576	Needle Bar Frame Hinge Stud
500207C	Needle Bar Frame Hinge Stud Set Screw
506577	Needle Bar Frame Pitman (forked)
506578	Needle Bar Frame Pitman Eccentric Stud
500207C	Needle Bar Frame Pitman Eccentric Stud Set Screw
189532	Needle Bar Height Indicator
238X	Needle Bar Height Indicator Screw
45334	Needle Clamp with 140545J
105131	Needle Clamp 45334 with SS675AL
506763	Needle Clamp Gib and Thread Guide
SS 675AL	Needle Clamp Position Screw
140545J	Needle Clamp Thumb Screw
506764	Needle Holder with 465J
506765	Needle Holder complete, Nos. 105131, 506763 and 506764
465J	Needle Holder Clamping Screw
189774	Needle Holder Position Pin
506766	Needle Vibrator Amplitude Regulating Lever with two 500207AL
506586	Needle Vibrator Amplitude Regulating Lever Position Pin
506587	Needle Vibrator Amplitude Regulating Lever Position Pin Spring
506588	Needle Vibrator Amplitude Regulating Lever Position Pin Thumb Nut
500207AL	Needle Vibrator Amplitude Regulating Lever Set Screw (2)
506767	Needle Vibrator Amplitude Regulating Lever Shaft complete, Nos. 500151C, 506590, 506591 and 506768
500211X	Needle Vibrator Amplitude Regulating Lever Shaft Cap Screw
506590	Needle Vibrator Amplitude Regulating Lever Shaft Crank
506591	Needle Vibrator Amplitude Regulating Lever Shaft Crank Connecting Link
500151C	Needle Vibrator Amplitude Regulating Lever Shaft Crank Connecting Link Hinge Screw (2)
506768	Needle Vibrator Amplitude Regulating Lever Shaft Crank Pin
506038	Needle Vibrator Amplitude Regulating Lever Shaft Friction Washer
506687	Needle Vibrator Amplitude Regulating Lever Shaft Pressure Block with 140431X
140431X	Needle Vibrator Amplitude Regulating Lever Shaft Pressure Block Clamping Screw
506595	Needle Vibrator Amplitude Regulating Lever Stop (left)
500780A	Needle Vibrator Amplitude Regulating Lever Stop (left) Thumb Nut
506769	Needle Vibrator Amplitude Regulating Lever Stop (right)
500780A	Needle Vibrator Amplitude Regulating Lever Stop (right) Thumb Nut
35610	Needle Vibrator Amplitude Regulating Lever Stop Friction Washer (2)
506770	Needle Vibrator Amplitude Regulating Lever Stop Washer (2)
500169X	Needle Vibrator Amplitude Regulating Lever Stop Screw (2)
506597	Needle Vibrator Zero Position Control Lever

No.	Name
506598	Needle Vibrator Zero Position Control Lever 506597 with 506599, 506600 and 506601
506599	Needle Vibrator Zero Position Control Lever Button
506600	Needle Vibrator Zero Position Control Lever Indicator
506601	Needle Vibrator Zero Position Control Lever Push Button
50128X	Needle Vibrator Zero Position Control Lever Screw (2)
506602	Needle Vibrator Zero Position Control Lever Stop Block
506695	Needle Vibrator Zero Position Control Lever Stop Block 506602 with two 500171X
500170XC	Needle Vibrator Zero Position Control Lever Stop Block Screw (2)
506696	Needle Vibrator Zero Position Control Lever Stop Block Screw Washer (2)
500171X	Needle Vibrator Zero Position Control Lever Stop Screw (2)
506603	Needle Vibrator Zero Position Lever
506604	Needle Vibrator Zero Position Lever 506603 with 506606 and 506607
506605	Needle Vibrator Zero Position Lever Bearing
506606	Needle Vibrator Zero Position Lever Swivel Stud
506607	Needle Vibrator Aero Position Lever Swivel Stud Crank with two 500207C
500207C	Needle Vibrator Zero Position Lever Swivel Stud Crank Set Screw (2)
506608	Needle Vibrator Zero Position Lever Swivel Stud Slide Block
506609	Presser Bar
506771	Presser Bar Guide with 1186C
1186C	Presser Bar Guide Clamping Screw
506722	Presser Bar Guide Pressure Spring
506773	Presser Bar Lifter
502095	Presser Bar Lifter Hinge Pin
506774	Presser Bar Spring
202346	Presser Bar Spring Stop Rod
506613	Presser Bar Tension Release Lever
500154E	Presser Bar Tension Release Lever Hinge Screw
506775	Presser Bar Tension Release Lever Pressure Spring
506614	Presser Foot Hinge Pin
188577	Presser Foot Plate
188576	Presser Foot Shank
506615	Presser Foot Spring
506616	Presser Foot complete, Nos. 188576, 188577, 506614 and 506615
50190J	Presser Foot Screw
500155J	Pressure Regulating Thumb Screw
224432	Rotating Hook with 203101 and 263134
224433	Rotating Hook 224432 with 200145C, 210536, 210541 and three 200596F
224443	Rotating Hook and Bobbin Case complete, Nos. 224433 and 224442
263099	Rotating Hook Bobbin
224442	Rotating Hook Bobbin Case complete, Nos. 210846 and 224441
210846	Rotating Hook Bobbin Case Base
224440	Rotating Hook Bobbin Case Cap with 200592C, 201016C and 263110

No.	Name
224441	Rotating Hook Bobbin Case Cap complete, Nos. 200964C, 210736, 210914 and 224440
210913	Rotating Hook Bobbin Case Latch
210914	Rotating Hook Bobbin Case Latch 210913 with 210734 and 210735
210734	Rotating Hook Bobbin Case Latch Lever
210735	Rotating Hook Bobbin Case Latch Lever Fulcrum Pin
210736	Rotating Hook Bobbin Case Latch Spring
200964C	Rotating Hook Bobbin Case Latch Stop Screw
263110	Rotating Hook Bobbin Case Tension Spring
201016C	Rotating Hook Bobbin Case Tension Spring Regulating Screw
200592C	Rotating Hook Bobbin Case Tension Spring Screw
506776	Rotating Hook Driving Shaft
506777	Rotating Hook Driving Shaft Connection Belt Pulley with 202324 and two 500212AL
500212AL	Rotating Hook Driving Shaft Connection Belt Pulley Set Screw (2)
202324	Rotating Hook Driving Shaft Connection Belt Pulley Spring Ring
506778	Rotating Hook Driving Shaft Spiral Gear with two 1259AL
1259AL	Rotating Hook Driving Shaft Spiral Gear Set Screw (2)
210536	Rotating Hook Gib
200596F	Rotating Hook Gib Screw (3)
203101	Rotating Hook Oil Wick
263134	Rotating Hook Oiling Felt
210764	Rotating Hook Position Finger
50117AL	Rotating Hook Position Finger Screw
200915C	Rotating Hook Retaining Screw
506621	Rotating Hook Shaft
506779	Rotating Hook Shaft Adjusting Collar with two 1259AL
1259AL	Rotating Hook Shaft Adjusting Collar Set Screw (2)
506780	Rotating Hook Shaft Bushing (back)
506781	Rotating Hook Shaft Bushing (front)
1259AL	Rotating Hook Shaft Bushing Set Screw (2)
506782	Rotating Hook Shaft Spiral Gear with two 1259AL
506626	Rotating Hook Shaft Spiral Gear Cover
500210X	Rotating Hook Shaft Spiral Gear Cover Screw (4)
506627	Rotating Hook Shaft Spiral Gear Grease Plug
1259AL	Rotating Hook Shaft Spiral Gear Set Screw (2)
210541	Rotating Hook Washer Needle Guard
200145C	Rotating Hook Washer Needle Guard Screw
500213XC	Spool Holder Bracket Screw
506783	Spool Holder Bracket Screw 500213XC with 206512
506512	Spool Holder Bracket Screw Oil Tube
506630	Stitch Pattern Central Indicator Plate
500172XC	Stitch Pattern Central Indicator Plate Screw (4)
506631	Tension Friction Washer
500773	Tension Regulating Thumb Nut

No.	Name
506632	Tension Stud
624AL	Tension Stud Set Screw
506633	Tension Wheel
506634	Tension (wheel) complete, Nos. 66774, 500773B, 506631, 506632, 506633 and 506703
26075	Thread Cutter and Holder
506784	Thread Guide (side of arm) lower
SS 59K	Thread Guide (side of arm) lower and middle Screw (2)
506785	Thread Guide (side of arm) middle
506786	Thread Guide (side of arm) upper
350201K	Thread Guide (side of arm) upper and Needle Bar Crank Oil Guard Screw
51701E	Thread Guide (side of arm) upper and Needle Bar Crank Oil Guard Screw Nut
506635	Thread Guide and Spool Pin (top of arm)
8879	Thread Guide and Spool Pin Washer (cloth)
506787	Thread Take-up Guard
350201K	Thread Take-up Guard Screw (2)
248258	Thread Take-up Lever
202399	Thread Take-up Lever Driving Stud with 244071
244071	Thread Take-up Lever Driving Stud Oil Packing (wick)
506788	Thread Take-up Lever Hinge Stud with 267240
267240	Thread Take-up Lever Hinge Stud Oil Packing (wick)
500214AL	Thread Take-up Lever Hinge Stud Set Screw
66774	Thread Take-up Spring
506643	Thread Take-up Spring Regulator and Thread Guide
50117AE	Thread Take-up Spring Regulator and Thread Guide Screw
506703	Thread Take-up Spring Thread Guard
506644	Thread Tension Lifter Lever
506645	Throat Plate
691ALX	Throat Plate Screw (2)
2102	Two Thread Tension Disc (4)
506789	Two Thread Tension Plate with 506648, 506791 and two each 500161K, 500215J and 506792
506647	Two Thread Tension Plate Spacer (2)
742J	Two Thread Tension Plate Screw (2)
201572B	Two Thread Tension Regulating Thumb Nut (2)
32572	Two Thread Tension Releasing Disc (2)
506648	Two Thread Tension Releasing Lever
506790	Two Thread Tension Releasing Lever Pin
506791	Two Thread Tension Releasing Lever Pressure Spring
500161K	Two Thread Tension Releasing Lever Screw (2)
506792	Two Thread Tension Releasing Pin (2)
13710	Two Thread Tension Spring (2)
500215J	Two Thread Tension Stud (2)
506793	Two Thread Tension Stud Flange (2)
140543L	Trade Mark Drive Screw (2)
139637	Drip Pan with four 1 in. wire nails

ACCESSORIES
(Supplied with Machine)

No.	Name
12361	Machine Hinge Connection (2)
44139	Machine Hinge Plate (2)
44140	Machine Hinge complete, Nos. 12361, 44139 and wood screw 1-1/4 in. No. 14 F. H. (2)
41400	Machine Rest Pin (wood)

ATTACHMENT SET NO. 503528
(Packaged in Metal Box)
(Supplied with Machine)

No.	Name
263099	Bobbin (4)
503518	Box (metal)
503535	Bushing Extractor for Feed Regulator Segment Bushing
188657	Guide
50190D	Guide Thumb Screw
135x17	Needles (5) two each of sizes 14 and 16 and one size 19
160347	Presser Foot (edge stitching) with needle hole on right side, for 1/64 in. stitching margin
160348	Presser Foot (edge stitching) with needle hole on left side, for 1/32 in. stitching margin
35134	Presser Foot
161185	Presser Foot 35134 with 337B, 35002, 35135, 35136 and 36696
35137	Presser Foot with Extension and Graduated Adjustable Guides complete, Nos. 35003, 35004, 35005, 35006 and 161185
35002	Presser Foot Extension
188658	Presser Foot Graduated Adjustable Guide
35003	Presser Foot Graduated Adjustable Guide (long, left)
35004	Presser Foot Graduated Adjustable Guide (long, right)
35005	Presser Foot Graduated Adjustable Guide (short, right)
35006	Presser Foot Graduated Adjustable Guide (short, right flush)
35134	Presser Foot Graduated Adjustable Guide Clamp
35136	Presser Foot Graduated Adjustable Guide Clamp Lever
337J	Presser Foot Graduated Adjustable Guide Clamp Screw
36696	Presser Foot Graduated Adjustable Guide Clamp Steady Pin
188740	Presser Foot with Extension and Graduated Adjustable Guide complete, Nos. 35137 and 188658
188691	Presser Foot
188692	Presser Foot Adjustable Guide

No.	Name
506691	Presser Foot Adjustable Guide 188692 with 188694
188696	Presser Foot Adjustable Guide Bracket
188694	Presser Foot Adjustable Guide Hinge Pin
188695	Presser Foot Adjustable Guide Hinge Pin Spring
188693	Presser Foot Adjustable Guide Hinge Pin Stop Pin
50238J	Presser Foot Adjustable Guide Thumb Screw
188690	Presser Foot Adjustable Guide Thumb Screw Washer
506692	Presser Foot Adjustable Guide, Nos. 188693, 188695, 188696 and 506691
188697	Presser Foot with Adjustable Guide complete, for Blind Stitching, Nos. 50238J, 188690, 188691 and 506692
120378	Screw Driver (shuttle tension)
503505	Screw Driver (machine)
161083	Oil Container
503533	Oil Container 161083 (filled with light grade Oil, Type "C")
503528	Attachment Set complete, Nos. 50190D, 120378, 160347, 160348, 188657, 188697, 188740, 503505, 503518, 503533, 503535, four 263099 and five needles (135x17, two each of sizes 14 and 16 and one size 19)

BOBBIN WINDER
(Supplied with Foot Power Drive Machine)

No.	Name
506795	Bracket with 457AL
506688	Frame with 457AL
34105	Frame Hinge Pin
457AL	Frame Hinge Pin Set Screw
41914	Frame Spring
506796	Pulley with 171ALX
171ALX	Pulley Set Screw
41586	Spindle
506797	Spool Holder Bracket
506798	Spool Holder complete, Nos. 506797 and two each 204296 and 500216XC
204296	Spool Thread Unwinder Holder (2)
500216XC	Spool Thread Unwinder Holder Screw (2)
506689	Stop Latch
42614	Stop Latch Hinge Stud
457AL	Stop Latch Hinge Stud Set Screw
7958	Stop Latch Stop Pin
41588	Stop Latch Tripping Arm with 185X
185X	Stop Latch Tripping Arm Clamping Screw
501686	Tension Disc

BOBBIN WINDER
 (Supplied with Foot Power Drive Machine)
 (Continued)

No.	Name
501687	Tension Disc Seat
501688	Tension Disc Spring
500217J	Tension Screw
501689	Tension Screw Washer
506799	Thread Guide and Tension Bracket
506800	Thread Guide and Tension Bracket complete, Nos. 500217J, 501686, 501687, 501688, 501689 and 506799
51023K	Thread Guide and Tension Bracket Screw (2)
506801	Bobbin Winder, Nos. 7958, 34105, 41586, 41588, 41914, 42614, 506688, 506689, 506795 and 506796
506802	Bobbin Winder complete, Nos. 506798, 506800 and 506801
692J	Bobbin Winder Screw
506654	Bobbin Winder Screw Washer

BOBBIN WINDER
 (Supplied with Motor Drive Machine)

No.	Name
202470	Base
203094	Bobbin Position Pin
202471	Frame
200221D	Frame Hinge Screw
202472	Frame Spring
200161D	Frame Spring Screw
225368	Pulley with 200380C
200380C	Pulley Set Screw
203095	Spindle with 203094
27306	Spool Pin
27307	Spool Stand
27308	Spool Stand complete, Nos. 418C, 5162J, 2106, 10141, 11241, 27306, 27307 and two each 2455 and wood screws 1 in. No. 10 F.H.
11241	Spool Washer (cloth)
202475	Stop Latch
200056E	Stop Latch Screw
202477	Stop Latch Thumb Lever
200299X	Stop Latch Thumb Lever Hinge Screw
200299X	Stop Latch Thumb Lever Joint Screw

BOBBIN WINDER
(Supplied with Motor Drive Machine)
(Continued)

No.	Name
201537X	Stop Latch Thumb Lever Joint Screw Nut
202478	Stop Latch Trip Lever
200299X	Stop Latch Trip Lever Hinge Screw
2455	Tension Disc (2)
1562J	Tension Regulating Thumb Nut
418C	Tension Screw Stud
10141	Tension Spring
2106	Tension Thread Guide
203096	Bobbin Winder, Nos. 200056E, 200161D, 200221D, 201537X, 202470, 202471, 202472, 202475, 202477, 202478, 203095, 225368, two wood screws 3/4 in. No. 12 R.H. and three 200299X
506722	Bobbin Winder Nos. 203096 and two 9331
506723	Bobbin Winder (swinging automatic, right hand) complete, Nos. 27308 and 506722
9331	Bobbin Winder Washer

AIR TUCKING ATTACHMENT NO. 506803
(Supplied only when ordered and at an additional charge)

No.	Name
506704	Air Tucking Foot (for wide Tucks)
506705	Air Tucking Foot (for narrow Tucks)
506706	Air Tucking Stay (for narrow Tucks)
506707	Air Tucking Stay (for medium Tucks)
506708	Air Tucking Stay (for wide Tucks and cording)
	Twin Needle
506803	Air Tucking Attachment complete, Nos. 506704, 506705, 506706, 506707, 506708 and Twin Needle

BLIND STITCH ATTACHMENT NO. 188724
 (Supplied only when ordered and at an additional charge)

No.	Name
188698	Side Pressure Adjusting Sewing Arm for 188710
183126XC	Side Pressure Adjusting Sewing Arm Hinge Screw for 188710
1700XC	Side Pressure Adjusting Sewing Arm Hinge Nut for 188710
188699	Collateral Cloth Guide for 188710
188702	Collateral Cloth Guide Pressing Spring for 188710
188706	Collateral Cloth Guide Pressing Spring Set Pin for 188710
188700	Collateral Cloth Guide Plate with 188701 for 188710
188706	Collateral Cloth Guide Plate Set Pin for 188710
592X	Collateral Cloth Guide Plate Set Pin Screw for 188710 (2)
188704	Collateral Cloth Guide Plate Holder with 188705 for 188710
183127XC	Collateral Cloth Guide Plate Holder Screw for 188710
188705	Collateral Cloth Guide Plate Hinge Pin for 188704
188701	Collateral Cloth Guide Pin for 188700
188707	Cloth Presser Foot for 188710
188710	Blind Stitch Foot, complete Nos. 592X, 1700XC, 183126XC, 183127XC, 188698, 188699, 188700, 188702, 188704, 188707 and two 188706
188708	Feller Clamp Plate for 188723
183128XC	Feller Clamp Plate Screw for 188723 (2)
188709	Feller Clamp Base for 188723
188711	Feller Clamp Base Bow for 188723
183129X	Feller Clamp Base Bow Screw for 188723 (2)
188712	Feller Clamp Swing Arm for 188723
188713	Feller Clamp Swing Arm Presser Spring for 188723
183130X	Feller Clamp Swing Arm Presser Spring Fastening Screw (190) shortened for 188723
188714	Feller Clamp Swing Arm Guide for 188723
189696	Feller Clamp Swing Arm Guide Spring Disc for 188723 (2)
183131X	Feller Clamp Swing Arm Guide Screw for 188723 (2)
188715	Feller Clamp Swing Arm Fulcrum Pin for 188723
183132X	Feller Clamp Swing Arm Set Screw (No. 7740 with Slot for 188723)
182514X	Feller Clamp Swing Arm Set Screw Nut for 188723 (2)
188723	Feller Clamp complete Nos. 183130X, 183132X, 188708, 188709, 188711, 188712, 188713, 188714, 188715 and two each 182514X, 183128XC, 183129X, 183131X and 189696
188724	Blind Stitch Attachment, complete, Nos. 188710 and 188723

FITTINGS
for Straight Stitching, for Collar Point Work
(Supplied only when ordered and at an additional charge)

No.	Name
506809	Feed Dog, 23 teeth
506614	Presser Foot Hinge Pin
506810	Presser Foot Plate
188576	Presser Foot Shank
506615	Presser Foot Spring
506811	Presser Foot complete, Nos. 188576, 506614, 506615 and 506810
506812	Throat Plate

HEMMERS (Foot)
(Supplied only when ordered and at an additional charge)

No.	Name
160344	Hemmer (foot) 1/16 in. hem
120938	Hemmer (foot) 3/32 in. hem
120803	Hemmer (foot) 1/8 in. hem
120804	Hemmer (foot) 5/32 in. hem
120805	Hemmer (foot) 3/16 in. hem
120806	Hemmer (foot) 1/4 in. hem
120807	Hemmer (foot) 5/16 in. hem

PRESSER FEET
(Supplied only when ordered and at an additional charge)

No.	Name
506709	Air Tucking Foot (for Thick Tucks)
188659	Presser Foot (solid) for Button sewing
188660	Presser Foot (solid) for Edge Quilting
506808	Presser Foot (solid) for straight stitching
188661	Presser Foot (solid) for zig-zag work
188613	Presser Foot (solid) for Satin stitching or Barring
506710	Presser Foot
506711	Presser Foot Buttonhole Indicator
500174J	Presser Foot Buttonhole Indicator Clamping Screw
500175J	Presser Foot Buttonhole Stop Screw
506712	Presser Foot complete, for Buttonholes, Nos. 500174J, 500175J, 506710 and 506711

THROAT PLATES

(Supplied only when ordered and at an additional charge)

No.	Name
506684	Throat Plate for zig-zag work, narrow slot for fine work (Lingerie) for use with regular Feed Dog No. 506686 or special Feed Dog No. 506538
506685	Throat Plate for straight stitching and hemming for use with regular Feed Dog No. 506686 or special Feed Dog No. 506538

FEED DOG

(Supplied only when ordered and at an additional charge)

No.	Name
506538	Feed Dog, coarse (16 teeth per inch) for use with regular Throat Plate No. 506645 or special Throat Plate Nos. 506684 or 506685

KNEE LIFTER PARTS

(Supplied with Foot and Motor Drive Machines)

No.	Name
2763	Rock Shaft
97502	Rock Shaft Hanger (2)
-----	Rock Shaft Hanger Wood Screw (1 in. No. 10 F.H.) (4)
2765	Rock Shaft Knee Arm with 1509E
2766	Rock Shaft Knee Arm Hub with 356C
356C	Rock Shaft Knee Arm Hub Set Screw
1509E	Rock Shaft Knee Arm Lock Nut
2768	Rock Shaft Knee Arm complete, Nos. 2765, 2766 and 2767
2767	Rock Shaft Knee Plate with 356C
356C	Rock Shaft Knee Plate Set Screw
6337	Rock Shaft Lifting Bracket with two 356C
2778	Rock Shaft Lifting Bracket Hook
356C	Rock Shaft Lifting Bracket Hook Set Screw
356C	Rock Shaft Lifting Bracket Set Screw
2770	Rock Shaft Stop Dog with 140219C
140219C	Rock Shaft Stop Dog Set Screw
84789	Rock Shaft complete, Nos. 2763, 2768, 2770, 2778, 6337, two 97502 and four wood screws 1 in. No. 10 F.H.

SPOOL HOLDER (unwinding) COMPLETE
(Supplied only when ordered and at an additional charge)

No.	Name
503529	Spool Holder Bracket with 219J and 50053D
219J	Spool Holder Set Screw
19066	Spool Holder Spindle
50053D	Spool Holder Spindle Set Screw
184033	Spool Holder Spindle Thread Slide Disc
691A	Spool Holder Spindle Thread Slide Disc Screw
503530	Spool Holder (unwinding) complete, Nos. 691A, 19066, 503529 and 184033, attachable to Thread Guide and Spool Pin (top of arm)