


SINGER

348K

List of Parts—SINGER* Machine No. 348K









ATTACHMENT SET 101540



- | | |
|-------------|----------------------|
| 32773 | Presser Foot |
| 161127 | Zipper Foot |
| 161172 | Seam Guide |
| 161295 | Screwdriver (SM) |
| 161609 | Tube of Oil |
| 161613 | Presser Foot |
| 161612 | Button Foot |
| 161894 | Raising Plate |
| 161895 | Throat Plate |
| 172336 | Bobbin (Plastic) (3) |
| 276302 | Fashion Disc 2 |
| 276303 | Fashion Disc 3 |
| 276305 | Fashion Disc 5 |
| 276306 | Fashion Disc 6 |
| 276308 | Fashion Disc 8 |
| 276309 | Fashion Disc 9 |
| 276310 | Fashion Disc 10 |
| 276312 | Fashion Disc 12 |
| 276313 | Fashion Disc 13 |
| 276319 | Fashion Disc 19 |
| 276321 | Fashion Disc 21 |
| 276326 | Fashion Disc 26 |
| 276331 | Fashion Disc 31 |
| 2020(15x1) | Needles 14 (3) |
| 21475(Rev.) | Instruction Book |



List of Parts—Machine No. 348K




For other discs see
Parts List Section
No. 276302 to 276331




From the library of: Diamond Needle Corp

List of Parts—Machine No. 348K







From the library of: Diamond Needle Corp


SINGER[®] SNK 4/ENK 4 for 337K, 338K, 347K & 348K Machines



WIRING DIAGRAM




From the library of Diamond Needle Corp




SNK 4/ENK 4 MOTOR

LIGHT



89480-017 (95 - 145 VOLTS)

FOOT CONTROLLER DOUBLE PILE



From the library of: Diamond Needle Corp

FOOT CONTROLLER SINGLE PILE

SNK 4/ENK 4 MOTOR

618776 004 (95 - 145 VOLTS)

