


SINGER
628E1/628E6/628E7

List of Parts—Machines Nos. 628E1, 628E6 and 628E7


ATTACHMENT SET 161867

21906	Loop Retainer Disc
21913	Throat Plate
81200	Binder
161133	Tube of Oil
161166	Zipper Foot
161168	Button Foot
161172	Seam Guide
161195	Hemmer Foot
161276	Lint Brush
161868	Attachment Box
163131	Bobbin (2)
163242	Spot Pin
163455	Thread Guide
163483	Special Purpose Foot
170071-001	Presser Foot
172185	Fashion Disc 1
172187	Fashion Disc 2
172190	Fashion Disc 4
172191	Fashion Disc 5
174527	Fashion Disc 9
174528	Fashion Disc 8
174529	Throat Plate
174533	Fashion Disc 10
174538	Fashion Disc 18
2020(15x1)	Needles 14 (3) 16 (3)






List of Parts—Machines Nos. 628E1, 628E6 and 628E7

NOTE: Set of Mated Gears or Individual Gears are not furnished. Supplied only when repairs are made at the factory.



Electrical Parts—Machines Nos. 628E1, 628E6 and 628E7



From the library: Diagram Needs Out

