


SINGER
646E3/646E6/646E7

620 173745043

Machine No. 646E

List of Parts--Machines Nos. 646E3, 646E6 and 646E7




ATTACHMENT SET 171125

- 21906 Chainstitch Attachment Loop Retainer Disc
- 21913 Chainstitch Attachment Throat Plate
- 161133 Tube of Oil
- 161166 Zipper Foot
- 161168 Presser Foot for button sewing
- 161172 Seam Guide
- 161276 Lint Brush
- 161917 Presser Foot Plate (snap-on, plastic) for sewing buttonholes
- 161919 Presser Foot Plate (snap-on) for straight sewing
- 161960 Glassing Envelope containing two needle threader hooks and Instruction Form 21632
- 163131 Bobbin (3)
- 163242-656 Spool Pin for two needle sewing
- 163455 Chainstitch Attachment Thread Guide
- 163483 Special Purpose Presser Foot
- 171124-656 Attachment Box
- 174529 Throat Plate for straight sewing
- Needle Cat. 2020 Size 14 (3)
- Needle Cat. 2020 Size 16 (3)
- Twin Needle Cat. 2028 Size 14 (1)



List of Parts—Machines Nos. 646E3, 646E6 and 646E7



Electrical Parts—Machines Nos. 646E3, 646E6 and 646E7

