

SINGER

52-12

LIST OF PARTS COMPLETE

FOR

MACHINE NO. 52-12

LIST OF PARTS COMPLETE

FOR

MACHINE NO. 12-12

| <u>No.</u> | <u>Name</u> |
|------------|------------------------------------|
| *13576 | Arm with 450C, 2006 and 2803 |
| 8582 | " Dowel Pin (back) |
| 4389 | " " " (front) |
| 123 E | " Screw (left, back) |
| 880 E | " " (left, front) |
| 138 E | " " (right) |
| 13502 | " Shaft |
| 2006 | " " Bushing (back) |
| 450 C | " " " " Set Screw |
| *2803 | " " " (front) |
| 144 D | " " Screw |
| 1519C | " Side Cover |
| 51224 W | " " " Thumb Screw |
| *13577 | Bed |
| 2811 | Crank Connecting Rod with two 158E |
| 158 E | " " " Cap Screw |
| 375 C | " " " Hinge Screw |
| 1518 E | " " " " " Nut |
| 13578 | Face Plate |
| 190 E | " " Screw |
| 13506 | Feed Bar |
| 315 C | " " Screw Center |
| 1519 E | " " " " Nut |
| 2039 | " Connecting Link |

| <u>No.</u> | | <u>Name</u> |
|------------|----|---------------------------------------|
| 378 | C | Feed Connecting Link Hinge Screw |
| 1520 | E | " " " " " Nut |
| 30226 | | " Dog |
| 30227 | | " " |
| 30228 | | " " |
| 30229 | | " " |
| 30230 | | " " |
| 30231 | | " " |
| 30232 | | " " |
| 30233 | | " " |
| 30234 | | " " |
| 30235 | | " " |
| 30236 | | " " |
| 30237 | | " " |
| 30238 | | " " |
| 30239 | | " " |
| 30240 | | " " |
| 191 | C | " " Screw |
| 2261 | | " Eccentric with 448AL |
| 448 | AL | " " Set Screw |
| 2042 | | " Forked Connection |
| 378 | C | " " " Hinge Screw |
| 1520 | E | " " " " " Nut |
| 13508 | | " Lifting Rock Shaft |
| 13509 | | " " " " complete, Nos. 2509 and 13508 |

| <u>No.</u> | <u>Name</u> |
|------------|--|
| 2509 | Feed Lifting Rock Shaft Crank with 157J and 1813 |
| 157 J | " " " " " Clamping Screw |
| 1813 | " " " " " Roller and Stud |
| 307 C | " " " " " Screw Center (left) |
| 1513 C | " " " " " " " Nut |
| 857 C | " " " " " " (right) |
| 2164 | " Regulator |
| 74 E | " " Hinge Screw |
| 747 E | " " Thumb Screw |
| 2047 | " Rock Shaft |
| 2046 | " " " 2047 with 2048 |
| 2048 | " " " Crank with 465C |
| 2049 | " " " " Pin |
| 465 C | " " " " Set Screw |
| 307 C | " " " Screw Center |
| 1513 C | " " " " " Nut |
| 13616 | Looper, small (left hand) |
| 13617 | " " (right hand) |
| 13634 | " Carrier with two 237AL and twelve 853AL |
| 237 AL | " " Set Screw |
| 13516 | " " Shaft |
| 13517 | " " " Bushing |
| 448 AL | " " " " Set Screw |
| 237 AL | " " " Set Screw |
| 13579 | " Driving Shaft |

| <u>No.</u> | <u>Name</u> |
|------------|--|
| 13519 | Looper Driving Shaft Crank with 460AL and 1962 |
| 2269 | " " " " Pin |
| 1962 | " " " " Roller and Stud |
| 460 AL | " " " " Set Screw |
| 13520 | " " " " Head with 211C |
| 2273 | " " " " Pin |
| 13521 | " " " " Link with 329E |
| 329 E | " " " " Adjusting Screw |
| 829 C | " " " " Hinge Screw |
| 1520 E | " " " " " " Nut |
| 13580 | " " " " complete, Nos. 2273, 13520 and 13579 |
| 853 AL | " " " " Set Screw |
| 13503 | Machine Pulley with two 448AL |
| 448 AL | " " " " Set Screw |
| 13581 | Needle Bar (hollow) |
| 13582 | " " " " Connecting Link with 794E |
| 794 E | " " " " Adjusting Screw |
| 881 C | " " " " Hinge Screw |
| 13674 | " " " " Stud with 1904 and two 640C |
| 640 C | " " " " Clamping Screw |

| <u>No.</u> | <u>Name</u> |
|------------|---|
| 1904 | Needle Bar Connecting Stud Roller (roller only) |
| 13585 | " " Crank with 435AL and 1293AL |
| 1293 AL | " " " Position Screw |
| 435 AL | " " " Set Screw |
| 13653 | " Clamp with twelve 50014 AL |
| 2273 | " " Pin |
| 50014 AL | " Set Screw |
| 13526 | Oscillating Rock Shaft |
| 3052 | " " " Hinge Pin |
| 1513 C | " " " " " Nut |
| 635 C | " " " " " Screw Bearing |
| 1513 C | " " " " " " " Nut |
| 2058 | Presser Bar |
| 2062 | " " Lifter |
| 1058 C | " " " Hinge Screw |
| 1520 E | " " " " " Nut |
| 2983 | " " Lifting Bracket with 453AL |
| 453 AL | " " " " Set Screw |
| 2308 | " " Spring |
| 2070 | " " " Washer |

| <u>No.</u> | <u>Name</u> |
|------------|--------------|
| 30391 | Presser Foot |
| 30392 | " " |
| 30393 | " " |
| 30394 | " " |
| 30395 | " " |
| 31376 | " " |
| 31377 | " " |
| 31378 | " " |
| 31379 | " " |
| 31380 | " " |
| 31381 | " " |
| 31382 | " " |
| 31383 | " " |
| 31384 | " " |
| 31385 | " " |
| 31386 | " " |
| 31387 | " " |
| 31388 | " " |
| 31389 | " " |
| 31390 | " " |
| 31391 | " " |

| <u>No.</u> | | <u>Name</u> |
|------------|----|---|
| 190 | J | Presser Foot Screw |
| 263 | W | Pressure Regulating Thumb Screw |
| 13722 | | Tension Bracket with twenty-one 13589 |
| 13723 | | " " complete, Nos. 13722, twelve each 637C, 1547D, 1560C, 13710 and twenty-four 2921 |
| 914 | A | " Bracket Screw |
| 2921 | | " Disc |
| 13589 | | " " Steady Pin |
| 1560 | C | " Regulating Thumb Nut |
| 637 | C | " Screw Stud |
| 1547 | D | " " " Nut |
| 13710 | | " Spring |
| 13673 | | Thread Guide (back of arm) |
| 13609 | | " " (side of arm) |
| 219 | A | " " " " " Screw |
| 1609 | D | " Nipper Adjusting Thumb Nut |
| 13533 | | " " Body |
| 460 | AL | " " " Set Screw |
| 13534 | | " " Cam with 882AL |
| 882 | AL | " " " Set Screw |
| 13669 | | " " Eyelet |
| 1527 | D | " " Lock Nut |
| 13567 | | " " Separating Plate |
| 12162 | | " " " " Guide Pin |
| 13537 | | " " Stud with 13538 |

| <u>No.</u> | <u>Name</u> |
|------------|---|
| 13538 | Thread Nipper Stud Position Pin |
| 13539 | " " " Roller |
| 13540 | " " " " Pin |
| 2026 | " " " Spring |
| 13559 | " " " complete, Nos. 13537, 13539 and 13540 |
| 13716 | " " " complete, Nos. 1527D, 1609D, 2026, 13533, 13559, 13669 and four 13567 |
| 13709 | Thread Take-Up Plate |
| 883 B | " " " Screw |
| 30786 | Throat Plate |
| 30787 | " " |
| 30788 | " " |
| 30789 | " " |
| 30790 | " " |
| 30791 | " " |
| 30792 | " " |
| 30793 | " " |
| 30794 | " " |
| 30795 | " " |
| 30796 | " " |
| 30797 | " " |
| 30798 | " " |
| 30799 | " " |
| 691 A | " " Screw |
| 13635 | Drip Pan with four 1 inch wire nails |