

HISTORICAL COPY
NUMBERING DEPARTMENT
JUNE 13, 1912
DO NOT REMOVE
COPY FOR M. T.

**LIST OF PARTS
COMPLETE**



Machine No. 62-48

From the library of: Diamond Needle Corp

THE SINGER MANUFACTURING COMPANY

HISTORICAL COPY
REPRODUCED FROM THE ORIGINAL
 JUNE 13, 1912

DO NOT REMOVE

LIST OF PARTS COMPLETE

FOR

MACHINE NO. 62-48

For general work in light fabrics, for trimming and binding in one operation, has vertical shear trimmer operated by an eccentric on the Arm Rotary Shaft, trims from $\frac{1}{16}$ to $\frac{3}{16}$ inch from the needle.

| | | |
|--------|---|-------|
| *52607 | Arm (upper and lower) solid..... | 20 00 |
| 46216 | " Rock Shaft..... | 1 00 |
| 46217 | " " " Crank (back) with two 1497c..... | 00 |
| 1497c | " " " " " Set Screw..... | 00 |
| 38412 | " " " " (front) with 443c..... | 1 00 |
| 23724 | " " " " " Pin..... | 01 |
| 443c | " " " " " Set Screw..... | 03 |
| 46343 | " Rotary Shaft..... | 3 00 |
| 38329 | " " " Collar with two 457c..... | 20 |
| 457c | " " " " " Set Screw..... | 02 |
| 23872 | " " " Flanged Bushing..... | 1 00 |
| 159F | " " " " " Screw..... | 03 |
| 4784 | " " " Oil Pad (felt)..... | 01 |
| 144D | " " " " " Screw..... | 03 |
| 17509 | " Side Cover (lower)..... | 10 |
| 286D | " " " " " Thumb Screw..... | 10 |
| 52554 | " " " (upper)..... | 20 |
| 9533 | " " " " " Pin..... | 02 |
| 176D | " " " " " Screw..... | 03 |
| 23873 | Balance Wheel with two 430c..... | 80 |
| 430c | " " " " " Set Screw..... | 04 |
| 52608 | Cloth Plate..... | 2 50 |
| 52609 | " " " Chute (hinged)..... | 1 25 |
| 330D | " " " " " Screw..... | 02 |
| 691F | " " " " " Screw (left)..... | 04 |
| 1094F | " " " " " (right)..... | 03 |
| 46322H | " " " Slide (left)..... | 40 |
| 38419 | " " " " " Spring..... | 05 |
| 725H | " " " " " " Screw..... | 02 |
| 46323H | Cloth Plate Slide (left) complete, Nos. 38419, 46322H and two 725H..... | 50 |
| 52610 | Cloth Plate Slide (right) with 1602E..... | 30 |
| 1602E | " " " " " Bushing..... | 02 |
| 286D | " " " " " Thumb Screw..... | 10 |

From the library of: Diamond Needle Corp

| | | |
|--------|--|-----|
| 52611 | Cloth Plate complete, Nos. 286D, 46323H, 52608 to 52610 and two 330D. | 470 |
| 46221 | Crank Connecting Rod with 46222, 46223 and two each 896E and 1057E. | 200 |
| 50069C | Crank Connecting Rod Ball Screw Stud. | 20 |
| 1619E | " " " " " " Nut. | 05 |
| *46222 | " " " " " " Cap (lower). | 25 |
| 896E | " " " " " " Screw. | 04 |
| *46223 | " " " " " " (upper). | 35 |
| 1057E | " " " " " " Screw. | 04 |
| 46225 | " " " " " " Washer (fibre). | 02 |
| 46179 | Face Plate. | 50 |
| 46111 | " " Pin. | 02 |
| 286D | " " Thumb Screw. | 10 |
| 38425 | Feed Bar with 231C and 460C. | 250 |
| 23716 | " " Bushing. | 40 |
| 23726 | " " Hinge Pin. | 50 |
| 231C | " " Set Screw. | 03 |
| 38426 | " " Slide Block. | 50 |
| 38427 | " Connecting Rod with 23865 and three 1057E. | 150 |
| *23865 | " " " " Cap. | 30 |
| 1057E | " " " " " " Screw. | 04 |
| 23866 | " " " " " " Hinge Pin (eccentric). | 20 |
| 1057E | " " " " " " Clamping Screw. | 04 |
| 52612 | " Dog. | 100 |
| 898D | " " Screw. | 04 |
| 460C | " " Stop Screw. | 02 |
| *38127 | " Eccentric. | 250 |
| *23729 | " " Body. | 250 |
| 443C | " " " " Set Screw. | 03 |
| 21331 | " " " " Pressure Spring. | 03 |
| 21332 | " " " " " " Cap. | 10 |
| 934D | " " " " " " Screw. | 02 |
| 196F | " " " " " " Set Screw. | 02 |
| 38128 | Feed Eccentric (adjustable) complete, Nos. 196F, 934D, 1103C, 21331, 21332, 23729, 38127 and two 443C. | 500 |
| 1103C | Feed Regulating Screw. | 15 |
| 38431 | " Rocking Frame. | 125 |
| 52613 | " " " " Bracket with two 465C. | 50 |
| 123E | " " " " " " Screw. | 06 |
| 38433 | " " " " " " Hinge Pin. | 50 |
| 465C | " " " " " " Set Screw. | 02 |
| 52614 | Knife. | 10 |
| 52615 | " Bar. | 400 |
| 46350 | " " Eccentric with two 457C. | 100 |
| 457C | " " " " " " Set Screw. | 02 |
| 52616 | " Holder. | 100 |

| | | |
|--------|---|-----|
| 1259C | Knife Holder Adjusting Screw. | 03 |
| 190C | " " " " Screw. | 03 |
| 52617 | " " Support. | 50 |
| 206D | " " " " " " Screw. | 02 |
| 52618 | Looper with 590D and 38393. | 225 |
| 46226 | " Bell Crank with 1037C. | 50 |
| 38436 | " " " " " " Hinge Stud. | 100 |
| 443C | " " " " " " Set Screw. | 03 |
| 46227 | Looper Bell Crank Pitman complete, Nos. 1706E, 1713E and 46233 to 46235. | 325 |
| 50070C | Looper Bell Crank Pitman Ball Screw Stud (upper) | 15 |
| 1636E | " " " " " " " " " " Nut. | 03 |
| 46228 | Looper Bell Crank Pitman Ball Stud (lower). | 30 |
| 1037C | " " " " " " " " " " S e t S c r e w . | 04 |
| *46229 | Looper Bell Crank Pitman Cap (lower). | — |
| 171E | " " " " " " " " " " Screw. | 03 |
| *46230 | " " " " " " " " " " (upper). | — |
| 171E | " " " " " " " " " " Screw. | 03 |
| *46231 | " " " " " " " " " " End Bearing (lower). | — |
| *46232 | " " " " " " " " " " (upper). | — |
| 46233 | " " " " " " " " " " H e a d (lower) Nos. 46228, 46229, 46231 and two 171E. | 150 |
| 46234 | Looper Bell Crank Pitman Head (upper) Nos. 46230, 46232, 50070C and two 171E. | 150 |
| 46235 | Looper Bell Crank Pitman Rod. | 20 |
| 1706E | " " " " " " " " " " Nut (lower). | 03 |
| 1713E | " " " " " " " " " " (upper). | 03 |
| 52619 | " Carrier with three 1147C. | 150 |
| 38440 | " " " " " " Hinge Pin. | 20 |
| 1147C | " " " " " " " " " " Set Screw. | 03 |
| 52620 | Looper Carrier Pitman complete, Nos. 1697C, 1698C, 38445, 38446 and 52621. | 325 |
| 50016C | Looper Carrier Pitman Ball Screw Stud (right). | 15 |
| 1518E | " " " " " " " " " " Nut | 04 |
| 38442 | " " " " " " " " " " Stud (left). | 25 |
| 1147C | " " " " " " " " " " Set Screw. | 03 |
| *42525 | " " " " " " " " " " Cap (left). | — |
| 187D | " " " " " " " " " " Screw. | 02 |
| *42524 | " " " " " " " " " " (right). | — |
| 187D | " " " " " " " " " " Screw. | 02 |
| *38443 | " " " " " " " " " " End Bearing (left). | — |
| *38444 | " " " " " " " " " " (right). | — |
| 38445 | " " " " " " " " " " Head (left) Nos. 38442, 38443, 42525 and two 187D. | 150 |
| 38446 | Looper Carrier Pitman Head (right) Nos. 38444, 42524, 50016C and two 187D. | 150 |

| | | |
|-------|---|------|
| 52621 | Looper Carrier Pitman Rod..... | 10 |
| 1697C | " " " " Nut (left)..... | 03 |
| 1698C | " " " " " (right)..... | 03 |
| 46042 | " " Rock Shaft with two 175D..... | 2 50 |
| 175D | " " " " Adjusting Screw..... | 02 |
| 38450 | " " " " Crank (forked) with 159E..... | 2 00 |
| 159E | Looper Carrier Rock Shaft Crank Clamping Screw..... | 03 |
| 38451 | " " " " Slide Block..... | 50 |
| 46043 | " " " " Hinge Pin..... | 75 |
| 1508C | " " " " " Nut..... | 06 |
| 129E | " " " " " Set Screw..... | 04 |
| 38452 | " Eccentric with two 465C..... | 1 00 |
| 465C | " " Set Screw..... | 02 |
| 52622 | " Needle Guard with 46105..... | 40 |
| 46105 | " " Pin..... | 01 |
| 229D | " " " Screw..... | 02 |
| 1147C | " Set Screw..... | 03 |
| 46358 | " Shaft and Feed Lifting Eccentric..... | 2 50 |
| 38454 | " " " " " Bracket..... | 30 |
| 123E | " " " " " Screw..... | 06 |
| 391F | Looper Shaft Screw..... | 02 |
| 38393 | " Thread Guard..... | 03 |
| 590D | " " " Screw..... | 02 |
| 38455 | Needle Bar (hollow) with 857H..... | 1 00 |
| 38456 | " " Bushing..... | 50 |
| 1133E | " " " Set Screw..... | 02 |
| 38458 | " " Connecting Link..... | 50 |
| 38459 | " " " " Hinge Stud..... | 30 |
| 1520E | " " " " " Nut..... | 03 |
| 38460 | " " " Stud with two 391E..... | 1 00 |
| 391E | " " " " Clamping Screw..... | 02 |
| 52623 | " Guard..... | 75 |
| 190D | " " Screw..... | 03 |
| 857H | " Set Screw..... | 02 |
| 17540 | Presser Bar..... | 30 |
| 38464 | " " Bushing (lower)..... | 80 |
| 1133E | " " " " Set Screw..... | 02 |
| 38456 | " " " (upper)..... | 50 |
| 1133E | " " " " Set Screw..... | 02 |
| 17541 | " " Lifter..... | 20 |
| 17542 | " " " Hinge Pin..... | 05 |
| 38466 | " " Lifting Bracket with 453C and 892C..... | 1 00 |
| 892C | " " " " Adjusting Screw..... | 05 |
| 453C | " " " " Set Screw..... | 02 |
| 38467 | " " Spring (flat)..... | 50 |
| 38468 | " " " Stud..... | 03 |

| | | |
|--------|--|------|
| 26276 | Presser Foot Hinge Pin..... | 01 |
| 52624 | " " Plate..... | 1 25 |
| 46099 | " " Shank..... | 60 |
| 52625 | Presser Foot (hinged) complete, Nos. 26276, 46099, and 52624..... | 1 85 |
| 190D | Presser Foot Screw..... | 03 |
| 574D | Pressure Regulating Thumb Screw..... | 15 |
| 1539D | " " " " Lock Nut..... | 05 |
| 46169 | Slack Thread Controller..... | 05 |
| 211F | " " " " Set Screw..... | 02 |
| 52626 | " " Regulator..... | 1 50 |
| 52569 | " " " Bracket with 172C and 1823..... | 1 25 |
| 172C | Slack Thread Regulator Bracket Clamping Screw..... | 04 |
| 38474 | " " " Bushing..... | 20 |
| 1823 | " " " Roller and Stud..... | 18 |
| 50062D | " " " Screw..... | 07 |
| 1620E | " " " " Nut..... | 03 |
| 2102 | Tension (under thread) Disc..... | 05 |
| 1560C | " " " Regulating Thumb Nut..... | 04 |
| 916F | " " " Screw Stud..... | 08 |
| 10148 | " " " Spring..... | 03 |
| 17547 | " " " Thread Guide..... | 25 |
| 2102 | " (upper thread) Disc..... | 05 |
| 1560C | " " " Regulating Thumb Nut..... | 01 |
| 916F | " " " Screw Stud..... | ? |
| 2103 | " " " Spring..... | ? |
| 17547 | " " " Thread Guide..... | 25 |
| 38225 | Thread (under) Eyelet (back)..... | 10 |
| 190D | " " " " Screw..... | 03 |
| 38284 | " " " (front)..... | 05 |
| 46049 | " " Nipper Cam with 465C..... | 50 |
| 465C | " " " " Set Screw..... | 02 |
| 38210 | " " " Spring (lower)..... | 15 |
| 38211 | " " " " (upper)..... | 25 |
| 46247 | " " " " Stop..... | 10 |
| 176F | " " " " Screw..... | 03 |
| 38475 | " " Take-up with 465C..... | 1 00 |
| 465C | " " " Set Screw..... | 02 |
| 38478 | " " " Staple with two each 590D, and 38481..... | 75 |
| 46040 | Thread (under) Take-up Staple Bracket with 910C..... | 2 00 |
| 690D | " " " " " Screw..... | 05 |
| 46041 | " " " " " Spring..... | 05 |
| 190D | " " " " " Screw..... | 03 |
| 910C | " " " " " Stop Screw..... | 03 |
| 38481 | " " " " " Thread Guard..... | 10 |
| 590D | " " " " " Screw..... | 02 |

| | | |
|-------|---------------------------------------|-----|
| 38482 | Thread (under) Take-up Stripper..... | 60 |
| 207D | " " " " Screw..... | 02 |
| 38476 | " " " Thread Guard (left)..... | 15 |
| 207D | " " " " " Screw..... | 02 |
| 38477 | " " " " " (right)..... | 20 |
| 207D | " " " " " " Screw..... | 02 |
| 38483 | " (upper) Controller..... | 40 |
| 206F | " " " Screw..... | 02 |
| 52627 | " " Eyelet..... | 25 |
| 190D | " " " Screw..... | 03 |
| 46312 | " " Take-up with 223D..... | 80 |
| 223D | " " " Clamping Screw..... | 02 |
| 52628 | Throat Plate with 665D and 52629..... | 175 |
| 52629 | " " Cutting Bar..... | 25 |
| 665D | " " " " Screw..... | 02 |
| 691F | " " " Screw..... | 04 |

ACCESSORIES

| | | |
|-------|--|----|
| 2015 | Machine Cushion (rubber)..... | 02 |
| — | 1 3/4 in. Wood Screw No. 16, to secure machine to table..... | |
| 4718 | Machine Rest (felt)..... | 01 |
| 35859 | Oiler with Cap and 35861..... | 07 |
| 35860 | " 35859, filled with oil..... | 10 |
| 35861 | " Spout, 3 1/2 in. long..... | 03 |
| 26026 | Screw Driver..... | 10 |
| 38487 | Threading Wire..... | 05 |
| 35095 | Tweezers, 6 in..... | 40 |
| 8908 | Wrench for 1520, 1620 and 1706..... | 08 |
| 23766 | " " 1508 and 1636..... | 10 |
| 19221 | " " 1619..... | 15 |
| 4822 | " " 1697 and 1698..... | 05 |

BINDER

| | | |
|-------|--|------|
| 36473 | Binder on Block with two 910F..... | 4 00 |
| 910F | " Adjusting Screw..... | 03 |
| 36474 | " Pin (long)..... | 01 |
| 36475 | " " (short)..... | 01 |
| 36476 | " Plate with 36474 and 36475..... | 50 |
| 219F | " " Screw..... | 02 |
| 26614 | Ribbon Tension Pin (bent)..... | 05 |
| 26615 | " " " (straight)..... | 05 |
| 26616 | " " Plate..... | 35 |
| 25717 | Ribbon Tension complete, Nos. 26614, 26616 and four 26615..... | 60 |
| 219F | Ribbon Tension Screw..... | 02 |
| 7071 | " " " Washer..... | 01 |

FOOT LIFTER PARTS

| | | |
|--|---|-----|
| 6439 | Chain, 36 in. to 45 in..... | 20 |
| NOTE: When ordering No. 6439 give length required. | | |
| 4879 | Chain Connecting Link for 4885..... | 03 |
| 23759 | Lifting Lever..... | 25 |
| 802D | " " Hinge Screw..... | 15 |
| 23761 | " " Spring..... | 15 |
| 1002D | " " Stop Screw..... | 05 |
| 4881 | Treadle..... | 30 |
| 4882 | " Shaft..... | 05 |
| 4883 | " Spring..... | 10 |
| 4884 | " Stand..... | 25 |
| 4885 | Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16..... | 75 |
| 23769 | Foot Lifter complete, Nos. 802D, 1002D, 4885, 6439, 23759 and 23761..... | 135 |

KNEE LIFTER PARTS

| | | |
|-------|---|----|
| 23759 | Lifting Lever..... | 25 |
| 23760 | " " Connecting Rod for 23768..... | 05 |
| 38384 | " " " " " 38385..... | 05 |
| 802D | " " Hinge Screw..... | 10 |
| 23761 | " " Spring..... | 05 |
| 1002D | " " Stop Screw..... | 03 |
| 2763 | Rock Shaft..... | 10 |
| 12242 | " " Hanger with two wood screws 1 in. No. 10..... | 08 |

PARTS FOR MACHINE NO. 62-48

| | | |
|-------|--|-----|
| 6335 | Rock Shaft Knee Arm..... | 10 |
| 6336 | Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335..... | 40 |
| 2766 | Rock Shaft Knee Arm Hub with 356c..... | 15 |
| 356c | " " " " " Set Screw..... | 06 |
| 2767 | " " " " Plate with 356c..... | 18 |
| 356c | " " " " " Set Screw..... | 06 |
| 6337 | " " " " Lifting Bracket with two 356c..... | 20 |
| 7125 | " " " " Hook..... | 15 |
| 356c | " " " " " Set Screw..... | 06 |
| 356c | " " " " " Set Screw..... | 06 |
| 2770 | " " " " Stop Dog with 356c..... | 12 |
| 356c | " " " " " Set Screw..... | 06 |
| 23767 | Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242..... | 110 |
| 23768 | Knee Lifter complete (power table) Nos. 802D, 1002D 23759 to 23761 and 23767..... | 155 |
| 38385 | Knee Lifter complete (bench stand) Nos. 802D, 1002D, 23759, 23761, 23767 and 38384..... | 160 |

THREAD UNWINDER

FOR TWO LARGE SPOOLS OR TWO LARGE CONES OF THREAD

| | | |
|-------|--|------|
| 27623 | Spool Pin..... | 08 |
| 155c | " " " Set Screw..... | 03 |
| 41530 | " Rest..... | 30 |
| 41531 | " " 41530 with 1149c and two each 155c and 27623..... | 50 |
| 1149c | Spool Rest Set Screw..... | 04 |
| 27940 | " Stand with 453c..... | 20 |
| 41514 | " Weight, 4 in. diam., with 41515..... | 15 |
| 41515 | " " Centre Pin..... | 05 |
| 27739 | Thread Cone (wood)..... | 05 |
| 41631 | " Guard with 208E and two 41569..... | 35 |
| 41569 | " " Eyelet..... | 02 |
| 41637 | " " Rod (lower)..... | 10 |
| 41638 | " " " (upper)..... | 15 |
| 41639 | " " " Coupling with two 456c..... | 20 |
| 456c | " " " " " Set Screw..... | 02 |
| 41640 | Thread Guard Rod complete, 30 in. long, Nos. 41637 to 41639..... | 45 |
| 453c | Thread Guard Rod Set Screw..... | 02 |
| 208E | " " Screw..... | 02 |
| 41533 | Thread Unwinder complete, Nos. 27940, 41531, 41631, 41640, two each 27739, 41514 and three wood screws 1 in. No. 12..... | 1.80 |